



LIFAN B-class vehicle spare part catalogue

LF7162/LF7162C



Introduction

- 1.The catalogue of the spare parts can only show its structure combination for directing the customer for maintenance; it can't completely show the practical status of the spare parts, thus, the catalogue of the spare parts can only be taken as a reference for ordering after-sales service spare parts.
- 2.Since the relevant parts for one model of car are in sorts of status, and the pictures of the parts in the catalogue can only show the newest status of the parts upon the editing this catalogue, thus, it can't reflect the details of parts which are presented in the price list.
- 3.Because our company are continuously improving the quality of LIFAN620 series of cars, relevant spare parts are also in the process to be optimized. Because it costs a period of time for the making of the catalogues of spare parts, the new-optimized spare parts can't be edited in the catalogues.
- 4.The parts price list is the main foundation for customers to order after-service parts not including packaging charges for requirements.
- 5.The parts price list includes parts code, name, model, design, status description, price and reference picture. Principally one component code only refers to one parts with entity status; thus parts code is as the only efficient foundation to get parts entity status.
- 6.When ordering spare parts with price list, one should get the model and design for required parts, get the name of the parts, and get the description behind the parts name which should conform with the status, finally determine the parts code.

7. In terms of comprehensive technology and procurement possibility, for which not on the price list partly can separate parts superficially and not solely provide principally. It will make side effect to the complete vehicle safety and operation if solely provided.
8. Due to the potential mistakes of written, please contact our personnel in charge of parts to assure the accuracy of real shipment if finding the difference between the real status and the status on the spare price list.
9. There are some reference pictures on the price list. Due to the pictures can not reflect the entity, customers can not make the entity pictures as the foundation of goods proof, please make the entity arrived as standard and the picture is as reference of ordering.

**Any query please contact the LIFAN
automobile service net!!!**


CONTENTS

LF7162 Spare parts catalogue.....	Page 1
LF7162C Spare parts catalogue.....	Page 261
LF7162/LF7162C Spare parts price list.....	Page 538

LF7162 spare parts catalogue

(Version:200904)


1.01 Engine-Transmission



1.01 Engine-Transmission

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	L1000000A1	发动机总成	Engine assy.	1		√
2	Q1411250TF9	螺栓(变速器与发动机连接)	Bolt	6		
3	Q1411270TF9	螺栓(变速器与发动机连接)	Bolt	1		
4	L1701000A1	变速器总成	Transmission assy.	1		√


1.02 Cylinder head



1.02 Cylinder head

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1		气缸盖罩双头螺栓	Cylinder head cover thru-stud	4		
2	04777997AA	气缸盖罩螺栓带胶圈	Cylinder head cover bolt	8		√
3	4693174AA	气缸盖罩螺栓胶圈	Cylinder head cover bolt washer	12		
4	4777796AE	气缸盖罩总成	Cylinder Head Cover assy	1		√
5	4693134AA	加油口盖	Cap,Oil Filler	1		
6	04777799AA	气缸盖罩垫片	Gasket, Cylinder Cover	1		√
7	4777794AA	火花塞套筒	Spark pulg Guild Pipe	4		
8	6036346AA	工艺堵头(装)	Plug	2		
9	6505239AA	气缸盖螺栓	Cylinder head bolt	10		√
10	53010533AA	气缸盖定位销	Pin	2		√
11	04693083AA	气缸垫	Cylinder head gasket	1		√
12	6036307AA	工艺堵头(装)	Plug	1		
13	4777739AB	气缸盖组件	Cylinder Head	1		
14	6101940	气缸盖连接螺栓	Bolt	2		√
15	04693124AA	工艺堵塞(带密封圈)	Plug	2		√
16	4693206AB	PCV阀软管(曲轴箱通风)	PCV valve vent hose	1		√
17	4884249AA	PCV阀总成	PCV assy.	1		
18	4777796AE	气缸盖罩总成	Cylinder Head Cover assy	1		√

1.03 Valve timing mechanism




1.03 Valve timing mechanism

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	4693304AA	排气摇臂	Intake swing arm	4		√
2	04777783AA	进气摇臂轴隔圈	Intake swing arm spacer	4		√
3	4777785AA	排气摇臂轴组件(含堵头)	Intake swing arm shaft	1		√
4	4693122AA	凸轮轴	Camshaft	1		√
5	6501689	凸轮轴轴承盖连接螺栓	Bolt	10		
6	4777879AB	进气摇臂(右)	Intake swing arm (R)	4		√
7	4777778AB	进气摇臂(左)	Intake swing arm (L)	4		√
8	04777776AA	进气摇臂轴组件(含堵头)	Intake swing arm shaft	1		√
9	4777050AC	气门弹簧锁片	Valve Spring lock	32		√
10	4777774AA	气门弹簧座	Valve Spring Retainer	16		√
11	4777773AA	气门弹簧	Valve Spring	16		√
12	04663904AA	气门油封	Valve seal	16		
13		气门导管	Valve Guide	16	set on cylinder head	
14		进气阀座	Intake valve carrier	8	set on cylinder head	
15	4777772AC	排气门	Exhaust Valve	8		√
16	PBS0518CH	气缸盖总成	Cylinder Head assy	1		
17		凸轮轴轴承盖定位销	Pin	5	set on cylinder head	
18		凸轮轴轴承盖	Camshaft bearing Cap	5	set on cylinder head	

1.03 Valve timing mechanism

[illegible]


1.04 Cylinder block



1.04 Cylinder block

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	4556018AB	油道堵塞(装)	Plug	2		
2	5066416AF	气缸体和基板	Cylinder block and baseplate	1		
3	6035743	水套堵塞(装)	Plug	1		
4	6034804	工艺堵头(装)	Plug	2		
5	6505763AA	应为气缸体和基板连接螺栓 (M8X1.25X85)	Bolt, connecting signal panel and crankshaft	7		√
6	6100945	曲轴主轴承螺栓	Bolt, crankshaft main bearing	10		√
7	4694106	气缸体与基板定位销	Pin	3		√
8	4693156AA	挡板(铸造型芯孔)	Baffle	1		
9	6506567AA	螺栓组合件	Bolt	2		


1.05 Crankshaft and piston rod



1.05 Crankshaft and piston rod

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	04777689AA	1, 2, 4, 5#曲轴主轴瓦(上)	1,2,4,5# crankshaft main bearing(upper)	4		√
2	5015906AB	3#曲轴主轴瓦(推力轴承)	3# crankshaft main bearing	1set	thrust bearing	√
3	PBS0519PC	活塞, 活塞销和连杆组件	Piston, pin and rod	4		√
4	5019834AA	活塞环组件	Piston rings group	4		√
5	5015910AA	连杆轴瓦	Rod Bearing	4sets		√
6	4777864AF	曲轴	Crankshaft	1		
7	4777685AC	曲轴位置信号盘	Crankshaft position signal panel	1		
8	6505673AA	螺钉	Bolt	3		
9	04777687AA	1, 2, 4, 5#曲轴主轴瓦(下)	1,2,4,5# crankshaft main bearing(lower)	4		
10	5015902AA	1, 2, 4, 5#曲轴主轴瓦包	1,2,4,5# crankshaft main bearing packing	4sets		√
11	4667198	曲轴前油封	CRANKSHAFT REAR SEAL	1		√


1.06 Timing agency and front cover



1.06 Timing agency and front cover

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	4693110AB	张紧器塞(带铜垫片)	Tensioner plug	1		√
2	4693261AB	张紧器	Tensioner	1		√
3	6505690AA	前盖螺栓	Front cover bolt	1		√
4	04777680AA	前盖密封圈组	Front cover seals	1		√
5	6505825AA	正时链导板螺栓	Bolt, timing chain guide	2		
6	4777710AB	正时链导板(压紧张紧轮)	Timing chain guide	1	compress tensioner wheel	√
7	4777699AA	正时链条	Timing chain	1		√
8	6506197AA	凸轮轴正时链轮连接螺栓	Bolt, timing chain wheel	1		√
9	4777736AA	凸轮轴正时链轮	Timing chain wheel	1		√
10	4777707AA	正时链导板	Timing chain guide	1		√
11	6505758AA	正时链导板销	Pin, Timing chain	1		
12	4777694AA	曲轴链轮	Crankshaft chain wheel	1		√
13	L1021100A1	正时机构总成	Timing gear assy.	1		
14	04777836AC	前盖总成	Front cover assy.	1		
15	6506620AA	前盖螺栓	Front cover bolt	1		√
16	GB9074.14--88(M6*1 6-10.9)	螺栓组合件	Bolt	8		
17	6506062AA	前盖螺栓	Front cover bolt	1		√

1.07 Lubrication system




1.07 Lubrication system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	4693140AA	机滤盖	Oil filter cap	1		√
2	L1017102A1	机滤盖O型圈	Oil filter cap seal	1		
3	L1017200A1	机油滤清器滤芯	Oil filter element	1		√
4	4777667AB	机滤座	Oil filter base	1		√
5	6101611	螺栓组合件	Bolt	3		
6	04704670AB	机油压力传感器	Oil pressure sensor	1		
7	L1017101A1	机滤座垫片	Oil filter base washer	1		
8	6506196AA	曲轴链轮定位销	Pin, crankshaft chain wheel	1		
9	04693104AA	机油泵密封圈(进)	Oil pump seal (in)	1		√
10	L1005210A1	机油泵泵体	Oil pump block	1		
11	4693103AA (TBD)	机油泵壳体	Oil pump shell	1		
12	04693164AA	机油泵密封圈(出)	Oil pump seal (out)	1		√
13	5066741AA	机油泵转子	Oil pump rotor	1		
14	GB9074.14--88 M5X6-10.9	螺栓组合件	Bolt	10		
15	4777836AC	前盖机油泵组件	Oil pump component, front cover	1		√
16	4693105AA	机油压力泄压阀塞	Oil pressure relief valve	1		
17	6505955AA	机油泵体定位销	Pin, oil pump	1		
18	4693108AA	机油泄压阀弹簧	Spring, oil pressure relief valve	1		

1.07 Lubrication system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
19	4693107AA	机油0型密封圈	O seal	1		
20	4693106AB	机油压力泄压阀盖	Oil pressure relief valve cap	1		
21	4693188AA	机油压力泄压保护环	Guard ring, oil pressure relief valve	1		
22	4693165AA	机油集滤器组件	Oil strainer	1		√
23	6101010	螺栓	Bolt	2		
24	6506403AA	螺栓组件	Bolt	11		√
25	04777835AA	油底壳垫片	Oil Pan gasket	1		√
26	L1009104A1	放油螺塞组件(含铜垫圈)	Oil plug	1	with washer	√
27	4777833AD	油底壳	Oil Pan	1		
28	6506402AA	螺栓组件	Bolt	1		√
29	6506401AA	螺栓组件	Bolt	1		√
30	GB/T5789-86(M10X10-10.9)	螺栓	Bolt	1		
31	04621939AB	曲轴后油封	Crankshaft rear seal	1		√
32	L1009221A1	机油尺套管	Oil level gauge guide	1		√
33	L1009211A1	机油尺	Oil level gauge	1		√


1.08 Intake manifold



1.08 Intake manifold

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	6506462AA	螺栓	Bolt	5		
2	04777845AE	进气歧管	Intake manifold	1		√
3	04777847AB	进气歧管垫片	Intake manifold washer	4		
4	L3612221A1	MAP传感器连接螺栓	Bolt, MAP sensor	2		
5	04693125AA	绝对压力传感器 (MAP)	MAP sensor	1		√
6	L3765100A1	电子节气门	E-Throttle assy.	1		
7	Q150B0650F9	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	4		
8	L1132110B1	节气门体总成	Throttle assy	1		√
9	L1132102A1	节气门垫片	Throttle gasket	1		√
10	Q150B0640F9	节气门螺栓	Throttle bolt	4		
11	Q2360412	十字盘头螺钉, 弹性垫圈和平垫圈组合件	Philips screw with spring washer and flat washer	4		
12	L1132101A1	怠速控制阀	Idle controller	1		
13	L3612240B1	节气门位置传感器	Throttle position sensor	1		
14	L1104017A1	压力调节器连接管	Pipe, pressure adjustor	1		


1.09 Exhaust Manifold



1.09 Exhaust Manifold

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	6506461AA	螺栓	Bolt	5		
2	4693051AB	排气歧管上罩	Exhaust manifold upper cover	1		
3	GB/T13589-94(M8-10.9)	螺杆	Thru-stud	1		
4	GB/T6177.1-2000(M8-10.9)	螺母	Nut	1		
5	4693052AA	排气歧管下罩	Exhaust manifold lower cover	1		
6	6503131	螺栓	Bolt	8		
7	4693133AD	排气歧管组件	Exhaust manifold component	1		
8	GB/T5783-2000(M8*45-10.9)	螺栓	Bolt	4		
9	04777852AB	排气歧管垫片	Exhaust manifold gasket	1		√


1.10 Thermostat



1.10 Thermostat

[illegible]


1.11 Pulley system



1.11 Pulley system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	L1025100A1	张紧轮	Tensioner assy	1		√
2	Q1840635F9	张紧轮螺栓	Tensioner bolt	3		
3	4777681AB	曲轴皮带轮	Crankshaft Pulley	1		√
4	6506442AA	曲轴皮带轮固定螺栓	Bolt, crankshaft Pulley	1		√
5	L1025200A1	惰轮(带固定螺栓)	Idle gear	1	with bolt	√
6	L1025210A1	惰轮固定螺栓	Idle gear bolt	1		
7	L3407210A1	动力转向泵皮带轮	Pulley, power steering pump	1		√
8	L1025400B1	传动皮带	Belt	1		√


1.12 Ignition device



1.12 Ignition device

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	05033216AC	1#高压线	Ignition cable 1	1	1,2,3,4must be ordered in suite	√
1	05033217AC	2#高压线	Ignition cable 2	1	1,2,3,4must be ordered in suite	√
1	05033218AC	3#高压线	Ignition cable 3	1	1,2,3,4must be ordered in suite	√
1	05033219AC	4#高压线	Ignition cable 4	1	1,2,3,4must be ordered in suite	√
2	04777800AC	火花塞套管油封	Seal, spark pulg guild pipe	4		√
3	5033076AB	火花塞	Spark Pluge	4		√
4	6507047AA	点火线圈螺栓组件	Ignition Coil bolt	4		√
5	5269670AB	点火线圈	Ignition Coil	1		√
6	04693243AA	点火线圈隔热垫	Heat insulator, Ignition Coil	8		√


1.13 Fuel distributor



1.13 Fuel distributor

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	4897125AA	0型圈	O seal	4		√
2	4891190	喷油器	Nozzle	4		
3	4418257AB	夹箍	Clamp	4		√
4	6401452	螺栓组合件	Bolt	2		
5	4418257AB	夹箍	Clamp	1		√
6	4891336AA	燃油调节器	Fuel adjustor	1		
7	4897125AA	0型圈	Pressure adjustor seal	1		√
8	4891338AA	油轨总成	Fuel Distributor	1		√
9	4891549AA	夹箍	Hoop	1		


1.14 Water pump



1.14 Water pump

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	GB/T70.1-2000(M8*9 0-10.9)	螺钉	Bolt	3		
1	GB/T70.1-2000(M8*4 5-10.9)	螺钉	Bolt	1		
2	04693097AA	进水管接头密封圈	Inlet tube joint seal	1		√
3	4777876AB	进水管接头	Inlet tube joint	1		
4	GB9074.14-88(M6*16-10.9)	螺栓组合件	Bolt	2		
5	4693169AA	进水管夹箍	Inlet tube hoop	1		
6	4693112AB	进水软管	Inlet hose	1		
7	4693168AB	进水管夹箍	Inlet hoop	1		
8	4693092AA	水泵盖	Water Pump Cover	1		
9	GB2673-86(M6*1 0-10.9)	螺钉	Bolt	7		


1.15 Auxiliary devices



1.15 Auxiliary devices

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	Q1411265TF9	起动电机螺栓	Startor bolt	2		
2	L3708100	起动电机总成	Startor assy.	1		√
3	L3701100B1	发电机总成	Generator assy.	1		√
4	L3701121A1	发电机调节器	Generator adjustor	1		
5	L3701110A1	发电机皮带盘	Generator pulley wheel	1		
6	Q18408100F9	发电机螺栓	Generator bolt	1		
7	Q1840895F9	发电机螺栓	Generator bolt	2		
	L1002118A1	变速器挡板	Transmission fender	1		√
	Q1410616F9	变速器挡板螺栓	Transmission fender bolt	2		


1.16 Clutch



1.16 Clutch

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	L1005320A1	飞轮齿圈总成	Flywheel rim	1		
2	L1005300A1	飞轮总成	Flywheel	8		√
3	L1005301A1	飞轮螺栓	Flywheel bolt	1	M10×1×22	√
4	L1601200A1	离合器从动盘总成	Clutch Driven Plate	1		√
5	Q1840816F9	离合器螺栓	Clutch bolt	6		
6	L1601100A1	离合器压盘	Clutch press plate	1		√
7	L1602202A1	分离轴承	Throwout bearing	1		√
8	L1602206A1	分离拨叉-防尘罩	Dustproof cover	1		
9	L1602201A1	分离拨叉	Throwout fork	1		
10	L1602203A1	锁片—分离拨叉	Locker	1		
11	L1602205A1	防尘套—分离拨叉	Dustproof cap	1		
12	L1701115A1	分离拨叉支座	Throwout fork base	1		
	L1601000A1	离合器	Clutch	1		


1.17 EFI system



1.17 EFI system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3612100B2	ECU	ECU	1	Sun&teck	√
2	L8204101A1	内六角花型大盘头螺钉	Inner hex screw	4		
3	L4001000C1	发动机线束	Engine harness	1	Sun&teck	√
4	05269870AB	水温传感器	Water Temperature Sensor	1		√
6	05293161AA	凸轮轴位置传感器	Camshaft Position Sensor	1		√
7	6501957	螺栓组合件	Bolt	1	M6X16-10.9	
8	04606093AC	爆震传感器	Knock Sensor	1		√
10	L3612320B1	曲轴位置传感器	Crankshaft Position Sensor	1	Sun&teck	√
	6501957	螺栓组合件	Bolt	1		√
	L4001000C8	B端子线	B end harness	1		√
	L1130301B1	碳罐控制阀	Canister Control Valve	1	Sun&teck	√
	L3612260B1	氧传感器	Oxygen Sensor	2	Sun&teck	√


1.18 Clutch shell



1.18 Clutch shell

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	L1701109A1	定位销	Pin	2		√
2	L1701102A1	输入轴前轴承	Input shaft front bearing	1		√
3	Q1410845	螺钉	Bolt	14		
4	L1701212A1	各档叉轴衬套	Forkshaft sleeve	6		√
5	L1701213A1	换、选档轴衬套	Gear shift and choose shaft sleeve	2		√
6	L1701106A1	输出轴前轴承(外圈)	Out ring, Input shaft front bearing	1		√
7	L1701107A1	输出轴前轴承(保持架组件)	Retainer, Input shaft front bearing	1		√
8	L1701104A1	输出轴前轴承压板	Pressure plate, nput shaft front bearing	1		√
9	Q150B0612	输出轴前轴承压板固定螺栓	Hex bolt	2		
10	L1701134A1	双头螺栓	Thru-stud	1		√
11	L1701103A1	换档钢球定位装置	Steel ball locating device	1		√
12	L1701138A1	磁铁	Magnet	1		√
13	L1701114A1	放油螺栓	Oil plug	1		√
14	L1701204A1	差速器前、后油封	Differential seal	2	front, rear	√
15	L1701101A1	离合器壳体	Clutch shell	1		√

1.19 Transmission shell




1.19 Transmission shell

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	Q5270624	螺旋弹性销	Pin	2		√
2	L1701218A1	换档轴衬套	Gear shift shaft sleeve	1		√
3	L1702310A1	换档摇臂组件	Shift swing arm element	1		√
4	L1702100A1	选、换档机构	Gear shift and choose system	1		√
5	L1702220A1	选档摇臂组件	Choose swing arm element	1		√
6	L1701219A1	选档轴衬套	Gear choose shaft sleeve	1		√
7	Q43115	选档轴卡环(轴用弹性挡圈)	Spring circlip for shaft	1		√
8	Q5220624	选档固定销	Pin	1		√
9	L1701201A1	变速器壳体	Transmission shell	1		√
10	L1701214A1	导油管	Oil guide tube	1		√
11	L2303215B1	车速传感器从动齿轮	Speedometer driven gear	1		√
12	L3612250	里程表传感器	Speedometer sensor	1		√
13	Q1410620F9	曲轴位置传感器螺栓	Bolt, crankshaft position sensor	1		√
14	L1701163A1	垫片—限油、放油螺塞（铜）	Washer	1	copper	√
15	L1701162A1	限油螺塞	Oil limited plug	1		√
16	L1701204A1	差速器前、后油封	Differential seal	2	front, rear	√
17	L1701202A1	输入输出轴后轴承	Input and output shaft rear bearing	2		√
18	L1701208A1	换、选档轴油封	Gear shift and choose shaft seal	2		√

1.19 Transmission shell

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
19	L1701132A1	输入输出轴卡环	Circlip, Input and output shaft	2		√
20	Q1410820F9	热回管螺栓	Bolt	10		√
21	L1701110A1	后盖总成	Rear cover	1		√
22	L1701213A1	换、选档轴衬套	Gear shift and choose shaft sleeve	1		√
23	L1701212A1	各档叉轴衬套	Forkshaft sleeve	3		√
24	L1701120A1	倒档灯开关总成	Reverse light switch	1		√
25	Q9000B	通气阀总成	Vent valve	1		√
26	L1702300A1	换档轴总成	Gear shift shaft assy.	1		√

1.20 Input shaft




1.20 Input shaft

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	L1701311A1	输入轴	Input shaft	1		√
2	L1701313A1	导油板堵盖	Oil guide plug	1		√
3	L1701364A1	三、四、五档滚针轴承	Needle bearing	3		√
4	L1701330A1	三档主动齿轮总成	Third drive gear assy.	1		√
5	L1701362A1	齿轮毂3-4档	Third、forth gear hub	1		
6	L1701366A1	滑块1-5档	Slider	6		
7	L1701443A1	钢球1-5档	Steel ball	6		
8	L1701368A1	弹簧1-5档	Spring	6		
9	L1701361A1	同步套3-4档	Third、forth gear synchronize sleeve	1		
10	L1701365A1	三、四档同步环	Third、forth gear synchronize rim	2		√
11	L1701363A1	三、四、五档齿毂卡环	Third、forth、fifth gear hub circlip	2		√
12	L1701340A1	四档主动齿轮总成	Forth drive gear assy.	1		√
13	L1701382A1	半挡环	Semi-circlip	1	5	√
14	L1701381A1	挡环	Circlip	1		√
15	Q523048	止动销	Pin	1		√
16	L1701350A1	五档主动齿轮总成	Fifth drive gear assy.	1		√
17	L1701367A1	五档同步环	Fifth gear synchronize rim	1		√
18	L1701472A1	齿轮毂5档	Fifth gear hub	1		

1.20 Input shaft

[illegible]


1.21 Output shaft



1.21 Output shaft

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	L1701446A1	同步外环-一二档同步器	First、second gear synchronize outer rim	2		√
2	L1701447A1	同步锥环-一、二档同步器	First、second gear synchronize taper rim	2		√
3	L1701448A1	同步内环-一、二档同步器	First、second gear synchronize inner rim	2		√
4	L1701420A1	一档从动齿轮总成	First driven gear assy.	1		√
5	L1701459A1	一、二档滚针轴承	Needle bearing	2		√
6	L1701411A1	输出轴	Output shaft	1		√
7	L1701313A1	导油板堵盖	Oil guide plug	2		√
8	L1701453A1	五档从齿卡环	Fifth driven gear circlip	1		√
9	L1701452A1	五档从动齿轮	Fifth driven gear assy.	1		√
10	L1701451A1	三、四档双联齿轮	Third、forth duplicate gear	1		√
11	L1701430A1	二档从动齿轮总成	Second driven gear assy.	1		√
12	L1701441A1	同步套1-2档	First、second gear synchronize sleeve	1		
13	L1701456A1	一、二档齿毂卡环	First、second gear hub circlip	1		√
14	L1701443A1	钢球1-2档	Steel ball	3		
15	L1701444A1	弹簧1-2档	Spring	3		
16	L1701445A1	滑块1-2档	Slider	3		
17	L1701442A1	齿轮毂1-2档	First、second gear hub	1		


1.22 Gearshift system



1.22 Gearshift system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	L1702620A1	五档拨叉总成	Fifth gear fork	1		√
2	L1702610A1	三、四档拨叉总成	Third、forth gear fork	1		√
3	L1702606A1	三、四档导块	Third、forth gear guide	1		√
4	L1702604A1	五、倒档导块	Fifth、reverse gear guide	1		√
5	L1702603A1	三档限位衬套	Third stopper sleeve	1		√
6	Q436120	卡环—倒档拨销	Circlip	1		√
7	L1702602A1	五、倒档叉轴	Fifth、reverse gear forkshaft	1		√
8	L1702601A1	三、四档叉轴	Third、forth gear forkshaft	1		√
9	L1702200A1	选档机构总成	Gear selector assy.	1		√
10	L1702501A1	一、二档叉轴	First、second gear forkshaft	1		√
11	Q5270524	螺旋弹性销	Pin	6		√
12	L1702510A1	一、二档拨叉总成	First、second gear fork	1		√


1.23 Reverse counter shaft



1.23 Reverse counter shaft

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	L1701610A1	倒档惰轮总成	Reverse idle gear	1		√
2	L1701616A1	倒档惰轮垫圈	Reverse idle gear washer	1		√
3	L1701614A1	倒档惰轮轴锁紧螺钉	Reverse idle gear bolt	1		√
4	L1701613A1	倒档惰轮轴	Reverse idle gear shaft	1		√
5	L1702700A1	倒档摇臂机构组件	Reverse swing arm element	1		√
6	Q150B0616	倒档锁止装置固定螺栓	Hex bolt	2		√
7	L1702400A1	倒档锁止装置	Reverse stopper	1		√


1.24 Differential



1.24 Differential

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	L2303202A1	主减速从动齿轮	Deceleration driven gear	1		√
2	L2303203A1	差速器前、后锥轴承	Differential tapered bearing	2		√
3	L2303201A1	差速器壳	Differential shell	1		√
4	L2303213A1	主减速从动齿轮连接螺栓	Bolt	12		√
5	Q5240535	行星轴定位销	Pin	1		√
6	L2303222A1	里程表主动齿轮	Speedometer drive gear	1		√
7	L2303209A1	行星齿轮垫片	washer,planet gear	2		√
8	L2303208A1	行星齿轮	planet gear	2		√
9	L2303211A1	行星齿轮轴	planet gear shaft	1		√
10	L2303206A1	半轴齿轮	Differential axle gear	2		√
11	L2303207A1	半轴齿轮垫片	Differential axle gear washer	2		√
12	L2303216A1	差速器轴承调整垫片	Differential bearing shim	1		√

2.01 Engine suspension (for Tritec engine)




2.01 Engine suspension (for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	231-1025TF30	六角法兰面螺栓	Hex flange bolt	7		√
2	101B-1010T13F3	六角法兰面螺母	Hex flange nut	1		√
3	B1001330	左悬置安装支座组件	Left suspension seat	1		√
4	B1001320	连接支架焊接总成	Connecting bracket	1		√
5	231-1035TF3	六角法兰面螺栓	Hex flange bolt	4		√
6	L1001310	发动机左悬置组件	Left suspension component	1		√
7	231-1016TF3	六角法兰面螺栓	Hex flange bolt	2		√
8	231-1290TF30	六角法兰面螺栓	Hex flange bolt	1		√
9	B1001130	辅助悬置安装支架组件	Suspension set bracket	1		√
10	L1001120	发动机辅助悬置组件	Engine suspension component	1		√
11	B1001110	辅助悬置连接支架组件	Suspension bracket bracket	1		√
12	231-1280TF30	六角法兰面螺栓	Hex flange bolt	4		√
13	B1001420	发动机右悬置组件	Right suspension component	1		
14	101B-1212T13F3	六角法兰面螺母	Hex flange bolt	3		√
15	231-1260TF30	六角法兰面螺栓	Hex flange bolt	3		√
16	L1001410	发动机右悬置及支架总成	Engine right suspension assy.	1		√
17	L1001201	后悬置支架	Rear suspension bracket	1		√
18	231-1275TF3	六角法兰面螺栓	Hex flange bolt	2		√

2.01 Engine suspension (for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
19	L1001210	后悬置支架带组件	Rear suspension bracket component	1		√
20	231-1035TF3	六角法兰面螺栓	Hex flange bolt	4		√
21	231-1045TF3	六角法兰面螺栓	Hex flange bolt	2		√

2.02 Front suspension(for Tritec engine)




2.02 Front suspension(for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	Q32008	六角法兰面螺母	Hex flange nut	6		√
2	B2905011	前减震器上压板	Front shock absorber press plate	2		√
3	231-1560TF3	六角法兰面螺栓	Hex flange bolt	4		√
4	101-1514T13F3	六角法兰面螺母	Hex flange nut	4		√
5	101B-1212T13F3	六角法兰面螺母	Hex flange nut	4	M12*1.25	√
6	B2906200	前横向稳定杆连杆总成	Front stabilizer bar con-rod	2		√
7	231-1490TF3	六角法兰面螺栓	Hex flange bolt	6		√
8	B2901100	副车架总成	Sub-frame assy.	1		√
9	124-1417T13F3	六角法兰面开槽螺母	Hex flange nut	2		√
10	Q5003230	开口销	Cotter pin	2		√
11	B2904100	左前下摆臂总成	Front left swing arm	1		√
11-1	B2904810	球销组件	Ball joint	1		√
11-2	Q32012	六角法兰面螺母	Hex flange bolt	2	only available with assembled parts	√
11-3	Q1841216	六角法兰面螺栓	Hex flange bolt	1	only available with assembled parts	√
12	231-1490TF3	六角法兰面螺栓	Hex flange bolt	2		√
13	B2910123	副车架胶塞	Sub-frame plug	2		√
14	B2906012	前横向稳定杆橡胶安装座	Front stabilizer bar rubber seat	2		√
15	B2906011	前横向稳定杆抱箍	Front stabilizer bar hoop	2		√

2.02 Front suspension(for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
16	Q1410825L	六角头螺栓带锥形垫圈组合件	Hex bolt and taper springness washer	4		√
17	101-1414T13F3	六角法兰面螺母	Hex flange bolt	2		√
18	B2906100	前横向稳定杆总成	Front stabilizer bar assy.	1		√
19	B2904200	右前下摆臂总成	Front right swing arm	1		√
19-1	B2904810	球销组件	Ball joint	1		√
19-2	Q32012	六角法兰面螺母	Hex flange nut	2	only available with assembled parts	√
19-3	Q1841216	六角法兰面螺栓	Hex flange bolt	1	only available with assembled parts	√


2.03 Front shock absorber



2.03 Front shock absorber

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B2905100	左前减振器总成	Front left shock absorber assy.	1		✓
1	B2905200	右前减振器总成	Front right shock absorber assy.	1		✓
1-1	B2905120	左前减振器阻尼器总成	Front left shock absorber damper	1		✓
1-1	B2905220	右前减振器阻尼器总成	Front right shock absorber damper	1		✓
1-2	B2905182	弹簧下座	Spring lower seat	2		✓
1-3	B2905181	前螺旋弹簧	Front coil spring	2		✓
1-4	B2905183	限位块	Stopper	2		✓
1-5	B2905184	防尘罩	Boot	2		✓
1-6	B2905185	弹簧上座	Spring upper seat	2		✓
1-7	B2905170	上连接盖板组件	Upper plate	2		✓
1-8	B2905186	锁紧螺母盖板	Nut plate	2		✓
1-9		六角法兰面螺母	Hex flange nut	2	only available with assembled parts	


2.04 Rear suspension



2.04 Rear suspension

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	Q32008T13F3	六角法兰面螺母	Hex flange nut	4		✓
2	231-1025TF3	六角法兰面螺栓	Hex flange bolt	2		✓
3	Q40214	大垫圈	Big washer	2		✓
4	101-1414T13F3	六角法兰面螺母	Hex flange nut	2		✓
5	101B-1212T13F3	六角法兰面螺母	Hex flange nut	2		✓
6	231-12130TF3	六角法兰面螺栓	Hex flange bolt	2		✓
7	231B-1027TF3	六角法兰面螺栓	Hex flange bolt	8		✓
8	B2911100	后桥总成	Rear axle assy.	1		✓
8-1	B2916110	后桥焊接组件及安装套	Rear axle	2		
8-2	231B-1275TF3	六角法兰面螺栓	Hex flange bolt	2	only available with assembled parts	✓
8-3	B2916140	后横向稳定杆总成	Rear stabilizer bar assy.	1		✓
8-4	101B-1212T13F3	六角法兰面螺母	Hex flange nut	2	only available with assembled parts	✓


2.05 Rear shock absorber



2.05 Rear shock absorber

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B2915100	左后减振器总成	Rear left shock absorber assy.	1		✓
1	B2915200	右后减振器总成	Rear right shock absorber assy.	1		✓
1-1	B2915120	后减振阻尼器总成	Rear shock absorber damper	2		✓
1-2	B2915182	防尘罩及限位块	Stop boot	2		✓
1-3	B2915181	后螺旋弹簧	Rear coil spring	2		✓
1-4	B2915183	限位盖	Stop plate	2		✓
1-5	B2915184	减振垫	Damper cushion	2		✓
1-6	B2915185	弹簧上橡胶垫	Spring upper rubber cushion	2		✓
1-7	B2915170	左后上连接板组件	Left connect plate	1		✓
1-7	B2915270	右后上连接板组件	Right connect plate	1		✓
1-8	B2915186	缓冲定位套	Positioning sleeve	2		✓
1-9	B2915187	缓冲块	Damper block	2		✓
1-10	B2915188	缓冲限位座	Damper seat	2		✓
1-11		六角法兰面螺母	Hex flange nut	2	only available with assembled parts	

2.06 Fuel supply(for Tritec engine)




2.06 Fuel supply(for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B1104030	燃油硬管/喷油嘴连接软管组件	Hose connecting fuel tube and nozzle	1		√
2	Q67512	A型蜗杆转动式软管环箍	Hoop	7		√
3	B1130153	燃油蒸汽控制阀/节气门连接软管	Hose connecting fuel valve and throttle	1		√
4	B1130300	燃油蒸汽控制阀总成	Fuel valve	1		
5	B1130152	碳罐/燃油蒸汽控制阀连接软管	Hose connecting canister and control vavle	1		√
6	B1130451	燃油蒸汽控制阀支架	Fuel valve bracket	1		√
7	B1130200	碳罐总成	Can Canister	1		√
8	B1130151	碳罐/回油硬管连接软管	Hose connecting canister and reflux tube	1		√
9	B1108310	油门拉索组件	Throttle cable	1		√
10	Q1400630	六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer	4		√
11	B1108100	油门踏板总成	Accelerator pedal assy.	1		√
12	B1104020	燃油硬管组件	Fuel tube	1		√
13	B1130110	油箱至碳罐连接硬管组件	Tube connecting fuel tank and canister	1		√
14	B1104251	燃油管路三管夹	Clamp	1		√
15	B1130120	油箱至碳罐连接软管组件	Hose connecting fuel tank and canister	1		√
16	B1117020	油箱回油管/燃油硬管连接组件	Fuel tank reflux pipe and fuel tube connecting component	1		√
17	B1117010	油箱/滤清器出油软管组件	Fuel filter hose	1		√
18	L1117100	汽油滤清器总成	Fuel filter	1		√

2.06 Fuel supply(for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
19	Q67516	A型蜗杆转动式软管软管	Hoop	2		√
20	Q1410616L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	2		√
21	B1132200	谐振腔总成	Cavity resonator	1		√
22	Q32006	六角法兰面螺母	Hex flange bolt	2		√


2.07 Air filter(for Tritec engine)



2.07 Air filter(for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	L8212012	子母扣	Inlay button	1		√
2	Q1410616	六角法兰面螺栓和锥形弹性垫圈组合件	Hex bolt, taper springness washer and flat washer	1		√
3	B1109210B1	空滤器进气管总成	Air filter intake pipe	1		√
4	B1109100	空气滤清器总成	Air filter assy.	1		√
4-1	B1109110	空滤器上盖组件	Air filter upper shell	1		
4-2	B1109103	空滤器滤芯组件	Air filter element	1		
4-3	B1109241	弹簧卡夹	Spring clamp	2		
4-4	B1109120	空滤器下盖组件	Air filter lower shell	1		
5	Q1410632L	六角法兰面螺栓和锥形弹性垫圈组合件	Hex bolt, taper springness washer and flat washer	3		√
6	B1109220	发动机进气软管总成	Engine section pipe	1		√
6-1	Q67670	B型蜗杆传动式环箍	Hoop	1		
6-2	Q673B12	弹性钢带环箍	Steel spring hoop	1		√
6-3	B1109670	曲轴箱通风管组件	Crankcase vent hose	1		
6-4	Q67680	B型蜗杆传动式环箍	Hoop	1		
6-5	B1109221	发动机进气软管	Engine section pipe	1		

2.08 Fuel tank




2.08 Fuel tank

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B1101100	燃油箱总成	Fuel tank assy.	1		√
2	B1101200	加注管总成	Fuel filler tube assy.	1		√
2-1	B1101251	加油软管护套	Hose sleeve	1		
2-2	Q676B45	B型蜗杆传动式环箍	Hoop	2		√
2-3	B1101260	加油软管	Fuel filler hose	1		
2-4	B1101220	加油及出气硬管	Reurn tube	1		
2-5	B1101210	加油口盖组件	Fuel filler cap	1		
2-6	B1101285	加油口护罩上卡簧	Fuel filler cover lower circlip	1		
2-7	B1101281	加油口护罩	Fuel filler cover	1		
2-8	B1101286	加油口护罩下卡簧	Fuel filler cover upper circlip	1		
2-9	Q67625	B型蜗杆传动式环箍	Hoop	2		
2-10	B1101253	出气软管	Vent hose	1		
3	B1101254	加油管回气硬管卡座 I	Reurn tube clamp I	1		
4	B1101255	加油回气硬管卡座 II	Reurn tube clamp II	1		
5	B1101010	燃油左固定带组件	Fuel tank left fixation	1		√
6	Q1401030	六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer	4		√
7	B1101020	燃油箱右固定带组件	Fuel tank right fixation	1		√
8	B1123100	电子燃油泵总成	Fuel pump assy.	1		√

2.08 Fuel tank

[illegible]

2.09 Steering system(for Tritec engine)



2.09 Steering system(for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3404310	转向管柱防尘套组件	Dustproof, steering tube	1		
2	B3412410	转向机上隔音罩卡圈	Noise insulator circlip, steering gear	1		√
3	B3412511	转向机上隔音罩	Noise insulator, steering gear	1		√
4	231B-1256TF3	六角法兰面螺栓	Hex flange bolt	2		√
5	125-1215	六角开槽薄螺母	Hex nut	2		√
6	Q5002528	开口销	Cotter pin	2		√
7	B3406340	转向器油管固定支架B组件	Pipe bracket B	1		√
8	Q1410616	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	1		√
9	231-1225TF3	六角法兰面螺栓	Steering reflux pipe I	2		√
10	B3406300	转向器回油管总成	Steering reflux pipe assy.	1		√
10-1	B3406310	转向器回油管组件 I	Steering reflux pipe I	1		
10-2	Q67512	A型蜗杆传动式软管环箍	Hoop	5		√
10-3	B3406321	转向器回油管 II	Steering reflux pipe II	1		
10-4	B3406711	油管护套	Pipe sleeve	1		
10-5	B3406330	转向器回油管组件III	Steering reflux pipe III	1		
10-6	Q67520	A型蜗杆传动式软管环箍	Hoop	1		√
10-7	B3406341	转向器回油管IV	Steering reflux pipe IV	1		√
10-8	B3406820	转向器油管支架组件 II	Steering reflux pipe bracket II	1		


2.09 Steering system(for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
10-9	B3406350	转向器回油管组件 V	Steering reflux pipe V	1		
10-10	B3406361	转向器回油管 VI	Steering reflux pipe VI	1		
10-11	B3406810	转向器油管支架组件 I	Steering reflux pipe bracket I	1		
11	B3406200	转向器进油管总成	Steering intake pipe assy.	1		√
11-1	B3406210	转向器进油管组件	Steering pump intake pipe	1		
11-2	507-1602	平垫圈	Flat washer	2		
11-3	221-1630	轴向径向螺栓	Bolt	1		
11-4	Q15B1025	六角头螺栓	Steering pump intake pipe assy.	1		
11-5	Q40310	弹簧垫圈	Springness washer	1		√
11-6	Q40110	平垫圈	Flat washer	1		
12	B3406100	转向油泵进油管总成	Steering pump intake pipe assy.	1		√
12-1	Q67529	A型蜗杆传动式软管环箍	Hoop	2		
12-2	B3406151	转向油泵进油管卡箍	Hoop,steering pump intake pipe	1		
12-3	B3406111	转向油泵进油管	Steering pump intake pipe	1		
13	B3408100	动力转向油壶总成	Power steering reservior assy.	1		√
14	B3408010	动力转向油壶支架组件	Power steering reservior bracket assy.	1		√
14-1	B3408011	动力转向油壶支架	Power steering reservior bracket	1		
14-2	B3408012	动力转向油壶卡片	Power steering reservior clip	1		

2.09 Steering system(for Tritec engine)

[illegible]


2.10 Power steering gear



2.10 Power steering gear

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3401100	转向器和转向拉杆总成	Steering gear assy.	1		✓
1-1	B3401200	右横向拉杆总成	Steering right rod	1		✓
1-2	Q351B14	六角薄螺母	Hex nut	2	only available with assembled parts	
1-3	B3401812	卡箍	Hoop	2		✓
1-4	B3401811	防尘罩	Dust shield	2		✓
1-5	B3401713	抱箍	Hoop	2		✓
1-6	B3401510	左缸油管组件	Left oil pipe	1		✓
1-7	B3401520	右缸油管组件	Right oil pipe	1		✓
1-8	B3401600	左横向拉杆总成	Steering left rod	1		✓
2	B3404200	下转向轴总成	Lower steering shaft assy.	1		✓
3	B3404100	上转向轴总成	Upper steering shaft assy.	1		✓
4	Q1460830	六角头螺栓和弹簧垫圈组合件	Hex bolt and washer	2		✓
5	101B-1212T13F3	六角法兰面螺母	Hex flange nut	1		✓
6	Q1840855	六角法兰面螺栓	Hex flange bolt	1		✓
7	Q1840816	六角法兰面螺栓	Hex flange bolt	2		✓


2.11 Shift system(for Tritec engine)



2.11 Shift system(for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	L1703016	变速拉索接头固定卡	Shift cable joint clip	2		
2	L1703017	E型卡	E clip	2		√
3	Q1840625	六角法兰面螺栓	Hex flange bolt	2		√
4	B1703200	选换档软轴总成	Gearshift cable	1		√
5	B1703019	软轴固定支架	Cable bracket	1		√
6	Q1410825L	六角头螺栓带锥形垫圈组合件	Hex bolt and taper springness washer	4		√
7	B1703150	换档手柄球头组件	Gearlever handle	1		√
7	B1703150B1	换档手柄球头组件	Gearlever handle	1	EX	√
8	B1703100	换档支座组件	Gear shift seat	1		√
9	L1703015	软轴支架	Cable bracket	1		√
10	Q1410820TF3	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	3		
11	Q1410620	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	1		√

2.12 Clutch controller system(for Tritec engine)




2.12 Clutch controller system(for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	L1609000	离合器工作缸	Clutch slave cylinder	1		√
2	B1607210	离合主泵出油硬管组件	Outtake tube, clutch master pump	2		√
3	L1600013	卡片	Clip	1		√
4	L1600015	支架	Bracket	1		√
5	231-1016TF3	六角法兰面螺栓	Hex flange bolt	1		√
6	Q1410630	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	2		√
7	Q1410616	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	3		√
8	B1611111	离合软管管夹	Clip	1		√
9	B1607120	离合主泵出油软管组件	Outtake hose, clutch master pump	1		√
10	B1607111	离合主泵进油软管	Intake hose, clutch master pump	1		√
11	Q67512	A型蜗杆传动式软管环箍	Hoop	2		√
12	Q68618	单片管夹	Clamp	1		√
13	221-1018	带孔螺栓	Eye bolt	1	M10×1×18	√
14	L1600014	垫密圈	washer	2		√
15	B1608100	离合器总泵总成	Clutch master pump	1		√
16	Q32008	六角法兰面螺母	Hex flange nut	2		√
17	Q5101022	销轴	Axis pin	1		√
18	Q5003220	开口销	Cotter pin	1		√

2.12 Clutch controller system(for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
19	B1602100	离合踏板总成	Clutch paddle assy.	1		√
19-1	B1602331	助力弹簧	Auxiliary spring	1		
19-2	B1602332	衬套I	Sleeve I	1		
19-3	B1602333	衬套II	Sleeve II	1		
19-4	B1602181	离合器板胶套	Clutch paddle sleeve	1		
20	204-0825TF3	六角螺栓和锥形弹垫组件	Hex bolt and taper springness washer	1		
21	178-0806	B型板簧螺母	“B”spring nut	1		√
22	Q68610	单片管夹	Clamp	1		√


2.13 Transmission shaft (for Tritec engine)



2.13 Transmission shaft (for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	SB22001	差速器侧万向节维修包（左）	Left universal joint kit,transmission side	1		
2	SB22002	差速器侧防护罩维修包	protection cover kit,transmission side	2		
3	SB22003	车轮侧万向节维修包	Universal joint kit,wheel side	2		
4	SB22004	车轮侧防护罩维修包	protection cover kit,wheel side	2		
5	SB22005	差速器侧万向节维修包（右）	Right universal joint kit,transmission side	1		
6	B2203100	左传动轴总成	Left transmission shaft assy.	1		√
7	B2203200	右传动轴总成	Right transmission shaft assy.	1		√
	Q387B22	六角开槽薄螺母	Hex nut	2		√
	L2203014	中间支撑安装支架	Mounting bracket	1		√
	Q1410830	六角头螺栓和弹性垫圈组合件	Bolt with springness washer	3		√
	Q40122	平垫圈	Washer	2		
	Q5005032	开口销	Cotter pin	2		

2.14 Brake system



2.14 Brake system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3506160B1	比例阀-FR(左前硬管)	Front left tube, proportional valve	1		
1	B3506160	ABS-FR(左前硬管)	Front left tube, ABS	1		√
2	B3506210	ABS-RL(左后硬管 I)	Rear left tube I, ABS	1		√
3	B3506140B1	比例阀-MCP(一缸硬管)	Master cylinder tube, proportional valve	1		
3	B3506140	ABS-MCP(一缸硬管)	Master cylinder tube, ABS	1		√
4	B3506110B1	比例阀-FL(左前硬管 I)	Front left tube I, proportional valve	1		
4	B3506110	ABS-FL(左前硬管 I)	Front left tube I, ABS	1		√
5	B3506230	ABS-RR(右后硬管 I)	Rear right tube I, ABS	1		√
6	B3506150B1	比例阀-MCS(二缸硬管)	Sub cylinder tube, proportional valve	1		
6	B3506150	ABS-MCS(二缸硬管)	Sub cylinder tube, ABS	1		√
7	Q1410616	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	10		√
8	B3506320	六管夹组件	Clamp	3	for 6 tube	√
9	B3550100	ABS-机构总成	ABS ECU	1		√
10	Q1410820	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	5		√
11	B3550211	ABS支架总成	ABS bracket	1		√
12	B3506356	三管夹A	Clamp A	1	for 3 tube	√
13	Q5101022	销轴	Axis pin	1		√
14	Q5003220	开口销	Cotter pin	1		√


2.14 Brake system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
15	L3506106	E型卡片	E shape clip	4		√
16	B3506130	前制动软管	Front brake hose	2		√
17	B3506120	ABS-FL(左前硬管Ⅱ)	Front left tube II, ABS	1		√
18	B3506357	三管夹B	Clamp B	1	for 3 tube	√
19	Q1840645	六角法兰面螺栓	Hex flange bolt	2		√
20	B3550411	比例阀阀体	Proportional Valve	1		√
21	B3506310	七管夹组件	Clamp	1	for 7 tube	√
22	136-0813	六角法兰面螺母和弹簧垫圈组合件	Hex bolt and taper springness washer	4		
23	B3506240	比例阀阀体-RR(后-右后硬管Ⅱ)	Rear right tube II, Proportional Valve	1		√
24	B3508300	驻车制动操纵杆总成	Parking brake lever	1		√
24-1	B3508420	驻车制动拉索前段组件	Parking brake cable, fore part	1		√
24-2	B3508411	拉索过孔胶套	Cable sleeve	1		
24-3	B3781110	驻车制动开关	Parking brake switch	2		
25	B3506351	五管夹A	Clamp A	3	for 5 tube	√
26	B3506355	五管夹卡扣	Clamp clip	3		√
27	B3506352	五管夹卡B	Clamp B	1	for 5 tube	√
28	B3506362	制动管路下护板	Brake pipeline fender	1		√
29	B3506220	比例阀阀体-RL(左后硬管Ⅱ)	Rear left tube II, Proportional Valve	1		√

2.14 Brake system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
30	B3506250	后制动软管组件	Rear brake hose	2		√
31	B3506359	单管夹B	Clamp B	2	for 1 tube	√
32	B3506353	五管夹C	Clamp C	1	for 5 tube	√
33	B3506354	五管夹D	Clamp C	1	for 5 tube	√
34	B3506358	单管夹A	Clamp A	4	for 1 tube	√
35	B3508412	前/后拉索支架	Brake cable bracket	1		√
36	B3508413	驻车制动拉索后段固定支架	Parking brake cable bracket, rear part	2		√
37	B3506361	前轮制动管路过孔胶套	Front brake tube sleeve	2		√


2.15 Brake pedal



2.15 Brake pedal

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3504100	制动踏板支架总成	Brake pedal bracket assy.	1		√
1-1	B3781120	制动灯开关	Brake lamp switch	1		√
1-2	Q351C10	六角薄螺母	Hex nut	1		
1-3	B3504110	制动踏板支架组件	Brake paddle bracket	1		
1-4	Q351C10	六角头螺栓	Hex bolt	1		
1-5	B3504361	制动踏板销柱衬管	Liner tube	1		√
1-6	B3504351	制动踏板销柱衬套	Bush	2		√
1-7	101B-1010	法兰盘螺母	Flange nut	1		
1-8	B3506161	制动踏板限位胶垫	Rubber stopper	1		
1-9	B3504200	制动踏板组件	Brake paddle	1		
1-10	B3504141	制动踏板胶垫	Brake paddle rubber sleeve	1		√
2	178-0806	B型板簧螺母	“B”spring nut	1		√
3	204-0825T1F3	六角头螺栓和锥形弹簧垫圈组合件	Hex bolt and taper springness washer	1		√


2.16 Brake pump



2.16 Brake pump

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3540100	真空助力器带制动泵总成	Vacuum booster with pump assy.	1		√
1-1	B3540200	制动总泵带油壶组件	Brake pump with fluid pot	1		
1-1-1	B3540270	制动油壶盖组件	Fluid pot cap	1		√
1-1-2	B3540250	制动油壶组件	Fluid pot	1		√
1-1-3	B3540292	十字头螺钉	Philips screw	1		
1-1-4	B3540291	橡胶密封圈	Seal	2		
1-1-5	B3504210	制动总泵总成	Brake pump	1		√
1-2	Q32008	六角法兰面螺母	Hex flange nut	2		√
1-3	B3540420	左前制动硬管接头组件	Front left brake tube joint	1		
1-4	B3540300	真空助力器总成	Vacuum booster assy.	1		√
1-4-1	B3540341	推杆叉	Putter	1		
1-4-2	Q350B10	六角螺母	Hex nut	1	only available with assembled parts	
1-4-3	B3540342	衬垫	Washer	1		
1-4-4	B3540411	助力真空管接头	Vacuum hose joint	1		
2	Q673B12	A型蜗杆传动式软管环箍	Steel spring hoop	2		√
3	B3540011	真空助力器真空软管	Vacuum hose	1	for Tritec engine	√
3	BAC540011	真空助力器真空软管	Vacuum hose	1	for LF481 engine	

2.17 Front brake




2.17 Front brake

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3501100	左前制动器带转向节总成	Left front brake with steer knuckle assy.	1		✓
1	B3501600	右前制动器带转向节总成	Right front brake with steer knuckle assy.	1		✓
1-1	Q184A1235	六角法兰面螺栓	Hex flange bolt	4		✓
1-2	B2304100	左转向节总成	Left steering knuckle assy.	1		
1-2	B2304200	右转向节总成	Right steering knuckle assy.	1		
1-2-1	B2304111	左转向节	Left steering knuckle	1		✓
1-2-1	B2304611	右转向节	Right steering knuckle	1		✓
1-2-2	B2304510	转向节轴承组件	Steering knuckle bearing	2		
1-2-3	B2304561	轴承挡圈	Bearing circlip	2		
1-3	B3501410	左前制动器底板组件	Front left brake bottom	1		✓
1-3	B3501910	右前制动器底板组件	Front right brake bottom	1		✓
1-4		六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer	6	only available with assembled parts	
1-5	B3103100	前轮毂总成	Front wheel hub	2		✓
1-6	B3501240	左前内制动摩擦片	Front left brake pad, inner	1		✓
1-6	B3501730	右前内制动摩擦片	Front right brake pad, inner	1		✓
1-7	B3501260	前外制动摩擦片	Front brake pad, outer	2		✓
1-8	B3501110	左前制动卡钳总成	Front left brake caliper	1		✓
1-8	B3501610	右前制动卡钳总成	Front right brake caliper	1		✓

2.17 Front brake

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1-9	B3501111	前制动盘	Front brake disc	2	左右各一	√

2.18 Rear brake




2.18 Rear brake

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3502100	左后制动器总成	Rear left brake	1		√
1	B3502600	右后制动器总成	Rear right brake	1		√
1-1	B3502111	后制动盘	Rear brake disc	2		√
1-2	231B-1027TF3	六角法兰面螺栓	Hex flange bolt	8		√
1-3	B3502110	左后制动卡钳总成	Rear left brake caliper assy.	1		√
1-3	B3502610	右后制动卡钳总成	Rear right brake caliper assy.	1		√
1-4	B3502182	后制动卡钳安装螺栓	Bolt, rear brake caliper	4		
1-5	B3502240	左后内制动摩擦片	Rear left brake pad, inner	1		√
1-5	B3502730	右后内制动摩擦片	Rear right brake pad, inner	1		√
1-6	B3502260	后外制动摩擦片	Front brake pad, outer	2		√
1-7	B3104100	后轮毂总成	Rear wheel hub	2		√
1-8	B3502400	左后制动底板总成	Left rear brake bottom assy.	1		
1-8	B3502900	右后制动底板总成	Right rear brake bottom assy.	1		
1-8-1	B3508100	驻车制动左拉索总成	parking brake left cable	1		
1-8-1	B3508200	驻车制动右拉索总成	Parking brake right cable	1		
1-8-2	B3502410	左后制动底板组件	Left rear brake bottom	1		√
1-8-2	B3502910	右后制动底板组件	Right rear brake bottom	1		√
1-8-3	B3502597	制动蹄固定簧片销	Brake shoe pin	4		

2.18 Rear brake

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1-8-4	Q1400610	六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer	2	only available with assembled parts	
1-8-5	B3502571	驻车制动摇臂	Parking brake swing arm	2		
1-8-6	B3502230	后制动蹄片组件	Rear brake shoe	4		√
1-8-7	B3502596	制动蹄固定簧片	Brake shoe leafspring	4		
1-8-8	B3502580	驻车制动调节杆组件	parking brake adjust rod	2		
1-8-9	B3502591	制动蹄回位弹簧	Return spring	2		
1-8-10	B3502595	制动蹄调节拉杆固定弹簧	Fixing spring	2		
1-8-11	B3502593	制动蹄拉紧弹簧	Stretched spring	2		
1-8-12	B3502594	制动蹄支撑板	Support plate	2		
1-9	231B-1027TF3	六角法兰面螺栓	Hex flange bolt	8		√

2.19 Radiator(for Tritec engine)




2.19 Radiator(for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	204-0814T1F3	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	2		√
2	B1302111	散热器上安装支架	Radiator upper bracket	2		√
3	B1302151	散热器上安装衬套	Radiator upper fixing sleeve	2		
4	B1301100	散热器总成	Radiator assy.	1		√
4-1	B1301170	散热器加水口盖组件	Radiator water filler cap	1		
5	B1302161	散热器下安装衬套	Radiator lower fixing sleeve	2		
6	Q67645	B型蜗杆式传动软管环箍	Hoop	4		
7	B1303121	散热器进水管	Radiator intake pipe	1		√
8	Q32006	六角法兰面螺母	Hex flange nut	2		√
9	B1303111	散热器出水管	Radiator drain pipe	1		√
10	B1308100	电子风扇带护风罩总成	Cooling fan assy.	1		√
10-1	B3749100	冷却风扇 I	Cooling fan I	1		
10-2	B1308710	护风罩组件	Fan shield	1		
10-3		六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer	6	only available with assembled parts	
10-4	B1308111	扇叶	Fan blade	2		
10-5		六角法兰面螺母	Hex flange nut	2	only available with assembled parts	
10-6	B3749200	冷却风扇 II	Cooling fan II	1		
11	B1311100	储液壶总成带溢流管	Water can with return tube assy.	1		√

2.19 Radiator(for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
11-1	B1311110	储液壶组件	Water can	1		
11-2	B1311181	溢流管	Return tube	1		
11-3	Q67312	刚带型弹性环箍	Steel hoop	2		
12	Q1400630	六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer	3		√

2.20 Exhaust system(for Tritec engine)




2.20 Exhaust system(for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	Q32008	六角法兰面螺母	Hex flange nut	4		√
2	L1200011	前密封垫	Front gasket	1		√
3	B1203100	排气管总成	Exhaust pipe assy.	1		√
4	Q32006	六角法兰面螺母	Hex flange nut	3	only available with assembled parts	√
5	B1211510	压簧螺栓组件	Setting bolt spring assy.	4		
5-1	B1211511	压簧螺栓	Bolt	4		√
5-2	B1211512	压簧	Pressure spring	4		√
6	Q1410616	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	3		√
7	B1211112	球型密封垫	Ball shape gasket	2		√
8	B1211522	后消声器橡胶悬置块	Rear muffler rubber block	3		√
9	B1211521	前消声器橡胶悬置块	Front muffler rubber block	1		√
10	B1205100	前消声器带催化器总成	Front muffler with catalyst assy.	1		√
11	Q32006	六角法兰面螺母	Hex flange nut	2		√
12	B1211525	排气管防脱架	Exhaust pipe bracket	1		√
13	Q32206	六角头螺母和锥形垫圈组合件	Hex bolt and taper springness washer	4		√
14	B1208013	排气管油箱下隔热板	Exhaust pipe heat insulater III	1	Fuel tank part	√
15	B1208011	排气管前围板下隔热板	Exhaust pipe heat insulater II	1	Front cowl part	√
16	B1208012	排气管前地板下隔热板	Exhaust pipe heat insulater I	1	Front floor part	√

2.20 Exhaust system(for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
17	Q350B06	六角薄螺母	Hex nut	4		√
18	B1208014	排气管右后纵梁下隔热板	Exhaust pipe heat insulater IV	1	Rear right longeron part	√
19	B1211526	隔热板减振垫	Heat insulater washer	1		√
20	B1201200	后消声器总成	Rear muffler	1		√


2.21 Wheels



2.21 Wheels

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	189-1235T13F6	车轮螺母组件	Wheel bolt	16		√
2	B3102510	轮毂盖板组件	Rim cap assy.	4		√
2-1	B3102513	轮毂中心标牌	Wheel LOGO	1		
2-2	B3102511	轮毂盖板	Rim cap	1		
2-3	B3102512	卡簧	Circlip	1		
3	L3106200	轮胎气门嘴	Valve component	5		√
4	L3106202	气门嘴防护帽	Cap, valve of tyre	5		
5	L3113011	5g粘式平衡块	Glue balancing weight	Demand	60g	
6	B3101111	铝合金车轮	Aluminum rim	4		√
7	B3101210	钢制车轮	Steel rim	1		√
8	B3106100	轮胎	Tyre	5		√


3.01 Communication system & AV system



3.01 Communication system & AV system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B7901500	CD播放器总成	CD player	1		✓
1	B7901700	DVD播放器总成	DVD player	1		✓
1	B7901700B1	DVD播放器总成 (GPS)	DVD player	1	with GPS	✓
2	B7909220	右前高音头组件	Right alt loudspeaker	1		✓
3	B7903170	收音机天线放大器总成	Antenna assy.	1		✓
4	Q2726395	十字槽盘头螺钉 -F型	Philips screw with washer	8		✓
5	Q1800612	六角法兰面承面带齿螺栓	Hex flange bolt	1		✓
6	Q41206	外锯齿锁紧垫圈	External teeth serrated lock washer	1		✓
7	B7909510	后扬声器	Rear loadspeaker	2		✓
8	B7909110	前门扬声器	Front door loadspeaker	2		✓
9	Q4400516	开口扁头抽芯铆钉	Rivet	6		✓
10	Q2734816F30	十字槽大半圆头自攻螺钉	Philips tapping screw	4		✓
11	B7909210	左前高音头组件	Left alt loudspeaker	1		✓

3.02 Electric equipment



3.02 Electric equipment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3721100	高音电喇叭	Alt horn	1		√
2	Q1840816	六角法兰面螺栓	Hex flange bolt	2		√
3	B3721200	低音电喇叭	Bass horn	1		√
4	B3741100	前刮水器电动机	Front wiper motor	1		√
5	B3747120	前风窗洗涤泵电机	Front wiper pump motor	1		
6	B7917730	倒车监控摄像头馈线	Reverse monitor harness	1	EX	√
7	B3723050	仪表线束管梁靠鼓风机接线器	Instrument harness adapter	1		
8	B3723010	仪表线束A柱下接线器	Instrument harness lower adapter	2	set on A pillar	
9	B3746500	左车门电动玻璃升降器电机	Glass lifter motor,left	4		√
9	B3746600	右车门电动玻璃升降器电机	Glass lifter motor,right	4		√
10	Q1840610	六角法兰面螺栓	Hex flange bolt	12		√
11	B3758110	前门接触开关	Contacter switch,front door	2		√
12	Q1840616T1F30	六角法兰面螺栓	Hex flange bolt	4		√
13	B3758120	后门接触开关	Contacter switch,rear door	2		√
14	Q1800612	六角法兰面承面带齿螺栓	Hex flange bolt	1		√
15	B7904310	静噪滤波器及支架	Noise filter	1		√
16	B271195	十字槽盘头自攻螺钉	Philips self-tapping screw	2		
17	B7917710	倒车监控摄像头	Reverse monitor camera	1	EX	√

3.02 Electric equipment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
18	Q2734295	十字槽盘头自攻螺钉	Philips self-tapping screw	2		
19	B7917711	摄像头装饰罩	Camera cap	1	EX	√
20	Q32006	六角法兰面螺母	Hex flange nut	2		√
21	B3605400	防盗报警器总成	Security warner	1		√
22	B3723060	车身线束接线器	Vehicle body harness adapter	1		
23	B3723030	仪表线束管梁左接线器	Instrument harness left adapter	1		
24	Q2706316	六角法兰面螺钉	Hex flange screw	1		√
25	B4104430	烟灰盒照明灯	Ashtray light	1		
26	B3725100	点烟器总成	Cigarette lighter	1		√
27	B3722200	发动机舱电器中央控制盒	Central control case	1	Engine room	
27-1	JD1926-30A/QC T73	继电器	Relay	1	speed regulation	√
27-1	JD1927-30A/QC T73	继电器	Relay	1	Front fog lamp	√
27-1	JD1927-30A/QC T73	继电器	Relay	1	Fan,High speed	√
27-1	JD1927-30A/QC T73	继电器	Relay	1	Fan,Low speed	√
27-1	JD1927-30A/QC T73	继电器	Relay	1	overtaking lamp	√
27-1	JD1927-30A/QC T73	继电器	Relay	1	Low beam	√
27-1	JD1927-30A/QC T73	继电器	Relay	1	High beam	√
27-1	JD1927-30A/QC T73	继电器	Relay	1	Compressor	√


3.02 Electric equipment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
27-1	JD1927-30A/QC T73	继电器	Relay	1	Main relay	√
27-1	JD101K-70A/QC T73	继电器	Relay	1	Blower	√
27-2	BX2011A1-30A/QC T73	保险丝	Fuse	2	ABS controller	√
27-2	BX2011A1-40A/QC T73	保险丝	Fuse	1	Blower	√
27-2	BX2011A1-60A/QC T73	保险丝	Fuse	1	Sub power	√
27-2	BX2011A1-60A/QC T73	保险丝	Fuse	1	Driving room power	√
27-2	BX2011A1-100A/QC T73	保险丝	Fuse	1	Main power	√
27-2	BX2011F-15A/QC T73	保险丝	Fuse	1	Low beam	√
27-2	BX2011F-15A/QC T73	保险丝	Fuse	1	High beam/overtaking lamp	√
27-2	BX2011F-15A/QC T73	保险丝	Fuse	1	Front fog lamp	√
27-2	BX2011F-25A/QC T73	保险丝	Fuse	1	Main relay	√
27-2	BX2011F-25A/QC T73	保险丝	Fuse	1	Fan,High speed	√
27-2	BX2011F-25A/QC T73	保险丝	Fuse	1	Fan,Low speed	√
27-2	BX2011F-10A/QC T73	保险丝	Fuse	1	Compressor	√
27-2	BX2011F-10A/QC T73	保险丝	Fuse	1	ECU	√
27-2	BX2011F-5A/QC T73	保险丝	Fuse	1	Fan,speed regulation/Compressor	√
27-2	BX2011F-10A/QC T73	保险丝	Fuse	1	Spare fuse	√
27-2	BX2011F-15A/QC T73	保险丝	Fuse	1	Spare fuse	√

3.02 Electric equipment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
27-2	BX2011F-20A/QC T73	保险丝	Fuse	1	Spare fuse	√
27-2	BX2011F-25A/QC T73	保险丝	Fuse	1	Spare fuse	√
27-2	BX2011F-30A/QC T73	保险丝	Fuse	1	Spare fuse	√
27-2	BX2011F-7.5A/QC T73	保险丝	Fuse	1	Spare fuse	√
27-3	B3722161B1	拨片器	Puller	1		
27-4	B3722211	发动机舱电器中央控制盒上盖	Central control case cap	1	Engine room	
28	Q32006	六角法兰面螺母	Hex flange nut	1		√
29	Q1410620	六角头螺栓和锥形弹性垫圈组合	Hex bolt and taper springness washer	1		√

3.03 Lamps




3.03 Lamps

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4116100	左前雾灯总成	Front left fog lamp	1		√
2	B4116200	右前雾灯总成	Front right fog lamp	1		√
3	Q2706316	六角法兰面螺钉	Hex flange screw	6		√
4	H3/GB 15776-2001	灯泡	Bulb	2		√
5	B4121100	左前组合灯	Front left head lamp	1	halogen lamp,unadjustable	√
5	B4121100B1	左前组合灯	Front left head lamp	1	EX,xenon lamp,adjustable	
5	B4121100C1	左前组合灯	Front left head lamp	1	halogen lamp,adjustable	
6	B4121200	右前组合灯	Front right head lamp	1	halogen lamp,unadjustable	√
6	B4121200B1	右前组合灯	Front right head lamp	1	EX,xenon lamp,adjustable	
6	B4121200C1	右前组合灯	Front right head lamp	1	halogen lamp,adjustable	
7	Q1410616LT1F30	六角头螺栓和锥形弹性垫圈组合	Hex bolt and taper springness washer	6		
8	H3/GB 15776-2001	灯泡	Bulb	2		√
9	H1/GB 15776-2001	灯泡	Bulb	2		√
9	D1S/GB 15776-2001	灯泡	Bulb	2	xenon bulb	
10	PY21W/GB 15776-2001	灯泡	Bulb	2		√
11	B4131100	左前门灯	Front left door lamp	1		√
12	B4123400	后顶灯	Rear ceiling light	1		√
13	C5W/GB 15776-2001	灯泡	Bulb	1		√

3.03 Lamps

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
14	B4131200	右前门灯	Front right door lamp	1		√
15	B4131400	右后门灯	Rear right door lamp	1		√
16	B4134100	高位制动灯	High-mount brake lamp	1		√
17	B4131300	左后门灯	Rear left door lamp	1		√
18	305-0508F3	六角法兰面螺栓	Hex flange bolt	1		√
19	B3758300	行李箱照明灯开关	Trunk light switch	1		√
20	PY21W/GB 15776-2001	灯泡	Bulb	2	Steering lamp	√
21	P21W/GB 15776-2001	灯泡	Bulb	2	Reverse lamp	√
22	W3W/GB 15776-2001	灯泡	Bulb	2	Registration lamp	√
23	Q32006	六角法兰面螺母	Hex flange nut	6		√
24	B4108200	右后牌照灯	Right registration lamp	1		√
25	B4108100	左后牌照灯	Left registration lamp	1		√
26	B4133400	右后组合灯	Right tail lamp	1		√
27	B4133300	左后组合灯	Left tail lamp	1		√
	B4123100	前顶灯	Front ceiling light	1		
	B4127100	行李箱照明灯	Trunk light	1		√


3.04 Locks



3.04 Locks

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3704100	点火开关	Ignition switch assy.	1		√
1-1	B3704162	防盗螺栓	Bolt	1		
1-2	B3704161	轴盖	Ignition Cap	2		
1-3	B3704170	点火开关锁芯总成	Ignition switch lock cylinder	1		
1-4	B3704300	点火开关光圈	Ignition switch coil	1		√
2						
2-1	B3704220	遥控钥匙 (LX)	Remote key	2	LX	
2-1	B3704220B1	遥控钥匙 (EX)	Remote key	2	EX, trunk unlock function	
2-1	B3704210	普通钥匙	Key	1		√
2-2	B3704221	钥匙片	Key plate	2		√
2-3	B3704240	遥控手柄 (LX)	key handle	2	LX	√
2-3	B3704240B1	遥控手柄 (EX)	key handle	2	EX	√
3	B3704510	左前门锁芯	Door lock cylinder, front left door	1		√
4	B3704520	右前门锁芯	Door lock cylinder, front right door	1		√
5	B3704550	行李舱锁芯总成	Trunk lock cylinder	1		√


3.05 Battery(for Tritec engine)



3.05 Battery(for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	Q32006	六角法兰面螺母	Hex flange nut	2		√
2	B3703216	蓄电池压板胶垫	Battery press beam	1		√
3	L3703100	蓄电池总成	Battery assy.	1		√
4	B3703215	蓄电池底盖	Battery bottom			√
5	B3703212	蓄电池拉杆	Battery draglink	1		√
6	Q1460620	六角头螺栓弹簧垫圈和平垫圈组合件	Hex bolt and taper springness washer	2		√
7	B3703220	蓄电池托架	Battery bracket	3		√
8	B3703230	蓄电池托架支撑架	Battery bracket mount	1		√
9	Q1460825	六角头螺栓弹簧垫圈和平垫圈组合件	Hex bolt and taper springness washer	1		√
10	231-1025TF3	六角法兰面螺栓	Hex flange bolt	1		√
11	Q1410516	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	4		√
12	231-1025TF3	六角法兰面螺栓	Hex flange bolt	2		√
13	B3703211	蓄电池压板	Battery press plate	1		√


3.06 Instrument panel



3.06 Instrument panel

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3820000	组合仪表	Instrument cluster	1	for TRITEC engine	√
1	B3820000B1	组合仪表	Instrument cluster	1	120KM/H warning,for TRITEC engine	√
2	B3820021	簧片螺母	Spring nut	1		
3	B8112100	电动空调控制面板及开关总成	Air conditioner control panel	1	MT	√
3	B8112100B1	自动空调控制面板及开关总成	Air conditioner control panel	1	AT	√
4	Q2734816	十字槽半圆头自攻螺钉	Philips self-tapping screw	2		√
5	B3774200	雨刮组合开关总成	Wiper switch	1		√
6	B3774100	灯光组合开关总成	Lamp switch	1		√
7	B3750500	电动后视镜开关组件	Wing mirror switch assy.	1	DX, LX	√
7	B3750500B1	电动后视镜开关组件	Wing mirror switch assy.	1	EX	
7-1	B3750510	防盗指示灯	Security waring light	1		√
7-2	B3782070	电动外后视镜控制开关	Wing mirror switch	1		√
7-3	B3710210	背景光调整开关	Background light switch	1		
7-4	B3710230	近光灯光轴调整开关	Low beam adjust switch	1		√


3.07 Electric device



3.07 Electric device

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3674100	BCM车身控制器组件	Body control module (BCM)	1	LX	√
1	B3674100B1	BCM车身控制器组件	Body control module (BCM)	1	DX	
1	B3674100C1	BCM车身控制器组件	Body control module (BCM)	1	EX	
2	Q1840816	六角法兰面螺栓	Hex flange bolt	2		√
3	B3658300	安全气囊时钟弹簧	Airbag clock spring	1	3 loop	√
3	B3658300B1	安全气囊时钟弹簧	Airbag clock spring	1	7 loop	√
4	B3661220	环境光传感器	Ambient light sensor	1		√
5	B3612211	电喷ECU固定支架	ECU bracket	1		√
6	Q37106	焊接方螺母	Square nut	4		√
7	Q1410520L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	2		√
8	B3612100B2	电喷ECU	ECU	1	for Tritec engine	√
9	B3612212	电喷ECU防尘罩	ECU cap	1		√
10	Q1410625	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	4		√
11	Q1840616	安装螺栓	Bolt	3		√
12	B3658100	安全气囊ECU	Airbag ECU	1	2 loop	√


3.08 Headlining harness



3.08 Headlining harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4005100	顶棚线束总成	Headlining harness	1	LX, rear top light	√
1	B4005100B1	顶棚线束总成	Headlining harness	1	EX	√


3.09 Vehicle body harness



3.09 Vehicle body harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4002100	左车身线束	Left body harness	1		√
1	B4002100B1	左车身线束	Left body harness	1	EX	√
2	Q1800612	六角法兰面承面带齿螺栓	Hex flange bolt	3		√
3	Q41206	外锯齿锁紧垫圈	External teeth serrated lock washer	3		√
4	B3723060	车身线束接线器	Body harness adapter	1		
5	B4035003	车身线束油泵胶套	Body harness sleeve	1		
6	B4035005	倒车雷达接线胶套	Reverse radar harness sleeve	1		


3.10 Defrost earth wire



3.10 Defrost earth wire

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4002020	后除霜接地线总成	Defrost earth wire	1		√
2	Q1800612	六角法兰面承面带齿螺栓	Hex flange bolt	1		√
3	Q41206	外锯齿锁紧垫圈	External teeth serrated lock washer	1		√


3.11 Reverse radar harness



3.11 Reverse radar harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4002800	倒车雷达探头线束	Reverse radar harness	1		√
2	B3603841	安装支架	Bracket	3		√
3	B3603820	倒车雷达传感器	Reverse radar sensor	3		√


3.12 Power harness



3.12 Power harness

[illegible]


3.13 Rear door harness



3.13 Rear door harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4006300	左后门线束	Rear left door harness	1		√
2	B4006400	右后门线束	Rear right door harness	1		√


3.14 Wheel speed sensor harness



3.14 Wheel speed sensor harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3630400	右前轮轮速传感器总成	Front right wheel speed sensor	1		√
2	B3630452	右前轮速传感器线束支架B	Plastic bracket,FR speed sensor	1		
3	B3630451	右前轮速传感器线束支架A	Metal bracket,FR speed sensor	1		
4	Q1840620	六角法兰面螺栓	Hex flange bolt	2		√
5	B4009250	右后轮轮速传感器线束总成	Rear right wheel speed sensor	1		√
6	B4009288	电缆线胶套	Sleeve	2		
7	B4009286	右后轮速传感器线束支架A	Plastic bracket,RR speed sensor	1		√
8	B4009287	右后轮速传感器线束支架B	Metal bracket,RR speed sensor	1		√
9	B4009284	后轮速传感器线束支架A	Metal bracket,Rear speed sensor	2		√
10	B4009285	后轮速传感器线束支架B	Plastic bracket,Rear speed sensor	2		√
11	B4009283	左后轮速传感器线束支架B	Metal bracket,RL speed sensor	1		√
12	B4009282	左后轮速传感器线束支架A	Plastic bracket,RL speed sensor	1		√
13	B4009240	左后轮轮速传感器线束总成	Rear left wheel speed sensor	1		√
14	B3630351	左前轮速传感器线束支架A	Metal bracket,FL speed sensor	1		
15	B3630300	左前轮轮速传感器总成	Front left wheel speed sensor	1		√
16	B3630352	左前轮速传感器线束支架B	Plastic bracket,FL speed sensor	1		


3.15 Front harness



3.15 Front harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	Q1800612	六角法兰面承面带齿螺栓	Hex flange bolt	2		√
2	B4001600	前部线束总成	Front harness	1	halogen lamp,adjustable	√
2	B4001600B1	前部线束总成	Front harness	1	EX,xenon lamp,adjustable	√
3	Q41206	外锯齿锁紧垫圈	External teeth serrated lock washer	2		√


3.16 Front door harness



3.16 Front door harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4006100	左前门线束	Front left door harness	1		√
2	B4006200	右前门线束	Front right door harness	1		√


3.17 Antenna harness



3.17 Antenna harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B7903170	收放机天线放大器总成	Antenna harness	1		√
2	Q1800612	六角法兰面承面带齿螺栓	Hex flange bolt	1		√
3	Q41206	外锯齿锁紧垫圈	External teeth serrated lock washer	1		√


3.18 Battery negative wire



3.18 Battery negative wire

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	Q1800612	六角法兰面承面带齿螺栓	Hex flange bolt	1		√
2	B4001350	蓄电池负极线束	Battery negative wire	1		√
3	Q41206	外锯齿锁紧垫圈	External teeth serrated lock washer	1		√


3.19 Instrument panel harness



3.19 Instrument panel harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4003100	仪表板线束	Instrument panel harness	1	DX, LX	√
1	B4003100B1	仪表板线束	Instrument panel harness	1	EX	
2	Q1800612	六角法兰面承面带齿螺栓	Hex flange bolt	2		√
3	Q41206	外锯齿锁紧垫圈	External teeth serrated lock washer	2		√


3.20 Airbag harness



3.20 Airbag harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4003600	安全气囊线束总成	Airbag harness	1		√
1	B4003600B1	安全气囊线束总成	Airbag harness	1	EX	√


3.21 Inner handrail switch



3.21 Inner handrail switch

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3746100	左前门扶手板开关	Inner handrail with switches,front left door	1		√
1-1	B3746120	左前门玻璃升降开关	Glass lifter,front left door	1		√
1-2	B3746110	左前门扶手板	Inner handrail,front left door	1		√
2	B3746300	左后门扶手板开关	Inner handrail with switches,rear left door	1		√
2-1	B3746220	玻璃升降开关	Glass lifter	1		√
2-2	B3746310	左后门扶手板	Inner handrail,raer left door	1		√
3	B3746200	右前门扶手板开关	Inner handrail with switches,front right door	1		√
3-1	B3746220	玻璃升降开关	Glass lifter	1		√
3-2	B3746210	右前门扶手板	Inner handrail,front right door	1		√
4	B3746400	右后门扶手板开关	Inner handrail with switches,rear right door	1		√
4-1	B3746220	玻璃升降开关	Glass lifter	1		√
4-2	B3746410	右后门扶手板	Inner handrail,rear right door	1		√
5	B3746130	自攻螺钉渡盖	Tapping screw cap	4		
6	Q2714819	十字槽盘头自攻螺钉	Philips self-tapping screw	4		√

3.22 Central control case



3.22 Central control case

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3722100	驾驶舱电器中央控制盒	Central control case	1	Driver room	√
1-1	JD1912-40A/QC T73	继电器	Relay	1	Sub power	√
1-1	JD1927-30A/QC T73	继电器	Relay	1	Horn	√
1-1	JD1927-30A/QC T73	继电器	Relay	1	Fuel	√
1-1	JD1927-30A/QC T73	继电器	Relay	1	Rear fog lamp	√
1-1	JD1927-30A/QC T73	继电器	Relay	1	Rear defroster	√
1-2	BX2011A1-30A/QC T73	保险丝	Fuse	1	Ignition AM1	√
1-2	BX2011A1-30A/QC T73	保险丝	Fuse	1	Ignition AM2	√
1-2	BX2011A1-30A/QC T73	保险丝	Fuse	1	Rear defroster	√
1-2	BX2011F-5A/QC T73	保险丝	Fuse	1	BCM central control lock power	√
1-2	BX2011F-5A/QC T73	保险丝	Fuse	1	Top light/trunk light	√
1-2	BX2011F-5A/QC T73	保险丝	Fuse	1	Air conditioner controller B+	√
1-2	BX2011F-5A/QC T73	保险丝	Fuse	1	Instrument cluster, ignition	√
1-2	BX2011F-5A/QC T73	保险丝	Fuse	1	A/V system power	√
1-2	BX2011F-5A/QC T73	保险丝	Fuse	1	BCM, ignition	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	Top light	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	Instrument cluster	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	Rear fog lamp	√


3.22 Central control case

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	sub lamps	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	Fuel pump	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	wing mirror	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	Air conditioner controller,ignition	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	Brake light	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	ABS control	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	airbag	√
1-2	BX2011F-15A/QC T73	保险丝	Fuse	1	top window	√
1-2	BX2011F-15A/QC T73	保险丝	Fuse	1	BCM steering light/indicator light	√
1-2	BX2011F-15A/QC T73	保险丝	Fuse	1	A/V system power	√
1-2	BX2011F-15A/QC T73	保险丝	Fuse	1	wiper	√
1-2	BX2011F-15A/QC T73	保险丝	Fuse	1	horn	√
1-2	BX2011F-15A/QC T73	保险丝	Fuse	1	cigarette	√
1-2	BX2011F-15A/QC T73	保险丝	Fuse	1	Brake light	√
1-2	BX2011F-25A/QC T73	保险丝	Fuse	1	magnetic field power/generator ECU/ignition coil/camshaft sensor/speed sensor	√
1-2	BX2011F-30A/QC T73	保险丝	Fuse	1	glass lifter power	√
1-2	BX2011F-5A/QC T73	保险丝	Fuse	1	Spare fuse	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	2	Spare fuse	√

3.22 Central control case

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1-2	BX2011F-15A/QC T73	保险丝	Fuse	1	Spare fuse	√
1-2	BX2011F-25A/QC T73	保险丝	Fuse	1	Spare fuse	√
1-2	BX2011F-30A/QC T73	保险丝	Fuse	1	Spare fuse	√
1-3	B3722111	驾驶室电器中央控制盒上盖	Central control case cap	1	Driver room	
1-4	B3722161	拨片器	Puller	1		
2	Q2734816	十字槽半圆头自攻螺钉	Philips self-tapping screw	3		√


3.23 Harness clamps



3.23 Harness clamps

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	XJ-7X12-R	线束支架	Harness clamp			√
2	CL-7X17-B	线束L型卡钉	Harness clamp			√
3	M23408	线束卡钉扎带	Harness clamp			√
4	CS03	线束卡钉扎带	Harness clamp			√
5	M32481	线束支架	Harness clamp			√
6	AD37600013	线束支架	Harness clamp			√
7	T11-3724072	线束支架	Harness clamp			√
8	82711-1A890	线束支架	Harness clamp			√
9	DWJ-H26	线束F型支架	Harness clamp			√
10	M23438	线束支架	Harness clamp			√
11	M32483	线束支架	Harness clamp			√
12	ZD3143X5	线束卡钉扎带	Harness clamp			√
13	XD-67	线束F型卡钉	Harness clamp			√


4.01 Vehicle body



4.01 Vehicle body

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5009001	白车身总成	Vehicle body assy.			√


4.02 Engine hood



4.02 Engine hood

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B8402000	发动机罩总成	Engine hood	1		√
2	B8402620	发动机罩右铰链组件	Engine hood right hinge	1		√
3	Q1840820	六角法兰面螺栓	Hex flange bolt	4		√
4	Q1840816	六角法兰面螺栓	Hex flange bolt	4		√
5	B8402610	发动机罩左铰链组件	Engine hood left hinge	1		√


4.03 Front cowl



4.03 Front cowl

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5302000	前围板总成	Front cowl assy.	1		√
2	B5301000	前围上横梁总成	Front cowl upper beam	1		√


4.04 顶盖 Roof



4.04 顶盖 Roof

[illegible]


4.05 Side cowl



4.05 Side cowl

[illegible]


4.06 Front door



4.06 Front door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B6101001	左前车门总成	Front left door assy.	1		√
2	B6106210	右前车门上铰链组件	Upper hinge,front right door	1		√
3	B6106220	右前车门下铰链组件	Lower hinge,front right door	1		√
4	B6106110	左前车门上铰链组件	Upper hinge,front left door	1		√
5	B6106120	左前车门下铰链组件	Lower hinge,front left door	1		√
6	Q1840820	六角法兰面螺栓	Hex flange bolt	16		√
7	B6101002	右前车门总成	Front right door assy.	1		√


4.07 Rear door



4.07 Rear door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B6201002	右后车门总成	Rear right door assy.	1		√
2	B6201001	左后车门总成	Rear left door assy.	1		√
3	B6206210	右后车门上铰链组件	Upper hinge,Rear right door	1		√
4	B6206220	右后车门下铰链组件	Lower hinge,Rear right door	1		√
5	B6206110	左后车门上铰链组件	Upper hinge,Rear left door	1		√
6	B6206120	左后车门下铰链组件	Lower hinge,Rear left door	1		√
7	Q1840820	六角法兰面螺栓	Hex flange bolt	16		√


4.08 Front side fender



4.08 Front side fender

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B8403111	左翼子板	Front left fender	1		√
2	B8403211	右翼子板	Front right fender	1		√


4.09 Front damping



4.09 Front damping

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B2803200	前保险杠骨架主体	Front bumper frame	1		√
2	B2803211	前保险杠左固定板	Front bumper frame left fixing plate	1		√
3	B2803212	前保险杠右固定板	Front bumper frame right fixing plate	1		√
4	B8401100	水箱上横梁总成	Radiator upper beam	1		√
5	B8400030	发动机罩锁体安装立柱总成	Engine hood lock fixing plate	1		√
6	B8400020	右前轮罩纵梁总成	Right front longeron and wheel cap assy.	1		√
7	B8400120	右前纵梁外板前段总成	Right front longeron fore part	1		√
8	B8400130	左前纵梁外板前段总成	Left front longeron fore part	1		√
9	B8400010	左前轮罩纵梁总成	Left front longeron and wheel cap assy.	1		√
10	B8401200	水箱下横梁总成	Radiator lower beam	1		√
11	B2804241	后保险杠骨架右安装支架	Rear bumper frame right fixing plate	1		√
12	B2804231	后保险杠骨架左安装支架	Rear bumper frame left fixing plate	1		√
13	B2804200	后保险杠骨架主体	Rear bumper frame	1		


4.10 Floor assy.



4.10 Floor assy.

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5120000	前地板总成	Front floor assy.	1		√
2	B5130000	后地板总成	Rear floor assy.	1		√


4.11 Rear cowl



4.11 Rear cowl

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5601100	搁物板总成	Shelf assy.	1		√
2	B5605200	行李箱盖右铰链总成	Trunk lid right hinge	1		√
3	B5605100	行李箱盖左铰链总成	Trunk lid left hinge	1		√
4	Q1840625	六角法兰面螺栓	Hex flange bolt	4		√
5	B5604000	行李箱盖总成	Trunk lid assy.	1		√
6	B5601200	后围板总成	Rear cowl assy.	1		√
7	B5601251	后保险杠右安装支架	Rear bumper right bracket	1		√
8	B5601241	后保险杠左安装支架	Rear bumper left bracket	1		√
9	Q32006	六角法兰面螺母	Hex flange nut	4		√


5.01 Steering wheel and Airbag



5.01 Steering wheel and Airbag

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3658300	安全气囊时钟弹簧	Airbag clock spring	1		√
1	B3658300B1	安全气囊时钟弹簧	Airbag clock spring	1	EX	√
2	B3402100B14	方向盘总成	Steering wheel	1	foam, deep grey	√
2	B3402100B1B14	方向盘总成	Steering wheel	1	leather,with multi-switches, deep grey	√
3	B5824100	驾驶员气囊模块	Driver's airbag	1		√
4	B3658100	安全气囊ECU	Airbag ECU	1	2 loop	√
4	B3658100B1	安全气囊ECU	Airbag ECU	1	4 loop	√
5	B5824200B14	副驾驶员气囊模块	Passengers airbag	1	deep grey	√
6	Q1840820	六角法兰面螺栓	Hex flange bolt	2		√

5.02 Side body



5.02 Side body

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	Q2215519F31	十字槽盘头自攻螺钉和大垫圈组合件	Philips screw with washer	14		✓
2	400-065	塑料卡扣	Plastic clip	14		✓
3	B5416225	左右裙板小堵盖	Skirt plate plug	14	small	✓
4	B5416223	左右裙板小卡扣	Skirt plate clip	14	small	
5	B5416224	左右裙板大卡扣	Skirt plate clip	16	big	
6	B5416226	左右裙板大堵盖	Skirt plate plug	16	big	✓
7	B5400113	隔音海绵	Sound proof cushion	2		✓
8	B5416222	A柱右三角窗装饰板橡胶条	Seal, right triangular window decoration	1		✓
8	B5416212	A柱左三角窗装饰板橡胶条	Seal, left triangular window decoration	1		✓
9	400-1405	塑料卡扣	Plastic clip	1		✓
10	B5416221	A柱右三角窗装饰板	Right triangular window decoration	1		✓
10	B5416211	A柱左三角窗装饰板	Left triangular window decoration	1		✓
11	B5402021	顶棚右前支撑架	Roof support, front right	1		✓
11	B5402011	顶棚左前支撑架	Roof support, front left	1		✓
12	B6107217	右前门框密封条	Front right door frame seal	1		✓
12	B6107117	左前门框密封条	Front left door frame seal	1		✓
13	B5402230B15	B柱右上护板组件	Right upper fender, B pillar	1	pale grey	✓
13	B5402130B15	B柱左上护板组件	Left upper fender, B pillar	1	pale grey	✓

5.02 Side body

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
14	B5402022	顶棚右后支撑架	Roof support, rear right	1		√
14	B5402012	顶棚左后支撑架	Roof support, rear left	1		√
15	B6207217	右后门框密封条	Rear right door frame seal	1		√
15	B6207117	左后门框密封条	Rear left door frame seal	1		√
16	B5107111	Φ 30堵盖	Plug	19	Φ30	√
17	Q72725	Φ 25橡胶堵盖	Rubber plug	2	Φ25	√
18	B8123630	通风口组件	Trunk ventilation	1		√
18-1	B8123631	行李舱通风口骨架	Trunk ventilation frame	2		
18-2	B8123632	行李舱通风口橡胶片 I	Trunk ventilation seal I	2		
18-3	B8123633	行李舱通风口橡胶片 II	Trunk ventilation seal II	2		
18-4	B5400121	侧围塑料螺母	Plastic nut, side bdoy	2	Φ15	√
19	B5402250B15	C柱右上护板组件	Right upper fender,C-pillar	1	pale grey	√
19	B5402150B15	C柱左上护板组件	Left upper fender,C-pillar	1	pale grey	√
20	400-1729	塑料卡扣	Plastic clip	7		√
21	400-256	塑料卡扣	Plastic clip	1		√
22	B5400341	右后轮挡泥板	Rear right mudguard	1		√
22	B5400331	左后轮挡泥板	Rear left mudguard	1		√
23	B5400342	右后挡泥板防溅板	Spray-proof, rear right mudguard	1		√


5.02 Side body

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
23	B5400337	左后挡泥板防溅板	Spray-proof, rear left mudguard	1		✓
24	B5400338	后挡泥板防溅板卡扣	Clip, rear spray-proof	2		✓
25	Q2754820	十字槽凹穴六角头自攻螺钉	Philips self-tapping screw	1		
26	B5400343	右后饰板	Rear right decoration,mudguard	1		✓
26	B5400339	左后饰板	Rear left decoration,mudguard	1		✓
27	400-1500	塑料卡扣	Plastic clip	1		✓
28	B5402181B15	左后门槛护板	Rear left threshold fender	1	pale grey	✓
28	B5402281B15	右后门槛护板	Rear right threshold fender	1	pale grey	✓
29	B5400112	左右B柱海绵块	B pillar cushion	4		✓
30	B5402241B15	B柱右下护板	Right lower fender,B-pillar	1	pale grey	✓
30	B5402141B15	B柱左下护板	Left lower fender,B-pillar	1	pale grey	✓
31	B5402171B15	左前门槛护板	Front left threshold fender	1	pale grey	✓
31	B5402271B15	右前门槛护板	Front right threshold fender	1	pale grey	✓
32	B5402220B15	A柱右下护板组件	Right lower fender,A-pillar	1	pale grey	✓
32	B5402120B15	A柱左下护板组件	Left lower fender,A-pillar	1	pale grey	✓
33	Q1840620	六角法兰面螺栓	Hex flange bolt	2		✓
34	B5400316	小挡泥板	Small mudguard	2		✓
35	B5400321	右前轮挡泥板	Front right mudguard	1		✓

5.02 Side body

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
35	B5400311	左前轮挡泥板	Front left mudguard	1		√
36	B5400315	固定钣金	Fixing plate	1		√
37	400-1933	塑料卡扣	Plastic clip	2		√
38	B6105141	侧车门锁扣组件	Door buckle component	4		√
39	327-0820	内六角花形沉头螺钉	Inner hex flat head screw	8		
40	B5402211B15	A柱右上护板	Right upper fender,A-pillar	1	pale grey	√
40	B5402111B15	A柱左上护板	Left upper fender,A-pillar	1	pale grey	√
41	400-540	塑料卡扣	Plastic clip	1		√

5.03 Front attachment




5.03 Front attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B2803132	前保险杠右连接支架	Front bumper right connecting bracket	1		√
2	B8402300	发动机罩撑杆组件	Hood prop assy.	1		√
2-1	B8402313	发动机罩撑杆顶部塑料顶套	Hood prop top	1		
2-2	B8402321	发动机罩撑杆放置卡槽	Hood prop hodler	1		√
2-3	B8402311	发动机罩撑杆	Hood prop	1	φ7	
2-4	B8402312	发动机罩撑杆旋转塑料卡套	Hood prop sleeve	1		
3	B8402800	车前橡胶件总成	Engine room seal assy.	1		
3-1	B8402821	发动机仓后密封条	Engine room rear seal	1		√
3-2	B8402822	发动机仓后密封条卡扣	Engine room rear seal clip	8		√
4	B5301012	堵片	Plug	2	Φ35	√
5	B2803131	前保险杠左连接支架	Front bumper left connecting bracket	1		√
6	Q2734819	十字槽半圆头自攻螺钉	Philips self-tapping screw	2		√
7	B5400813	子母扣	Inlay clip	8		√
8	B2802111	发动机左下横挡泥板	Engine mudguard, left	1		√
9	B8402400	机仓锁拉索	Engine hood lock cable	1		√
10	B8402510	发动机罩锁体机仓锁	Engine hood lock	1		√
11	Q1840612	六角法兰面螺栓	Hex flange bolt	1		√
3-3	B8402811	发动机仓前密封条	Engine room front seal	1		√

5.03 Front attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
3-4	B8402812	发动机仓前密封条卡扣	Engine room front seal clip	4		√
13	Q2714819	十字槽盘头自攻螺钉	Philips screw	6		√
14	B2803134	前保险杠固定卡套	Front bumper fixing sleeve	6		
15	B2802211	发动机右下横挡泥板	Engine mudguard, right	1		√

5.04 Safety belt




5.04 Safety belt

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5811210B15	右前安全带卷收器总成	Front right safety belt retractor assy.	1	pale grey, ordinary	√
1	B5811210B1B15	右前安全带卷收器总成	Front right safety belt retractor assy.	1	pale grey, pretensioner	√
1	B5811210A2B15	右前安全带卷收器总成	Front right safety belt retractor assy.	1	pale grey, ordinary,E-mark	√
1	B5811210B2B15	右前安全带卷收器总成	Front right safety belt retractor assy.	1	pale grey, pretensioner,E-mark	√
1-1	B5811211	右前安全带卷收器	Front right safety belt retractor	1		
1-2	231-(7/16) " 42	六角法兰面螺栓	Hex flange bolt	1		
2	B5811114	安全带带头护盖	Safety belt end cap	2		√
3	231-0614	六角法兰面螺栓	Hex flange bolt	2		
4	231-(7/16) " 22	六角法兰面螺栓	Hex flange bolt	4		
5	231-1025TF3	六角法兰面螺栓	Hex flange bolt	2		√
6	B5811120	安全带高度调节器总成	Safety belt height adjuster	2		√
6	B5811120A2	安全带高度调节器总成	Safety belt height adjuster	2	E-mark	√
7	B5811110B15	左前安全带卷收器总成	Front left safety belt retractor assy.	1	pale grey, ordinary	√
7	B5811110B1B15	左前安全带卷收器总成	Front left safety belt retractor assy.	1	pale grey, pretensioner	√
7	B5811110A2B15	左前安全带卷收器总成	Front left safety belt retractor assy.	1	pale grey, ordinary,E-mark	√
7	B5811110B2B15	左前安全带卷收器总成	Front left safety belt retractor assy.	1	pale grey, pretensioner,E-mark	√
7-1	B5811111	左前安全带卷收器	Front left safety belt retractor	1		
7-2	231-(7/16) " 42	六角法兰面螺栓	Hex flange bolt	1		

5.04 Safety belt

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
8	B5812110B15	后安全带卷收器总成	Rear safety belt retractor assy.	2	pale grey	√
8	B5812110A2B15	后安全带卷收器总成	Rear safety belt retractor assy.	2	pale grey, E-mark	√
8-1	B5812111	后安全带卷收器	Rear safety belt retractor	2		
8-2	231-(7/16) " 34	六角法兰面螺栓	Hex flange bolt	2		
8-3	231-(7/16) " 22	六角法兰面螺栓	Hex flange bolt	2		
9	B5812230B15	后排双联锁扣总成	Rear safety belt twin buckle	1	pale grey	√
9	B5812230A2B15	后排双联锁扣总成	Rear safety belt twin buckle	1	pale grey, E-mark	√
10	B5812130B15	后排锁扣及腰带总成	Rear safety belt	1	pale grey	√
10	B5812130A2B15	后排锁扣及腰带总成	Rear safety belt	1	pale grey, E-mark	√


5.05 Ventilation



5.05 Ventilation

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5306400B14	右出风口总成	Right ventilation nozzle	1	deep grey	√
2	B5306520B16	中风口右风窗组件	Middle ventilation nozzle, right part	1	black	√
3	B5306510B16	中风口左风窗组件	Middle ventilation nozzle, left part	1	black	√
4	B5306300B14	左出风口总成	Left ventilation nozzle	1	deep grey	√

5.06 Floor attachment




5.06 Floor attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5110116	中地板右阻尼垫	Floor damper,right	1		
2	Q72716	地板Φ16橡胶堵盖	Floor rubber plug	2	Φ16	√
3	B5110115	中地板左阻尼垫	Floor damper,left	1		
4	B5110117	行李箱阻尼垫	Trunk damper	1		
5	B5107117	腰形堵盖	Plug	2		√
6	B5107123	油箱检修口盖	Fuel tank top cap	1		√
7	201-1020	六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer	2		
8	B7007000	后座椅支架	Rear seat bracket	1		
9	Q72745	地板Φ45橡胶堵盖	Floor rubber plug	6	Φ45	√
10	B2805111	后托钩	Rear hook	1		√
11	Q1401235	六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer	2		√
12	Q72730	地板Φ30橡胶堵盖	Floor rubber plug	2	Φ30	√
13	Q72725	Φ25橡胶堵盖	Floor rubber plug	7	Φ25	√
14	B5107124	加油管下隔架	Fuel filling pipe spacer	2		√
15	201-0820	六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer	4		
16	B5107122	后座椅挂钩塑料套	Rear hook sleeve	2		
17	B5107118	前地板中堵盖	Front floor middle plug	2		
18	B5107113	地板后左阻尼垫	Floor damper,rear left	1		

5.06 Floor attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
19	B5110111	地板前左阻尼垫	Floor damper,front left	1		
20	B8206000B16	驾驶员搁脚板	Driver's feet rest	1	black	
21	B5110112	地板前右阻尼垫	Floor damper,front right	1		
22	B5107111	Φ30堵片	Plug	12	Φ30	√
23	B5107112	Φ10橡胶堵盖	Rubber plug	6	Φ10	√
24	B5110114	地板后右阻尼垫	Floor damper,rear right	1		
25	B5109023	地毯前左内侧隔垫	Carpet spacer, left	1		
26	B5109023	地毯前右内侧隔垫	Carpet spacer, right	1		
27	B5109100B15	主地毯	Carpet assy.	1	pale grey	√
28	B5101210	备胎固定支架	Spare tyre fixing bracket	1		√
28-1	B5101214	备胎旋紧帽	Spare tyre cap 1	1		
28-2	B5101213	备胎缩紧盖背部毡垫	Felt washer	1		
28-3	B5101212	备胎缩紧盖	Spare tyre cap 2	1		√
28-4	B5101211	备胎固定杆	Spare tyre fixing rod	1		


5.07 Roof attachment



5.07 Roof attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5704112	车顶密封压条卡扣	Roof seal clip	4		√
2	B5704111	车顶左密封压条	Roof seal, left	1		√
3	B5704211	车顶右密封压条	Roof seal, right	1		√
4	B8215100B15	安全拉手	Safety handle	3		√
5	Q1840645	六角法兰面螺栓	Hex flange bolt	6		√
6	B5702111B15	顶蓬	Roof	1	pale grey	√
7	B8204200B15	右遮阳板总成	Right sunvisor	1	pale grey	√
8	B8204100B15	左遮阳板总成	Left sunvisor	1	pale grey	√
9	B8204030B15	遮阳板固定挂钩	Sunvisor fixing hook	2	pale grey	√
10	B8204020B15	右遮阳板大固定座组件	Right sunvisor fixing seat	1	pale grey	√
11	B8204010B15	左遮阳板大固定座组件	Left sunvisor fixing seat	1	pale grey	√
12	B5702012	顶蓬海绵块I	Roof foam cushion I	2		√
13	B5702013	顶蓬海绵块II	Roof foam cushion II	2		√


5.08 Roof attachment (Top window)



5.08 Roof attachement (Top window)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5702111B1B15	顶蓬	Roof	1	top window, pale grey	

5.09 Windsheild




5.09 Windsheild

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B8201000	内视镜	Rearview mirror	1		√
2	B8201121	内视镜底座	Rearview mirror seat	1		
3	B5206123	后挡风玻璃胶条	Rear wind-shield glass seal	1		√
4	B5206124	后挡风玻璃插片	Rear wind-shield glass insert	4		
5	B5206120	后挡风玻璃	Rear wind-shield glass	1		√
6	B5206116	挡风玻璃上限位卡 II	Wind-shield glass clip II	2		√
7	B5206115	挡风玻璃限位卡 I	Wind-shield glass clip I	2		√
8	B5206110	前挡风玻璃	Front wind-shield glass	1		√
9	333-0518	十字槽大盘头自攻螺钉	Philips self-tapping screw	2	only available with assembled parts	
10	B5206113	前挡风玻璃胶条	Front wind-shield glass seal	1		√
11	B5207330	洗涤喷嘴	Washer nozzle	2		√
12	B5207318	洗涤水管E	Washer hose E	1		
13	B5207317	两通水管节接头B	Two-way valve B	1		
14	B5205116	雨刮器摆臂安装螺母塑料盖帽	Wiper arm cap	2		√
15	127-0808	六角螺母和平垫圈组件	Hex nut and flat washer	2	only available with assembled parts	
16	B5205200	雨刮器左摆臂刮刷总成	Left wiper assy.	1		√
16-1	B5205210	雨刮器左摆臂组件	Left wiper arm	1		
16-2	B5205220	雨刮器左刮刷组件	Left wiper brush	1		

5.09 Windsheild

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
17	201-0630	六角头螺栓和垫圈组件	Hex bolt and flat washer	2	only available with assembled parts	
18	B5205100	雨刮器双连杆机构带电机总成	Wiper con-rod with front wiper motor assy.	1		√
19	B5205300	雨刮器右摆臂刮刷总成	Right wiper assy.	1		√
19-1	B5205310	雨刮器右摆臂组件	Right wiper arm	1		
19-2	B5205320	雨刮器右刮刷组件	Right wiper brush	1		
20	B5207100	洗涤壶组件	Washer can	1		√
21	Q1410620L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	3		√
22	B5207313	洗涤水管B	Washer hose B	1		
23	B5207312	两通水管接头A	Two-way valve A	1		
24	B5207311	洗涤水管A	Washer hose A	1		
25	B5207314	三通水管接头	T-valve	1		
26	B5207322	洗涤水管A固定卡扣条	Clip, washer hose A	1		
27	B5207316	洗涤水管D	Washer hose D	1		
28	B5207315	洗涤水管C	Washer hose C	1		
29	B8201100	内后视镜组件		1		
30	Q2140512F30	十字槽螺钉		1		
31	B8201121	内后视镜底座		1		


5.10 Sub-Instrument panel



5.10 Sub-Instrument panel

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5305300B16	中下部面罩总成	Middle-lower panel assy.	1	black	√
1-1	B5305311	中下部面罩本体	Middle-lower panel	1		√
1-2	B5305314	排档面板装饰框	Shift lever cover clamp	1		√
1-3	B5305312	排挡杆皮护套	Shift lever cover	1		√
2	B5305010B15	手刹盖板组件	Park braking panel	1	pale grey	√
3	B5305100B15	副仪表板总成	Sub-instrument panel assy.	1	pale grey	√
3-1	B5305111	副仪表板本体	Sub-instrument panel body	1		√
3-2	B5305114	前杯托盖外板	Outer panel, drinking cup placement	1		√
3-3	B5305115	前杯托盖内板	Outer panel, drinking cup placement	1		√
3-4	B5305117	前杯托盖翻转弹簧	Spring, drinking cup placement	3		√
3-5	B5305116	前杯托盖缓冲垫	Drinking cup placement damper	3		√
3-6	B5305118	前杯托盒隔板	Drinking cup placement spacer	1		√
3-7	B5305200	副仪表板杂物盒总成	Glove box, Sub-instrument panel	1		√
3-8	B5305214	开关锁舌	Box switch	1		√
3-9	B5305430	后烟灰缸总成	Rear ashtray assy.	1		√
4	B5305410B16	前烟灰缸总成	Front ashtray assy.	1	black	√


5.11 Rear bumper



5.11 Rear bumper

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B2804121	后保险杠缓冲块	Rear bumper damper	1		√
2	Q31208	板簧螺母	Nut	2		√
3	B2804131	后保险杠连接支架	Rear bumper bracket	2		√
4	400-1733	塑料卡扣	Plastic clip	4		√
5	B2804111	后保险杠	Rear bumper	1		√
6	Q150B0620T1F30	六角头螺栓	Hex bolt	2		√
7	Q1840820	六角法兰面螺栓	Hex flange bolt	2		√
8	Q40206	大垫圈	Big washer	2		√

5.12 Rear body attachment



5.12 Rear body attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5602311	行李舱后座隔热泡沫	Trunk heat insulator	1		
2	B5602211B16	后座椅饰板	Rear seat decoration	1	black	√
3	400-1868	塑料卡扣	Plastic clip	1		√
4	B5608415	搁物板左扬声器罩	Left speaker cap,shelf	1		
4	B5608416	搁物板右扬声器罩	Right speaker cap,shelf	1		
5	B5608400B15	搁物板护板	Shelf panel	1	pale grey	√
6	B5605113	行李箱缓冲垫	Trunk damper	1		√
7	B5608200B02	行李箱右侧护面组件	Trunk right fender	1	black	√
8	B5608314	行李箱右尾角盖板	Trunk right corner cover	1		√
9	B5600032	右缓冲块	Trunk right damper	1		√
10	Q1410620L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	1		√
11	B5608112	检修盖板	Access panel	1		
12	B5602111B16	后裙板护板	Rear skirt fender	1	black	√
13	Q1840612	六角法兰面螺栓	Hex flange bolt	2		√
14	B5606110	行李箱锁体	Trunk lock	1		√
15	B5606212	行李箱锁拉杆	Trunk lock rod	1		
16	101-0505	六角法兰面螺母	Hex flange nut	2		
17	B5606210	行李箱锁锁芯	Trunk lock cylinder	1		


5.12 Rear body attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
18	B3921012A2	车后标识牌	Rear LOGO"LLL"	1		√
19	B5506210A2	后牌照饰板	License plate trim	1		√
20	B5608511B02	行李箱盖内饰板	Trunk lid interior	1	black	√
21	B5604401	行李箱密封条	Trunk seal	1		√
22	400-540	塑料卡扣	plastic clip	2		√
23	B5506203	中间安装卡扣毡垫	Felt washer	2		
24	B5606424	行李舱锁车内开关卡扣	Trunk buckle	1		√
25	B5101210	备胎固定支架	Spare tyre fixing bracket	1		√
26	B5608322	盖板背部定位支架	Spare tyre bracket	3		
27	B5608320	备胎盖板组件	Spare tyre cover	1		√
28	B5608311B02	行李箱地毯	Trunk carpet	1	black	√
29	B5608313	行李箱左尾角盖板	Trunk right corner cover	1		√
30	B5600031	行李舱盖左缓冲块	Trunk left damper	1		√
31	B5608100B02	行李舱左侧护面组件	Trunk left fender	1	black	√
32	B5606430	加油口锁体	Fuel filler lock	1		
33	B5606423	行李舱锁车内开关拉索	Trunk lid cable	1		
34	B5606420	行李箱\油箱口拉索开关总成	Cable switch,trunk/fuel filler	1		
35	400-1932	塑料卡扣	plastic clip	3		√

5.12 Rear body attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
36	B5606427	加油口锁车内开关拉索	Fuel filler cable	1		
37	B5605011	行李箱左弹力扭杆	Trunk left torsion rod	1		√
38	400-244	塑料卡扣	plastic clip	11		√
39	B5605012	行李箱右弹力扭杆	Trunk right torsion rod	1		√

5.13 Rear seat




5.13 Rear seat

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B7005400B15	后座椅右侧背	Rear seat right side rest	1	woolen, pale grey	√
1	B7005400A2B15	后座椅右侧背	Rear seat right side rest	1	leather, pale grey	√
1	B7005400A3B15	后座椅右侧背	Rear seat right side rest	1	leatherette, pale grey	√
2	B7005200B15	后座椅右靠背	Rear seat right back rest assy.	1	woolen, pale grey	√
2	B7005200A2B15	后座椅右靠背	Rear seat right back rest assy.	1	leather, pale grey	√
2	B7005200A3B15	后座椅右靠背	Rear seat right back rest assy.	1	leatherette, pale grey	√
2-1	B7008100	后座椅头枕	Rear seat pillow	1	woolen	
2-1	B7008100A2	后座椅头枕	Rear seat pillow	1	leather	√
2-2	B7005211	后座椅右靠背本体	Rear seat right back rest	1	woolen	√
2-2	B7005211A2	后座椅右靠背本体	Rear seat right back rest	1	leather	√
3	B7005100B15	后座椅左靠背	Rear seat left back rest assy.	1	woolen, pale grey	√
3	B7005100A2B15	后座椅左靠背	Rear seat left back rest assy.	1	leather, pale grey	√
3	B7005100A3B15	后座椅左靠背	Rear seat left back rest assy.	1	leatherette, pale grey	√
3-1	B7008100	后座椅头枕	Rear seat pillow	1	woolen	
3-1	B7008100A2	后座椅头枕	Rear seat pillow	1	leather	√
3-2	B7005111	后座椅左靠背本体	Rear seat left back rest	1	woolen	
3-2	B7005111A2	后座椅左靠背本体	Rear seat left back rest	1	leather	√
3-3	B7006100	中央扶手总成	Middle handrail	1	woolen	

5.13 Rear seat

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
3-3	B7006100A2	中央扶手总成	Middle handrail	1	leather	✓
4	B7005300B15	后座椅左侧背	Rear seat left side rest	1	woolen, pale grey	✓
4	B7005300A2B15	后座椅左侧背	Rear seat left side rest	1	leather, pale grey	✓
4	B7005300A3B15	后座椅左侧背	Rear seat left side rest	1	leatherette, pale grey	✓
5	B7003000B15	后座椅座垫	Rear seat cushion	1	woolen, pale grey	✓
5	B7003000A2B15	后座椅座垫	Rear seat cushion	1	leather, pale grey	✓
5	B7003000A3B15	后座椅座垫	Rear seat cushion	1	leatherette, pale grey	✓
6	B7007111	左靠背左铰链	Left hinge, rear seat	1		✓
7	B7007300	后座椅靠背中间铰链	Middle hinge, rear seat	1		✓
8	B7007211	右靠背右铰链	Right hinge, rear seat	1		✓


5.14 Front bumper



5.14 Front bumper

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B2803121	前保险杠缓冲块	Front bumper damper	1		√
2	400-1733	塑料卡扣	Plastic clip	1		√
3	Q32006	六角法兰面螺母	Hex flange nut	2		√
4	Q150B620T1F30	六角法兰面螺栓	Hex flange bolt	2		
5	B2803133	带胶头螺栓	Plastic head bolt	2	M6	√
6	Q2706316	六角法兰面螺钉	Hex flange screw	4		√
7	B2803132	前保险杠右连接支架	Right bracket,front bumper	1		√
8	B3921011A2	车前标识牌	Front LOGO"LLL"	1		√
9	B2803150A2	前格栅	Front grille	1		√
10	B2803131	前保险杠左连接支架	Left bracket,front bumper	1		√
11	B2803110	前保险杠组件	Front bumper	1		√
12	Q39748202	簧片螺母	Spring nut	6		√
13	Q40206	大垫圈	Big washer	6		√
14	Q2714825	十字槽凹穴六角头自攻螺钉	Philips self-tapping screw	6		√
15	Q40206	大垫圈	Big washer	2		√
16	Q2215519F31	十字槽盘头子攻螺钉和大垫圈组合件	Philips screw with washer	2		√

5.15 Front body attachment




5.15 Front body attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	400-136	塑料卡扣	Plastic clip	2	cancelled	
2	B5304220	右通风盖板组件	Ventilation right cover	1		√
3	B5304222	风窗右盖板密封条	Ventilation right cover seal	1		√
4	B5304241	前挡风玻璃下流水槽	Front windshield water deflector	1		√
5	B5310120	发动机仓隔热垫	Engine room heat insulator	1		√
6	B5310110	前围隔热垫总成	Front cowl heat insulator	1		√
7	B5302200	仪表板管梁总称	Instrument panel beam assy.	1		√
7-1	B5306230	仪表板横梁组件	Instrument panel beam	1		√
7-2	B5306220	仪表板横梁右固定板组件	Right fixing plate,instrument panel beam	1		√
7-3	B5306270	仪表板横梁拉杆	Drag link,instrument panel beam	1		√
7-4	B5306210	仪表板横梁左固定板组件	Left fixing plate,instrument panel beam	1		√
7-5	B5306250	仪表板横梁左撑杆组件	Left stay bar,instrument panel beam	1		√
7-6	B5306260	仪表板横梁右撑杆组件	Right stay bar,instrument panel beam	1		√
8	B5301019	前围板大堵盖 (R)	Front cowl bigger plug,right	1		
9	B5301012	Φ25堵片	Plug	2	Φ25	√
10	B5301021	前围板小堵盖	Front cowl smaller plug	2		
11	B5301018	前围板大堵盖 (L)	Front cowl bigger plug,left	1		
12	B5307112	Φ10橡胶堵盖	Rubber plug	3	Φ10	√

5.15 Front body attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
13	B5301011	前围Φ18橡胶堵盖	Front cowl rubber plug	2	Φ18	√
14	B5304212	风窗左盖板密封条	Ventilation left cover seal	1		√
15	B5304210	右通风盖板组件	Ventilation left cover	1		√
16	B5304231	风窗盖板膨胀卡扣	Ventilation cover cap	2		
17	B8402810	发动机仓盖隔热垫	Engine hood heat insulator	1		√

5.16 Driver's seat




5.16 Driver's seat

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B6800100B15	驾驶员座椅总成	Front passenger's seat assy.	1	woolen,pale grey,without waist adjuster	√
1	B6800100A2B15	驾驶员座椅总成	Front passenger's seat assy.	1	woolen,pale grey,with waist adjuster	√
1	B6800100A3B15	驾驶员座椅总成	Front passenger's seat assy.	1	leather,pale grey,with waist adjuster	
1	B6800100A4B15	驾驶员座椅总成	Front passenger's seat assy.	1	leatherette,pale grey,with waist adjuster	√
1	B6800100B1B15	驾驶员座椅总成	Front passenger's seat assy.	1	leather,pale grey,with waist adjuster, heater	√
1-1	B6808100	前座椅头枕	Front seat pillow	1	woolen	
1-1	B6808100A2	前座椅头枕	Front seat pillow	1	leather	√
1-2	B6802116	驾驶员座椅右盖板	Driver's seat cap,right	1		√
1-3	B6802119	调腰器提钮盖板	Waist adjuster cap	1		√
1-4	B6802115	驾驶员座椅左盖板	Driver's seat cap,left	1		√
1-5	B6802118	座椅靠背角度提钮盖板	Backrest adjuster cap, driver's seat	1		√
1-6	B6802117	座垫高度调节旋钮盖板	Driver's Seat cushion adjuster cap	1		√
1-7	B6804000	驾驶员座滑轨总成	Driver's seat slide	1		√
1-8	B6802111B15	驾驶员座椅下护板	Driver's seat bottom fender	1	pale grey	√
1-9	B6802114B15	驾驶员座椅后脚盖	Driver's seat stand,rear	1	pale grey	√
1-10	B6802113B15	驾驶员座椅前脚盖	Driver's seat stand,front	1	pale grey	√
1-11	B6800110	驾驶员座本体总成	Driver's seat body	1		√
2	Q2101030TF2	内六角花形圆柱头螺钉	Inner hex screw	4		√

5.16 Driver's seat

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
3	B5811130B15	左前安全带锁扣总成	Front left safety belt buckle	1	pale grey	√
3	B5811130A2B15	左前安全带锁扣总成	Front left safety belt buckle	1	pale grey, E-mark	√
4	231-7/1622	六角法兰面螺栓	Hex flange bolt	1		


5.17 Front passenger's seat



5.17 Front passenger's seat

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B6900100B15	副驾驶座椅总成	Front passenger's seat assy.	1	woolen,pale grey	√
1	B6900100A2B15	副驾驶座椅总成	Front passenger's seat assy.	1	leather,pale grey	√
1	B6900100A3B15	副驾驶座椅总成	Front passenger's seat assy.	1	leatherette,pale grey	√
1-1	B6808100	前座椅头枕	Front seat pillow	1	woolen	
1-1	B6808100A2	前座椅头枕	Front seat pillow	1	leather	√
1-2	B6900110	副驾驶员座本体总成	Front passenger's seat body	1		√
1-3	B6902115	副驾驶员座椅左盖板	Front passenger's seat cap,left	1		√
1-4	B6902116	副驾驶员座椅右盖板	Front passenger's seat cap,right	1		√
1-5	B6902118	座椅靠背角度提钮盖板	Front passenger's seat backrest adjuster cap	1		√
1-6	B6902111B15	副驾驶座椅下护板	Front passenger's seat bottom fender	1	pale grey	√
1-7	B6904000	副驾驶员座滑轨总成	Front passenger's seat slide	1		√
1-8	B6902113B15	副驾驶座椅前脚盖	Front passenger's seat stand,front	1	pale grey	√
1-9	B6902114B15	副驾驶座椅后脚盖	Front passenger's seat stand,rear	1	pale grey	√
2	Q2101030TF2	内六角花形圆柱头螺钉	Inner hex screw	4		√
3	B5811230B15	右前安全带锁扣总成	Front right safety belt buckle	1	pale grey	√
3	B5811230A2B15	右前安全带锁扣总成	Front right safety belt buckle	1	pale grey, E-mark	√
4	231-7/1622	六角法兰面螺栓	Hex flange bolt	1		

5.18 Rear right door attachment



5.18 Rear right door attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B6205230A2	右后侧车门门把手总成	Outer handle assy, rear right door	1		√
1-1	B6105131	侧车门门把手	Outer handle	1		√
1-2	B6205222	右后侧车门门把手B	Door outer handle B, rear right door	1		√
1-3	B6105133	侧门门把手塑料垫圈B	Plastic ring B, door handle	1		√
1-4	B6105132	侧门门把手塑料垫圈A	Plastic ring A, door handle	1		√
1-5	B6205225	右后侧车门门把手座	Handle seat, rear right door	1		√
2	B6200220	右后侧车门活动导轨总成	Glass rail assy, rear right door	1		√
2-1	B6200221	右后侧车门玻璃活动导轨	Glass rail, rear right door	1		√
2-2	B6200222	右后侧车门玻璃活动导轨上支架	Glass rail bracket, rear right door	1		√
2-3	321-0508	十字槽沉头螺钉	Philips screw	1		
2-4	B6200227	右后车门导轨胶套	Glass rail sleeve, rear right door	1		√
3	B6203212	右后门三角玻璃	Triangular glass, rear right door	1		√
4	Q1840610	六角法兰面螺栓	Hex flange bolt	1		√
5	Q2400820	十字槽沉头螺钉和锥形锁紧垫圈组合	Philips screw and washer	2		√
6	B6109112	侧车门缓冲块	Door damper	2		√
7	B6105141	侧车门锁扣组件	Door buckle component	1		√
8	B6207213	右后侧车门三角玻璃密封条	Triangular glass seal, rear right door	1		√
9	B6207211	右后侧车门玻璃泥槽	Glass seal, rear right door	1		√


5.18 Rear right door attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
10	B6207214	右后侧车门密封条	Rear right door seal	1		√
11	B6107114	侧车门密封条卡扣A	Door seal clip A	15		√
12	B6202217	右后门扶手软垫板	Inner handrail cushion, rear right door	1		
13	B6202118	后门螺钉堵盖	Rear right door screw cap	1		√
14	Q2734216	十字槽大半圆头自攻螺钉	Philips self-tapping screw	1		√
15	B3746400	右后门扶手板开关总成	Inner handrail with switches, rear right door	1		√
16	Q2734216	十字槽盘半圆头自攻螺钉	Philips self-tapping screw	1		√
17	B6105400	右侧车门内扣手总成	Inner handle, rear right door	1		√
18	B6202211	右后门内护板装饰条	Interior trim, rear right door	1		√
19	B6202210B97	右后门内护板总成	Rear right door interior	1	grey, upper deep lower pale	√
20	400-540	塑料卡扣	Plastic clip	8		√
21	B6202020	右后门防雨帘组件	Rain shield, rear right door	1		√
22	Q2540508	十字沉头螺钉	Philips screw	2		√
23	Q398B03	塑料螺母	Plastic nut	2		√
24	Q1840610	六角法兰面螺栓	Hex flange bolt	4		√
25	B6206220	右后侧车门下铰链组件	Lower hinge, rear right door	1		√
26	Q1840820	六角法兰面螺栓	Hex flange bolt	4		√
27	Q1840816T1F30	六角法兰面螺栓	Hex flange bolt	1		√

5.18 Rear right door attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
28	B6209100	后车门限位器	Rear door stopper	1		√
29	Q1840820	六角法兰面螺栓	Hex flange bolt	4		√
30	B6206210	右后侧门上铰链组件	Upper hinge, rear right door	1		√
31	B6203200	右后侧车门车窗玻璃	Rear right door glass	1		√
32	B6205210	右后门锁体	Rear door lock	1		√
32	B6205210B1	右后门锁体	Rear door lock	1	central lock	√
33	B6207212	右后侧车门玻璃外切水条	Weather Strip, rear right door	1		√
34	B6204200	右后侧车门玻璃升降器总成	Glass lifter, rear right door	1		√

5.19 Front right door



5.19 Front right door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B6105230A2	右前侧车门门把手总成	Outer handle assy, front right door	1		√
1-1	B6105131	侧车门门把手	Outer handle	1		√
1-2	B6105234	右前侧车门门把手座	Handle seat, front right door	1		√
1-3	B6105133	侧车门门把手塑料垫圈B	Plastic ring B, door handle	1		√
1-4	B6105132	侧车门门把手塑料垫圈A	Plastic ring A, door handle	1		√
2	B6103200B1	右前侧车门车窗玻璃	Front right door glass	1		√
3	B6100220	右前侧车门活动导轨总成	Glass rail assy, front right door	1		√
3-1	B6100221	右前侧车门玻璃活动导轨	Glass rail, front right door	1		√
3-2	B6100222	右前侧车门玻璃活动导轨下支架	Glass rail bracket, front right door	1		√
3-3	Q1840610	六角法兰面螺栓	Hex flange bolt	1		√
4	Q1840612T1F30	六角法兰面螺栓	Hex flange bolt	2		√
5	B6104200B1	右前侧车门玻璃升降器总成	Glass lifter, front right door	1		√
6	B6107212	右前侧车门玻璃外切水条	Weather Strip, front right door	1		√
7	B6105210	右前侧门锁体	Front right door lock	1	DX	√
7	B6105210B1	右前侧门锁体	Front right door lock	1	LX, EX	√
8	Q2560620F13	十字槽半沉头螺钉	Philips screw	3		√
9	B8202200	右外后视镜总成	Right wing mirror	1	Dongguang	√
9	B8202200B1	右外后视镜总成	Right wing mirror	1	Donnelly	√


5.19 Front right door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
10	Q2400820	十字槽沉头螺钉和锥形锁紧垫圈组合	Philips screw and washer	2		√
11	B6105141	侧车门锁扣组件	Door buckle component	1		√
12	B6109112	侧车门缓冲块	Door damper	3		√
13	Q1840610	六角法兰面螺栓	Hex flange bolt	1		√
14	B6105318	塑料螺母	Plastic nut	1		√
15	309-3516	十字槽盘头螺钉和平垫圈组合件	Philips screw with washer	1		
16	Q1840610	六角法兰面螺栓	Hex flange bolt	8		√
17	Q1840616T1F30	六角法兰面螺栓	Hex flange bolt	2		√
18	Q1840816T1F30	六角法兰面螺栓	Hex flange bolt	1		√
19	B6109100	前车门限位器	Front door stopper	1		√
20	B6107211	右前侧车门玻璃泥槽	Glass seal,front right door	1		√
21	B6107213	右前侧车门密封条	Front right door seal	1		√
22	B6107114	侧车门密封条卡扣A	Door seal clip A	15		√
23	B6102020	右前门防雨帘组件	Rain shield,front right door	1		√
24	400-540	塑料卡扣	Plastic clip	8		√
25	B6102214	右前门上装饰条	Interior trim,front right door	1		√
26	B6102217	右前门扶手垫板	Inner handrail cushion,front right door	1		
27	Q2734216	十字槽盘半圆头自攻螺钉	Philips self-tapping screw	1		√

5.19 Front right door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
28	B6102119	前门螺钉堵盖	Front door screw cap	1		√
29	B3746200	右前门扶手板开关	Inner handrail with switches,front right door	1		√
30	309-3516	十字槽盘头螺钉和平垫圈组合件	Philips screw with washer	1		
31	B6105400	右侧车门内扣手总成	Inner handle, front right door	1		√
32	B6102210B97	右前门内护板总成	Front right door interior	1	grey, upper deep lower pale	√

5.20 Rear left door



5.20 Rear left door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B6205130A2	左后侧车门门把手总成	Outer handle assy, rear left door	1		√
1-1	B6105131	侧车门门把手	Outer handle	1		√
1-2	B6205125	左后侧车门门把手座	Handle seat, rear left door	1		√
1-3	B6105132	侧门门把手塑料垫圈A	Plastic ring B, door handle	1		√
1-4	B6105133	侧门门把手塑料垫圈B	Plastic ring A, door handle	1		√
1-5	B6205122	左后侧车门门把手B	Door outer handle B, rear left door	1		√
2	B6200120	左后侧车门活动导轨总成	Glass rail assy, rear left door	1		√
2-1	B6200121	左后侧车门玻璃活动导轨	Glass rail, rear left door	1		√
2-2	B6200127	左后车门导轨胶套	Glass rail sleeve, rear left door	1		√
2-3	B6200122	左后侧车门玻璃活动导轨上支架	Glass rail bracket, rear left door	1		√
2-4	Q2540608	十字槽沉头螺钉	Philips screw	1		
3	B6204100	左后侧车门玻璃升降器总成	Glass lifter, rear left door	1		√
4	B6207112	左后侧车门玻璃外切水条	Weather Strip, rear left door	1		√
5	B6205110	左后门锁体	Rear left door lock	1		√
5	B6205110B1	左后门锁体	Rear left door lock	1	central locking	√
6	B6203100	左后侧车门车窗玻璃	Rear left door glass	1		√
7	B6206110	左后侧门上铰链组件	Upper hinge, rear left door	1		√
8	Q1840820	六角法兰面螺栓	Hex flange bolt	8		√


5.20 Rear left door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
9	Q1840816T1F30	六角法兰面螺栓	Hex flange bolt	1		√
10	B6209100	后车门限位器	Rear door stopper	1		√
11	Q1840616T1F30	六角法兰面螺栓	Hex flange bolt	2		√
12	B6206120	左后侧车门下铰链组件	Lower hinge,rear left door	1		√
13	Q1840610	六角法兰面螺栓	Hex flange bolt	4		√
14	Q398B03	塑料螺母	Plastic nut	2		√
15	Q2540508	十字沉头螺钉	Philips screw	2		√
16	B6202010	左后门防雨帘组件	Rain shield,rear left door	1		√
17	400-540	塑料卡扣	Plastic clip	7		√
18	B6202110B97	左后门内护板总成	Rear left door interior	1	grey, upper deep lower pale	√
19	B6105300	左侧车门内扣手总成	Inner handle, left door	1		√
20	Q2734216	十字槽大半圆头自攻螺钉	Philips self-tapping screw	1		√
21	B3746300	左后门扶手板开关总成	Inner handrail with switches,rear left door	1		√
22	Q2734216	十字槽半圆头自攻螺钉	Philips self-tapping screw	1		√
23	B6202118	后门螺钉堵盖	Rear door screw cap	1		√
24	B6202117	左后门扶手软垫板	Inner handrail cushion,rear left door	1		
25	B6202111	左后门内护板装饰条	Interior trim,rear left door	1		√
26	B6107114	侧车门密封条卡扣A	Door seal clip A	15		√

5.20 Rear left door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
27	B6207114	左后侧车门密封条	Front right door seal	1		√
28	B6207111	左后侧车门玻璃泥槽	Glass seal, rear left door	1		√
29	B6207113	左后侧车门三角玻璃密封条	Triangular glass seal, rear left door	1		√
30	B6105141	侧车门锁扣组件	Door buckle component	1		√
31	B6109112	侧车门缓冲块	Door damper	2		√
32	Q2400820	十字槽沉头螺钉和锥形锁紧垫圈组合	Philips screw and washer	2		√
33	224-0616	六角头头部带十字槽螺栓	Philips hex bolt	1		
34	B6203112	左后门三角玻璃	Triangular glass, rear left door	1		√

5.21 Front left door



5.21 Front left door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B6105130A2	左前侧车门门把手总成	Outer handle assy, rear left door	1		√
1-1	B6105134	左前侧车门门把手座	Handle seat, rear left door	1		√
1-2	B6105132	侧车门门把手塑料垫圈A	Plastic ring B, door handle	1		√
1-3	B6105133	侧车门门把手塑料垫圈B	Plastic ring A, door handle	1		√
1-4	B6105131	侧车门门把手	Outer handle	1		√
2	B6103100B1	左前侧车门车窗玻璃	Front left door glass	1		√
3	B6100120	左前侧车门活动导轨总成	Glass rail assy, front left door	1		√
3-1	B6100121	左前侧车门玻璃活动导轨	Glass rail, front left door	1		√
3-2	B6100122	左前侧车门玻璃活动导轨下支架	Glass rail bracket, front left door	1		√
3-3	224-0616	六角头头部带十字槽螺栓	Philips hex bolt	1		
4	Q1840610	六角法兰面螺栓	Hex flange bolt	2		√
5	B6104100B1	左前侧车门玻璃升降器总成	Glass lifter, front left door	1		√
6	B6107112	左前侧车门玻璃外切水条	Weather Strip, front left door	1		√
7	Q2560620F13	十字槽半沉头螺钉	Philips screw	3		√
8	B6105110	左前侧门锁体	Front left door lock	1	DX	√
8	B6105110B1	左前侧门锁体	Front left door lock	1	LX, EX	√
9	B8202100	左外后视镜总成	Left wing mirror	1	Dongguang	√
9	B8202100B1	左外后视镜总成	Left wing mirror	1	Donnelly	√


5.21 Front left door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
10	B6109100	前车门限位器	Front door stopper	1		√
11	Q1840816T1F30	六角法兰面螺栓	Hex flange bolt	1		√
12	Q1840616T1F30	六角法兰面螺栓	Hex flange bolt	2		√
13	Q1840610	六角法兰面螺栓	Hex flange bolt	9		√
14	B6105318	塑料螺母	Plastic nut	1		√
15	309-3516	十字槽盘头螺钉和平垫圈组合件	Philips screw with washer	1		
16	224-0616	六角头头部带十字槽螺栓	Philips hex bolt	2		
17	B6109112	侧车门缓冲块	Door damper	3		√
18	B6105141	侧车门锁扣组件	Door buckle component	1		√
19	Q2400820	十字槽沉头螺钉和锥形锁紧垫圈组合	Philips screw and washer	2		√
20	B6107111	左前侧车门玻璃泥槽	Glass seal,front left door	1		√
21	B6107114	侧车门密封条卡扣A	Door seal clip A	15		√
22	B6107113	左前侧车门密封条	Front left door seal	1		√
23	B6102010	左前门防雨帘组件	Rain shield,front left door	1		√
24	400-540	塑料卡扣	Plastic clip	8		√
25	B6102110B97	左前门内护板总成	Front left door interior	1	grey, upper deep lower pale	√
26	B6102114	左前门上装饰条	Interior trim,front left door	1		√
27	B6105300	左侧车门内扣手总成	Inner handle, left door	1		√

5.21 Front left door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
28	309-3516	十字槽盘头螺钉和平垫圈组合件	Philips screw with washer	1		
29	B3746100	左前门扶手板开关总成	Inner handrail with switches,front left door	1		√
30	Q2734216	十字槽半圆头自攻螺钉	Philips self-tapping screw	1		√
31	B6102119	前门螺钉堵盖	Front door screw cap	1		√
32	B6102117	左前门扶手垫板	Inner handrail cushion,front left door	1		


5.22 Glove box



5.22 Glove box

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5303100B15	仪表板杂物箱总成	Glove box assy.	1	pale grey	√
1-1	B5303112	杂物箱加强面板	Glove box panel	1		
1-2	B5306020	气体阻尼器	Glove box damper	1		√
1-3	B5303110	杂物箱锁组件	Glove box lock	1		
1-3-1	B5303117	杂物箱锁拉手板	Glove box handle	1		
1-3-2	B5303114	杂物箱锁本体	Glove box lock body	1		
1-3-3	B5303115	杂物箱锁舌	Glove box locking dog	1		
1-4	B5303111	物箱本体	Glove box body	1		


5.23 LOGO



5.23 LOGO

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3921011A2	车前标识牌	Front LOGO"LLL"	1		√
2	B3921012A2	车后标识牌	Rear LOGO"LLL"	1		√
3	B3102513	轮毂中心标牌	Wheel LOGO	4		
4	B3921015	车尾车型标识牌	Rear model LOGO"LF7162"	1	for Tritec engine	
5	B3921019A2	车尾车型标识 II	Rear model LOGO"620"	1		
6	L3921013B1	车尾车名标识牌	Rear LOGO"LIFAN"	1		√
7	L3921018	车侧门标牌	Side LOGO"1.6L"	1		√
8	BAC3921015	车尾车型标识牌	Rear model LOGO"LF7162"	1	for LF481 engine	

5.24 Instrument panel




5.24 Instrument panel

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5306125B14	副安全气囊盖板	Passengers airbag panel	1	deep grey, for configuration without passenger's airbag	√
2	B5306117	光敏传感器堵盖	Cap, optical sensor	1		
3	B5306118	阳光传感器堵盖	Cap, sunlight sensor	1		
4	Q1840616T1F30	六角法兰面螺栓	Hex flange bolt	6		√
5	B5306110B14	仪表板上护板	Instrument panel fender,upper	1	deep grey	√
6	Q2734816F30	十字槽大半圆头自攻螺钉	Philips self-tapping screw	2		√
7	B5306011B16	组合仪表罩	Instrument cluster cover	1	black	√
8	Q2734216	十字槽大半圆头自攻螺钉	Philips self-tapping screw	2		√
9	400-0243	塑料卡扣	Plastic clip	2		√
10	B5306137	组合仪表安装卡簧	Instrument cluster snap spring	2		
11	B5306820C03	仪表板右装饰条组件	Instrument panel trim assy,right	1	peachwood	√
11-1	B5306821	仪表板右装饰条	Instrument panel trim,right	1		
11-2	B5305315	塑料卡扣	Plastic clip	12		
12	B5306810C03	仪表板左装饰条组件	Instrument panel trim assy,left	1	peachwood	√
12-1	B5306811	仪表板左装饰条	Instrument panel trim,left	1		
13	B5306130B15	仪表板下护板	Instrument panel fender,lower	1	pale grey	√
14	Q2706316	六角法兰面螺钉	Hex flange screw	3		√
15	B5306711B14	转向柱上护罩	Steering pillar shield upper	1	deep grey	√

5.24 Instrument panel

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
16	B5306712B14	转向柱下护罩	Steering pillar shield lower	1	deep grey	√
17	Q2734816	十字槽大半圆头自攻螺钉	Philips self-tapping screw	2		√
18	Q2214219	十字槽盘头自攻螺钉和大垫圈组合	Philips screw with washer	1		√
19	B5306132	票据盒	Notes box	1		√
20	B5306134	票据盒缓冲胶套	Notes box damper	2		
21	B5306133	票据盒锁紧簧片	Notes box locker	1		
22	B5306138	杂物箱锁扣	Glovebox buckle	1		
	B5306000	仪表台总成	Instrument panel assy.	1		

6.01 Air conditioner assy. (for Tritec engine)




6.01 Air conditioner assy. (for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B8105100	冷凝器总成	Condensor	1		√
2	Q1400625	六角头螺栓与平垫圈组合件	Hex bolt and flat washer	2		√
3	B8108331	高压硬管加注口盖	Filler cap,high-pressure tube	1		√
4	B8108300	空调高压硬管总成	High-pressure tube	1		√
5	B8108100	空调高压软管总成	High-pressure hose	1		√
6	B8108322	空调高压硬管支架A	High-pressure tube bracket A	1		√
7	Q184A0612	六角法兰面螺栓	Hex flange bolt	1		√
8	Q2300512	十字槽盘头螺钉与平垫圈组合件	Philips screw with washer	1		√
9	B8108500	空调低压软管总成	Low-pressure hose	1		√
10	B8108310	空调高低压管夹	Clamp	1		√
11	Q1400616	六角头螺栓与平垫圈组合件	Hex bolt and flat washer	1		√
12	Q340B06	1型六角螺母	Hex nut	2		√
13	B8108510	空调高低压管支架总成	Pipe bracket assy.	1		√
13-1	B8108513	双头缓冲螺栓	Stud	1		√
13-2	B8108512	支撑板	Support plate	1		√
13-3	B8108514	空调高低压管支架	Pipe bracket	1		√
14	B8111014	高低压管隔离圈	Separate plate,H/L pressure pipes	1		√
15	127-0607	六角螺母和平垫圈组合件	Hex nut and flat washer	5		√

6.01 Air conditioner assy. (for Tritec engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
16	B8100100	HVAC总成	HVAC assy.	1		√
17	B8111012	暖气进/出管隔离圈	Separate plate,I/O heater pipes	1		√
18	Q67525	A型蜗杆式弹性环箍	Hoop	2		√
19	B8108013	暖风机出水管	Heater outtake pipe	1		√
20	B8108012	暖风机进水管	Heater intake pipe	1		√
21	Q67525	A型蜗杆式弹性环箍	Hoop	2		√
22	Q1840895	六角法兰面螺栓	Hex flange bolt	1		
23	L8103101B1	空调压缩机总成支架	Compressor bracket	1		
24	Q1410830	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and washers	2		√
25	LAA8103100B1	空调压缩机总成	Compressor	1		√
26	Q1410840	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and washers	2		
27	Q1400825	六角头螺栓与平垫圈组合件	Hex bolt and flat washer	2		√
28	Q184A0612	六角法兰面螺栓	Hex flange bolt	2		√


6.02 Ventilations



6.02 Ventilations

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5306415	除霜风口中段风道	Defroster ventilation,middle part	1		
2	B5306414	左右风口风管和除霜风口风道	L/R ventilation assy.	1		
3	B5306424	风道左右风口连接卡扣	Clip	2		√
4	B8121431	乘客席左风管前段	Left ventilation fore part,Passenger side	1		√
5	B8121432	乘客席左风口后段	Left ventilation rear part,Passenger side	1		√
6	B8121442	乘客席右风口后段	Right ventilation rear part,Passenger side	1		√
7	B8121441	乘客席右风管前段	Right ventilation fore part,Passenger side	1		√
8	B5306411	连接卡扣	Connect clip	2		
9	B5306412	中风口风管	Middle ventilation	1		
10	Q2213513	左右风管连接螺钉	Connect screw	2		


6.03 Evaporator



6.03 Evaporator

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B8107100	蒸发器暖风机总成	Evaporator heater	1		
1-1	B8114200	蒸发器温度传感器	Evaporator Temperature sensor	1		√
1-2	B8106010	膨胀阀	Expansion Valve	1		√
1-3	B8107110	蒸发器芯子组件	Evaporator core	1		√
1-4	B3745300	吹风模式执行器	Actuator,blow Mode	1		√
1-5	B3745400	冷暖风执行器安装组件	Actuator assy,A/C Mode	1		√
1-5-1	B3745411	冷暖风执行器	Actuator,A/C Mode	1		√
1-5-2	B3745412	冷暖风执行器安装支架	Actuator bracket	1		√
1-6	Q2706316A	六角法兰面自攻螺钉	Hex flange tapping screw	5		√
1-7	B8107140	蒸发器左壳体	Evaporator shell,L	1		√
1-8	B8107150	蒸发器右壳体	Evaporator shell,R	1		√
1-9	B8107160	暖风机散热器总成	Heater radiator	1		√
1-10	Q2704216A	十字槽沉头螺钉	Philips screw	9		√
1-11	B8107151	暖风机散热器进出管管夹	Clamp	1		√

6.04 Blower




6.04 Blower

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B8104100	鼓风机总成	Blower assy.	1		
1-1	B3745100	鼓风机电机	Blower motor	1		√
1-2	B8121150	进风箱上壳体	Bellow shell,upper	1		√
1-3	B8121160	进风箱下壳体	Bellow shell,lower	1		√
1-4	B3745200	内外循环风执行器	Actuator,blower	1		√
1-5	B8211170	空滤器	Air filter,blower	1		√
1-6	B3745180	空调鼓风机调速模块	Governor,blower	1		√
1-7	Q2704216A	十字槽沉头螺钉	Philips screw	5		√
1-8	Q2706316A	六角法兰面自攻螺钉	Hex flange tapping screw	8		√
	B8121100	进风箱总成	Bellow assy.	1		

LF7162C spare parts catalogue

(Version:200904)

1.01 气缸盖罩 Cylinder head cover




1.01 气缸盖罩 Cylinder head cover

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	LF479Q1-1003200A1	气缸盖罩总成	Cylinder head cover assy	1		√
1-1	LF479Q1-1003210A	气缸盖罩	Cylinder head cover	1		
1-2	LF479Q1-1003202A	气缸盖罩通气嘴	Nozzle,cylinder head cover	1		
1-3	LF479Q1-1003212A	挡油板（I）	Oil baffle I	1		√
1-4	LF479Q1-1003213A	挡油板（II）	Oil baffle II	1		√
1-5		挡油板安装螺栓	Bolt	11		
2	LF479Q1-1003230A	加油口盖总成	Oil filler cap assy.	1		
2-1	LF479Q1-1003201A	加油口盖	Cap,oil filler	1		√
2-2	LF479Q1-1003204A	加油口盖密封垫	Gasket	1		
	LF479Q1-3707000A	高压阻尼线总成	Ignition cable suite			
3	LF479Q1-3707100A	高压阻尼线（I）	Ignition cable 1	1		√
4	LF479Q1-3707200A	高压阻尼线（II）	Ignition cable 2	1		√
5	LF479Q1-3707300A	高压阻尼线（III）	Ignition cable 3	1		√
6	LF479Q1-3707400A	高压阻尼线（IV）	Ignition cable 4	1		√
7	LF479Q1-1014011A	PCV阀通气软管	PCV vent hose	1		√
8	LBA1109012	长通气软管	Longe hose	1		√
9	LF479Q1-1014100A	PCV阀总成	PCV assy.	1		√
10	LF479Q1-1003015A	气缸盖罩密封垫	Gasket, cylinder head cover	1		√

1.01 气缸盖罩 Cylinder head cover

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
11	LF479Q1-1003018A	气缸盖罩螺母	Cylinder head cover nut	4	M6	√
12	LF479Q1-1003017A	气缸盖罩螺栓密封垫	Cylinder head cover bolt gasket	4		√
13	LF479Q1-1014014A	PCV阀密封圈	PCV seal	1		√
	LF479Q1-1003203A	汽缸盖罩油封	Seal,cylinder head cover	4		√

1.02 气缸盖 Cylinder head



1.02 气缸盖 Cylinder head


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-1003100A	气缸盖总成	Cylinder Head assy.	1		√
1-1	LF481Q1-1003101A	气缸盖体	Cylinder Head			
1-2	LF479Q1-1003109A	排气凸轮轴轴承盖 I	Exhaust Camshaft Bearing Cap 1	1	△	
1-3	LF479Q1-1003110A	排气凸轮轴轴承盖 II	Exhaust Camshaft Bearing Cap 2	1	△	
1-4	LF479Q1-1003111A	排气凸轮轴轴承盖 III	Exhaust Camshaft Bearing Cap 3	1	△	
1-5	LF479Q1-1003112A	排气凸轮轴轴承盖 IV	Exhaust Camshaft Bearing Cap 4	1	△	
1-6	LF479Q1-1003113A	排气凸轮轴轴承盖 V	Exhaust Camshaft Bearing Cap 5	1	△	
1-7	LF479Q1-1003104A	进气凸轮轴轴承盖 I	Intake Camshaft Bearing Cap 1	1	△	
1-8	LF479Q1-1003105A	进气凸轮轴轴承盖 II	Intake Camshaft Bearing Cap 2	1	△	
1-9	LF479Q1-1003106A	进气凸轮轴轴承盖 III	Intake Camshaft Bearing Cap 3	1	△	
1-10	LF479Q1-1003107A	进气凸轮轴轴承盖 IV	Intake Camshaft Bearing Cap 4	1	△	
1-11	LF479Q1-1003108A	进气凸轮轴轴承盖 V	Intake Camshaft Bearing Cap 5	1	△	
2	LF479Q1-1003102A	碗形堵塞 I	Bowl Plug 1	1		
3	LF479Q1-1003016A	半圆塞	Semi-Circle Plug	1		√
4	LF479Q1-1300017A	出水管	Outlet tube	1		√
5	Q1840820	六角法兰面螺栓	Hex flange bolt	2		√
6	LF481Q1-1003300A	气缸盖密封垫总成	Gasket	1		√
7	LF479Q1-1003013A	气缸盖连接组合螺栓（排气侧）	Cylinder head bolt(exhaust)	5	1*1.25*18	√

1.02 气缸盖 Cylinder head

[illegible]

Δ =set on cylinder Head, can't be ordered separately


1.03 气缸体 Cylinder block



1.03 气缸体 Cylinder block

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-1307012A	水泵O型密封圈	Water Pump O-Ring	1	φ3*33.5	√
2	LF479Q1-3612200A	爆震传感器	Knock Sensor	1		√
3	LF481Q1-1002100A	曲轴箱总成	Crank case assy.	1		√
4	LF479Q1-1005019A	曲轴后油封	Crankshaft rear seal	1		√
5	Q1841016	六角螺栓	Hex bolt	2		√
6	LF479Q1-1701012A	变速器挡板	Transimission Plate	1		√
7	Q1840616	六角法兰面螺栓	Hex flange bolt	6		√
8	LF479Q1-1005018A	曲轴后端盖	Crankshaft rear cover	1		√
9	Q5220614	曲轴后端盖定位销	Crankshaft rear cover pin	2		√
10	LF479Q1-1005017A	曲轴后端盖密封垫	Crankshaft rear gasket	1		√
11	LF479Q1-3818100A	机油压力报警器	Oil pressure warner	1		√
12	LF479Q1-1017100A	机油滤清器总成	Oil Filter Assy	1		√
13	LF479Q1-1002107A	凸轮轴轴承盖紧固螺栓	Crank case bearing cap bolt	10		
14	LF479Q1-1017011A	机油滤清器连接管	Oil Filter connecting pipe	1		√

1.04 配气机构 Valve timing mechanism



1.04 配气机构 Valve timing mechanism

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-1003114A	凸轮轴主轴承盖紧固螺栓	Crank case bearing cap bolt	16		
2	LF481Q1-1003019A	汽缸盖罩双头组合螺栓	Cylinder head cover thru-stud	4		
3	LF481Q1-1006101A	进气凸轮轴	Intake Camshaft	1		√
4	LF479Q1-1007018A	进气门油封	Intake valve seal	8		√
5	LF479Q1-1007021A-1	填隙片	Shim	demand	$235 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-2	填隙片	Shim	demand	$240 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-3	填隙片	Shim	demand	$245 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-4	填隙片	Shim	demand	$250 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-5	填隙片	Shim	demand	$255 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-6	填隙片	Shim	demand	$260 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-7	填隙片	Shim	demand	$265 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-8	填隙片	Shim	demand	$270 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-9	填隙片	Shim	demand	$275 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-10	填隙片	Shim	demand	$280 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-11	填隙片	Shim	demand	$285 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-12	填隙片	Shim	demand	$290 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-13	填隙片	Shim	demand	$295 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-14	填隙片	Shim	demand	$300 \times (10^{-2}) \text{ mm}$	√

1.04 配气机构 Valve timing mechanism


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
5	LF479Q1-1007021A-15	填隙片	Shim	demand	$305 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-16	填隙片	Shim	demand	$310 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-17	填隙片	Shim	demand	$315 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-18	填隙片	Shim	demand	$320 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-19	填隙片	Shim	demand	$325 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-20	填隙片	Shim	demand	$330 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-21	填隙片	Shim	demand	$335 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-22	填隙片	Shim	demand	$340 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-23	填隙片	Shim	demand	$345 \times (10^{-2}) \text{ mm}$	√
5	LF479Q1-1007021A-24	填隙片	Shim	demand	$350 \times (10^{-2}) \text{ mm}$	√
6	LF479Q1-1007019A	挺柱	Tappet	16		√
7	LF479Q1-1007016A	气门锁片	Valve Lock	32		√
8	LF479Q1-1007015A	气门弹簧座	Valve Spring Retainer	16		√
9	LF479Q1-1007013A	气门弹簧	Valve Spring	16		√
10	LF479Q1-1007017A	排气门油封	Exhaust Valve Seal	8		√
11	LF479Q1-1003121A	气门导管	Valve Guide	16	△	
12	LF479Q1-1007014A	气门弹簧底座	Valve Spring Seat	16		√
13	LF481Q1-1007011A	排气门	Exhaust Valve	8		√

1.04 配气机构 Valve timing mechanism

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
14	LF481Q1-1007012A	进气门	Intake Valve	8		√
15	LF479Q1-1006202A	排气正时齿轮	Exhaust timing gear	1		√
16	LF481Q1-1006201A	排气凸轮轴	Exhaust Camshaft	1		√
17	LF479Q1-1006203A	排气齿轮卡环	Exhaust gear snap ring	1		√
18	LF479Q1-1006011A	凸轮轴油封	Camshaft shaft seal	1		√
19	LF479Q1-1006203A	排气齿轮卡环	Exhaust gear snap ring	1		√
20	LF479Q1-1006104A	波形垫	Wave Washer	1		√
21	LF479Q1-1006106A	进气正时齿轮副齿	Intake timing sub gear	1		√
22	LF479Q1-1006103A	消隙弹簧	Backlash spring	1		√
23	LF479Q1-1006105A	进气正时齿轮	Intake timing gear	1		√
	LF479Q1-1006107A	进气齿轮卡环	Exhaust gear snap ring	1		√

△=set on cylinder Head, can't be ordered separately

1.05 曲轴与活塞连杆 Crankshaft and piston rod




1.05 曲轴与活塞连杆 Crankshaft and piston rod

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1005015A	曲轴上轴瓦	Crankshaft upper bearing	5	ordered in suite	√
2	LF481Q1-1005024A	曲轴下轴瓦	Crankshaft lower bearing	5	ordered in suite	√
3	LF479Q1-1005013A	曲轴上止推片	Crankshaft upper thrust washer	2	ordered in suite	√
4	LF479Q1-1005014A	曲轴下止推片	Crankshaft lower thrust washer	2	ordered in suite	√
5	LF479Q1-1005022A	曲轴前油封	Crankshaft front seal	1		√
6	LF479Q1-1005012A	半圆键	Crankshaft woodruff key	1		√
7	LF481Q1-1005011A	曲轴	Crankshaft	1		√
8	LF479Q1-1004013A	活塞销	Piston Pin	4		√
9	LF481Q1-1004201A	活塞环I	Piston ring I	4	ordered in suite	√
10	LF481Q1-1004202A	活塞环II	Piston ring II	4	ordered in suite	√
11	LF481Q1-1004211A	片环	Piece ring	8	ordered in suite	√
12	LF481Q1-1004212A	衬环	Sleeve ring	4	ordered in suite	√
13	LF481Q1-1004012A	活塞	Piston	4	ordered in suite	√
14	LF481Q1-1004011A	连杆轴瓦	Rod Bearing	8	ordered in suite	√
15	LF479Q1-1004100A	连杆	Rod	4		√
15-1	LF479Q1-1004102A	连杆体	Rod	4		
15-2	LF479Q1-1004103A	连杆端盖	Rod cap	4		
15-3	LF479Q1-1004104A	连杆螺栓	Rod bolt	8		

1.05 曲轴与活塞连杆 Crankshaft and piston rod

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
15-4	LF479Q1-1004105A	连杆紧固螺母	Rod nut	8		


1.06 正时机构与前盖 Timing agency and front cover



1.06 正时机构与前盖 Timing agency and front cover

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	Q1840620	六角法兰面螺栓	Hex flange bolt	6		√
2	LF479Q1-1025021A	前罩壳上体	Front cover upper	1		√
3	LF479Q1-1025022A	前罩壳中体	Front cover middle	1		√
4	Q1840625	六角法兰面螺栓	Bolt	3		√
5	LF479Q1-1025023A	前罩壳下体	Front cover lower	1		√
6	LF479Q1-1025014A	凸轮轴正时皮带轮	Camshaft timing pulley	1		√
7	Q1841025	六角法兰面螺栓	Hex flange bolt	1		√
8	LF479Q1-1025100A	张紧轮总成	Tenioner	1		√
9	Q1841040	六角螺栓	Bolt	1		√
10	LF479Q1-1025025A	张紧轮扭簧	Tenioner spring	1		√
11	LF479Q1-1025018A	曲轴正时皮带轮前挡片	Front plate,crankshaft timing pulley	1		√
12	LF479Q1-1025012A	曲轴正时皮带轮	Crank shaft timing pulley	1		√
13	LF479Q1-1025019A	曲轴正时皮带轮后挡片	End plate ,crankshaft timing pulley	1		√
14	LF479Q1-1025016A	正时皮带	Timing belt	1		√


1.07 油底壳 Oil pan



1.07 油底壳 Oil pan

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-1010011A	机油集滤器密封垫	Gasket, oil strainer	1		√
2	LF479Q1-1009012A	机油盘双头螺柱	Thru-stud	2	6*1/11	√
3	Q32006	六角法兰面螺母	Hex flange bolt	2		√
4	LF479Q1-1010100A	机油集滤器总成	Oil strainer sub-assy	1		√
5	Q1840612	六角法兰面螺栓	Hex flange bolt	19		√
6	LF479Q1-1009100A	机油盘总成	Oil Pan	1		√
7	LF479Q1-1009012A	机油盘双头螺柱	Thru-stud	2	6*1/11	√
8	Q32006	六角法兰面螺母	Hex flange bolt	2		√
9	LF479Q1-1009013A	放油螺塞	Oil plug	1	12*1.25*16	√
10	Q40112T4F	放油螺塞垫圈	Oil plug washer	1		√
11	LF479Q1-1009015A	油位计导管	Oil level gauge guide	1		√
12	LF479Q1-1009300A	油位计总成	Oil level gauge assy	1		√
13	LF479Q1-1009011A	O型密封圈	O seal	1		√

1.08 进气歧管 In-manifold




1.08 进气歧管 In-manifold

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	Q1840825	六角法兰面螺栓	Bolt	3		√
2	Q32008	六角法兰面螺母	Hex flange nut	2		√
3	LF481Q1-1008201A	进气歧管上体	upper intake manifold	1		√
4	LF479Q1-1104014A	碳罐控制阀托架	Canister Control Valve bracket	1		√
5	LF479Q1-1108011A	油门拉索支架	Throttle cable bracket	1		√
6	LF479Q1-3765011A	节气门体总成密封垫	Throttle gasket	1		√
7	LBA1132100	节气门体总成	Throttle assy	1	Delphi	√
7	LBA1132100B1	节气门体总成	Throttle assy	1	Sun&teck	√
7	LBA1132100C1	节气门体总成	Throttle Assy	1	Sun&teck, plastic manifold	√
8	Q1840650	节气门螺栓	Throttle bolt	4		√
9	LF479Q1-1008203A	进气歧管上下体密封垫	Gasket upper&lower intake manifold	1		√
10	LF479Q1-1008202A	进气歧管下体	Lower intake manifold	1		√
11	LF479Q1-1008018A	双头螺栓	Thru-stud	2	M8*12/26	√
12	LF479Q1-3614011A	进气温度压力传感器支架	Bracket,temperature&pressure sensor	1	delphi	√
12	LF479Q1-3614011B	进气温度压力传感器支架	Bracket,temperature&pressure sensor	1	Sun&teck	
13	LF479Q1-1008018A	双头螺栓	Thru-stud	2	M8*12/26	√
14	Q32008	六角法兰面螺母	Hex flange nut	2		√
15	LF479Q1-1008014A	进气歧管密封垫	Intake manifold gasket	1		√

1.08 进气歧管 In-manifold

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
16	Q1840830	六角法兰面螺栓	Bolt, Intake manifold	7		√
17	LF479Q1-1008200A	进气歧管总成	Intake manifold	1		√


塑料进气歧管 In-manifold (plastic)



塑料进气歧管 In-manifold (plastic)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-1008200A1	进气歧管总成	Intake manifold	1	Plastic	√
2		密封垫	Seal	4		


1.09 排气歧管 Ex-manifold



1.09 排气歧管 Ex-manifold

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-1008013B	排气歧管密封垫	Exhaust manifold gasket	1	1.2±.1	√
2	LF481Q1-1008100A	排气歧管总成	Exhaust Manifold	1		√
3	LF479Q1-1008011A	排气歧管上罩	Heat Insulator upper	1		√
4	Q1840610	螺栓	Bolt	6		√
5	LF479Q1-1008012A	排气歧管下罩	Heat insulator lower	1		√
6	Q32010	六角法兰面螺母	Nut	5		√
7	LF479Q1-1008017A	排气歧管双头螺柱	Thru-stud	5	1*1.25*2/2	√
8	Q1840816	六角法兰面螺栓	Bolt	2		√
9	LF479Q1-1008016A	排气歧管支架	Exhaust manifold bracket	1		√
10	Q1841016	六角螺栓	Hex bolt	1		√


1.10 节温器 Thermostat



1.10 节温器 Thermostat

[illegible]


1.11 轮系 Pulley system



1.11 轮系 Pulley system

[illegible]


1.12 燃油分配器 Fuel distributor



1.12 燃油分配器 Fuel distributor

[illegible]

1.13 电喷系统 EFI system




1.13 电喷系统 EFI system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	BAC3612100B4	电喷ECU	ECU	1	for LF481 engine	√
2	LBA3612500	点火线圈总成	Ignition Coil	1	delphi	
2	LBA3705100B1	点火线圈总成	Ignition Coil	1	su&teck with OBD	√
3	LBA1132100	节气门体总成	Throttle assy	1	delphi	√
3	LBA1132100B1	节气门体总成	Throttle assy	1	sun&teck with OBD	√
3	LBA1132100C1	节气门体总成	Throttle Assy	1		√
4	LBA3614300	进气温度压力传感器	Temperature And Pressure Sensor	1	delphi	√
4	LBA3614300B1	进气温度压力传感器	Temperature And Pressure Sensor	1	sun&teck with OBD	√
5	LBA1130310	碳罐控制阀	Canister Control Valve	1	delphi	√
5	LBA1130310B1	碳罐控制阀	Canister Control Valve	1	sun&teck with OBD	√
6	LF479Q1-3707800A	火花塞总成	Spark Pluge	4		√
7	LBA3612400	爆震传感器	Knock Sensor	1		√
7	LBA3612400B1	爆震传感器	Knock Sensor	1	with OBD	√
8	LBA3612600	曲轴位置传感器	Crankshaft Position Sensor	1		√
8	LBA3612600B1	曲轴位置传感器	Crankshaft Position Sensor	1	sun&teck with OBD	√
9	LBA3616100	水温传感器	Water Temperature Sensor	1	delphi	√
9	LBA3616100B1	水温传感器	Water Temperature Sensor	1	sun&teck with OBD	√
10	LF479Q1-3818100A	机油压力报警器	Oil pressure warner	1		√

1.13 电喷系统 EFI system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
11	LBA3612300	氧传感器	Oxygen Sensor	1	delphi	√
11	LBA3612300B1	氧传感器	Oxygen Sensor	1	sun&teck with OBD	√
11	LBF3612300	前氧传感器	Front oxygen Sensor	1		√
11	LBF3612300B1	后氧传感器	Rear oxygen Sensor	1		√
12	LBA1121100	燃油分配管总成	Fuel Distributor	1	delphi	√
12	LBA1121100B1	燃油分配管总成	Fuel Distributor	1	sun&teck with OBD	√
	LBA1124100B1	燃油喷射器	Fuel injector	4	sun&teck with OBD	√
	LF481Q1-3611011A	曲轴位置传感器垫片	Crankshaft Position Sensor gasket	1		√
	Q1840630	曲轴位置传感器螺栓	Crankshaft Position Sensor bolt	1		√
	LBA1132160	节气门位置传感器	Throttle position sensor	1	delphi	√
	LBA1132160B1	节气门位置传感器	Throttle position sensor	1	sun&teck with OBD	√
	LBA1132150	怠速步进电机	Idle motor	1	delphi	√
	LBA1132150B1	怠速步进电机	Idle motor	1	sun&teck with OBD	√


1.14 水泵 Water pump



1.14 水泵 Water pump

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-1307103A	水泵盖	Water Pump Cover	1		
2	LF479Q1-1307104A	水泵体密封件	Gasket	1		
3	LF479Q1-1307102A	水泵体	Water Pump Body	1		
4	LF479Q1-1307107A	轴连轴承	Bearing	1		
5	LF479Q1-1307106A	法兰	Flange	1		
6	LF479Q1-1008018A	双头螺栓	Thru-stud	2	M8*12/26	√
7	Q676B45	水泵进出水软管管夹	Clip	2		√
8	LF479Q1-1307015A	水泵进水胶管	Inlet Water Hose	1		√
9	LF479Q1-1307013A	水泵进水管	Inlet Water Hose	1		√
10	Q1840610	螺栓	Bolt	1		√
11	Q32008	六角法兰面螺母	Hex flange nut	2		√
12	Q150B0835	六角头螺栓	Bolt	3		√
13	LF479Q3-1307100A-1	水泵总成	Water Pump	1		√
	LF479Q1-1307011B	水泵进水管密封垫	Inlet Water Hose gasket	1		


1.15 辅助装置 Auxiliary device



1.15 辅助装置 Auxiliary device

[illegible]


1.16 离合器 Clutch



1.16 离合器 Clutch

[illegible]


1.17 机油泵 Oil pump



1.17 机油泵 Oil pump

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1011100A	机油泵总成	Oil Pump Assy	1		√
2		螺钉	Pol	5		
3	LF481Q1-1011104A	定位销	Set Pin	2		
4	LF481Q1-1011106A	机油泵转子	Drive Gear	1		
5	LF479Q1-1011011A	机油泵密封垫	Gasket, oil pump	1		√
6	LF479Q1-1011012A	机油泵定位销	Oil pump pin	2	φ11*8	√
7	Q61903	螺塞	Plug	2		
8	LF481Q1-1011108A	机油泵安全阀	Oil Pump Relief Valve	1		
9	Q1840825	六角法兰面螺栓	Bolt	3		√
10		双头螺柱	Stub	2		
11	LF481Q1-1011101A	泵体	Oil Pump body	1		

1.18 起动电机和发电机 Starter and Generator




1.18 起动电机和发电机 Starter and Generator

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-3701013A	发电机紧固螺母	Generator nut	1	M1*1.25	√
2	LF481Q1-3701100A	发电机总成	Generator assy.	1		√
3	Q18410105	发电机托架螺栓	Generator bracket bolt	1		√
4	LF481Q1-3708100A	起动电机总成	Startor assy.	1		√
5	Q1841040	六角螺栓	Bolt	2		√
	LF479Q3-3701110A	皮带轮	Pulley	1	Generator spare part	√
	LF479Q3-3701120A	前端盖	Front cap	1	Generator spare part	√
	LF479Q3-3701130A	前滚动轴承	Bearing	1	Generator spare part	√
	LF479Q3-3701140A	定子	Stater	1	Generator spare part	√
	LF479Q3-3701150A	转子	Rotor	1	Generator spare part	√
	LF479Q3-3701160A	后滚动轴承	Bearing	1	Generator spare part	√
	LF479Q3-3701170A	后盖组成	End cap	1	Generator spare part	√
	LF479Q3-3701180A	电压调节器	Voltage regulator	1	Generator spare part	√
	LF479Q3-3701190A	电刷总成	Brush	1	Generator spare part	√
	LF479Q3-3701111A	整流器	Rectifier	1	Generator spare part	√
	LF479Q3-3701112A	绝缘套	Insulant	1	Generator spare part	√
	LF479Q3-3701113A	罩盖	Cover	1	Generator spare part	√
	LF479Q3-3708110A	前盖总成	Front cap assy.	1	Startor spare part	√

1.18 起动电机和发电机 Starter and Generator

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
	LF479Q3-3708120A	单向器	unidirectional	1	Startor spare part	√
	LF479Q3-3708130A	电磁开关	Solenoid Switch	1	Startor spare part	√
	LF479Q3-3708140A	星轮轮轴总成	Star gear	1	Startor spare part	√
	LF479Q3-3708150A	减速齿轮总成	Reducing gear	1	Startor spare part	√
	LF479Q3-3708160A	星形齿轮总成	Spider gear	1	Startor spare part	√
	LF479Q3-3708170A	电枢总成	Armature	1	Startor spare part	√
	LF479Q3-3708180A	机壳总成	Shuck	1	Startor spare part	√
	LF479Q3-3708190A	刷架总成	Brush bracket	1	Startor spare part	√
	LF479Q3-3708111A	电刷端盖总成	Front cap with brush assy.	1	Startor spare part	√
	LF479Q3-3708112A	拨叉	Fork	1	Startor spare part	√

1.19 发动机线束 Engine harness




1.19 发动机线束 Engine harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q3-4001100C50	发动机线束	Engine harness	1	sun&teck+OBD	

D: Delphi; S=Sun&teck; P=plastic in-manifold; N3=National III; E3=EURO III; E4=EURO IV


1.20 变速器总成 Transmission assy.



1.20 变速器总成 Transmission assy.

[illegible]

1.21 变速器壳体总成 Transmission shell



1.21 变速器壳体总成 Transmission shell

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1701011A	离合器壳体	Clutch shell	1	old status	√
1	LF481Q1-1701011A1	离合器壳体	Clutch shell	1	new status	
2	LF481Q1-1701021A	变速器壳体	Transmission shell	1	old status	
	LF481Q1-1701021A1	变速器壳体	Transmission shell		new status	
3	LF481Q1-1701337A	油封堵	Plug	2		
4	LF481Q1-2303321A	T型差速器油封	Differential T seal	1	clutch side old status	√
	LF481Q1-2303322A	T型差速器油封	Differential T seal	1	clutch side new status	
5	LF481Q1-1701023A	连接螺栓	Connecting bolt	14	M8X35	√
6	LF481Q1-1702110A	换挡导轴组件	Shift shaft component	1		√
7	LF481Q1-1701330A	分离拨叉	Throwout fork	1		√
8	LF481Q1-1701331A	分离拨叉护套	Throwout fork sleeve	1		√
9	LF481Q1-1702160A	离合器分泵	Clutch slave cylinder	1		√
10	LF481Q1-1702039A	换位拉线支架	Transposition cable bracket	1		
11	LF481Q1-1702047A	拉线支架螺栓	Cable bracket bolt	5	M8X18	√
12	LF481Q1-1701027A	倒车信号灯开关	Reverse light switch	1		
13	LF481Q1-1701024A	油管支架	Tube bracket	1		√
14	LF481Q1-1701026A	六角头螺塞	Hex bolt plug	2		√
15	LF481Q1-1701033A	换挡定位总成	Shift position device	1		√


1.21 变速器壳体总成 Transmission shell

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
16	LF481Q1-1701154A	端盖	End cover	1		√
17	LF481Q1-1701155A	端盖螺栓	End cover bolt	4	M6X18.5	√
18	LF481Q1-1702038A	换挡拉线支架	Shift cable bracket	1		
19	LF481Q1-1701334A	分离轴承	Throwout bearing	1		√
20	LF481Q1-1701333A	分离拨叉支撑柱	Throwout fork support	1		√
21	LF481Q1-1701335A	线卡子	Clamp	2		
22	LF481Q1-2303314A	T型差速器油封	Differential T seal	1	transimission side old status	√
	LF481Q1-2303322A	T型差速器油封	Differential T seal	1	transimission side new status	
23	LF481Q1-1701030A	输入轴S型油封	Input shaft S seal	1	23*37*7	√
24	LF481Q1-1702159A	离合器分泵螺栓	Bolt	2		√
25	LF481Q1-1701025A	油管支架螺栓	Tube bracket bolt	1	M8X15	
26	LF481Q1-1702157A	换档盖紧固螺栓	Bolt	2		√
27	LF481Q1-1702158A	换档盖定位螺栓	Bolt	2		√
28	LF481Q1-1701336A	方形磁体	Square magnet	1		
29	LF481Q1-1701028A	定位销	Pin	2		
30	LF481Q1-1701034A	导油槽	Oil passage	1		√
31	LF481Q1-1702170A	液压油管	Hydraulic tube	1		√
32	LF481Q1-1701086A	铝垫	Aluminium washer	1		√

1.21 变速器壳体总成 Transmission shell

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
33	LF481Q1-1701036A	带垫螺栓	Bolt with washer	2		


1.22 输入轴 Input shaft



1.22 输入轴 Input shaft

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1701041A	输入轴	Input shaft	1		
2	LF481Q1-1701078A	输入轴轴承	Input shaft bearing	1	25X62X17	
3	LF481Q1-1701050A	三档主动齿轮总成	Third drive gear	1		
4	LF481Q1-1701060A	三四档同步器总成	Third forth synchronize assy.	1		
5	LF481Q1-1701053A	四档主动齿轮总成	Forth drive gear	1		
6	LF481Q1-1701057A	五档主动齿轮总成	Fifth drive gear	1		
7	LF481Q1-1701070A	五档同步器总成	Fifth synchronize assy.	1		
8	LF481Q1-1701078A	输入轴轴承	Input shaft bearing	1	25X62X17	
9	LF481Q1-1701077A	五档滚针轴承	Fifth needle bearing	1	K31X36X2DTN	
10	LF481Q1-1701069A	五档同步环	Fifth synchronize rim	1		√
11	LF481Q1-1701044A	输入四档止推垫定位球	Input forth thrust washer ball	1		√
12	LF481Q1-1701065A	四档同步环	Forth synchronize rim	1		√
13	LF481Q1-1701042A	同步器档圈	Synchronize circlip	1		√
14	LF481Q1-1701059A	三档同步环	Third synchronize rim	1		√
15	LF481Q1-1701076A	三四档滚针轴承	Third forth needle bearing	2	K34X39X2DTN	
16	LF481Q1-1701300A	输入轴总成	Input shaft assy.	1		


1.23 输出轴 Output shaft



1.23 输出轴 Output shaft

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1701141A	输出轴前轴承	Output shaft front bearing	1	3X55X17	√
2	LF481Q1-1701110A	一档从动齿轮总成	First driven gear	1		
3	LF481Q1-1701113A	一档同步环	First synchronize rim	1		√
4	LF481Q1-1701124A	二档同步环	Second gear synchronize rim	1		√
5	LF481Q1-1701127A	二档滚针轴承	Second gear needle bearing	1	K34X39X23TN	√
6	LF481Q1-1701138A	四档从动齿轮	Forth driven gear	1		√
7	LF481Q1-1701150A	输出轴后轴承	Output shaft rear bearing	1	2X47X15	√
8	LF481Q1-1701140A	五档从动齿轮	Fifth driven gear	1		
9	LF481Q1-1701136A	三档从动齿轮	Third driven gear	1		
10	LF481Q1-1701130A	二档从动齿轮总成	Second driven gear	1		
11	LF481Q1-1701120A	一二档同步器总成	First second synchronize assy.	1		√
12	LF481Q1-1701103A	一档滚针轴承	First needle bearing	1	K34X39X28DTN	√
13	LF481Q1-1701106A	输出轴	Output shaft	1		√
14	LF481Q1-1701400A	输出轴总成	Output shaft assy.	1		
15	LF481Q1-1701101A	输出五档档圈	Output fifth circlip	1		√
16	LF481Q1-1701151A	输出轴轴承垫片	Output shaft spring washer	1		
	LF481Q1-1701137A	输出轴三档定位套	Output third position sleeve	1		√
	LF481Q1-1701029B	铜垫圈	Copper washer	1		


1.24 拨叉轴 Fork shaft



1.24 拨叉轴 Fork shaft

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1702081A	互锁销B	Interlock pin	1		√
2	LF481Q1-1702075A	倒档拨块	Reverse shift block	1		√
3	LF481Q1-1702061A	三四档拨叉轴	Third forth fork shaft	1		√
4	LF481Q1-1702051A	一二档拨叉轴	First second fork shaft	1		√
5	LF481Q1-1702071A	五倒档拨叉轴	Fifth reverse fork shaft	1		√
6	LF481Q1-1702082A	互锁销B	Interlock pin	1		√
7	LF481Q1-1702062A	三四档换档拨叉	Third forth fork	1		√
8	LF481Q1-1702052A	一二档换档导块	First second shift block	1		√
9	LF481Q1-1702053A	一二档换档拨叉	First second fork	1		√
10	LF481Q1-1702073A	五档换档拨叉	Fifth fork	1		√
11	LF481Q1-1702072A	五倒档换档导块	Fifth reverse shift block	1		√
12	LF481Q1-1702054A	换档叉止动螺栓	Shift fork stop bolt	2	M6X.75X19	√
13	LF481Q1-1702056A	弹性圆柱销	Spring pin	2	5.5X22	√
14	LF481Q1-1702057A	叉轴档圈	Fork shaft circlip	5	1.5x11.6x16.6	√
15	LF481Q1-1702074A	拨叉回位弹簧	Fork spring	1		√


1.25 差速器 Differential



1.25 差速器 Differential

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-2303309A	里程表主动齿轮	Speedometer drive gear	1		
2	LF481Q1-2303310A	差速器前轴承6208	Differential front bearing	1	old status	
	LF481Q1-2303316A	差速器圆锥滚子轴承	Differential roller bearing	1	new status	
3	LF481Q1-2303304A	半轴齿轮垫片	Differential axle gear washer	2		√
4	LF481Q1-2303301A	差速器壳	Differential shell	1	old and new status	√
5	LF481Q1-2303306A	行星齿轮轴	Planet gear shaft	1		√
6	LF481Q1-2303305A	行星齿轮垫片	Planet gear washer	2		
7	LF481Q1-2303302A	半轴齿轮	Differential axle gear	2		√
8	LF481Q1-2303312A	差速器后轴承6308	Differential rear bearing	1	old status	√
	LF481Q1-2303316A	差速器圆锥滚子轴承	Differential roller bearing	1	new status	
9	LF481Q1-2303311A	差速器螺栓	Differential bolt	10	M12X1X19.5	√
10	LF481Q1-2303308A	差速器齿圈	Differential roller bearing	1		√
11	LF481Q1-2303307A	圆柱销	Pin	1		√
12	LF481Q1-2303303A	行星齿轮	Planet gear	2		√
13	LF481Q1-2303300A	差速器总成	Differential assy.	1		√
	LF479Q1-3802100A	里程表传感器	Speedometer sensor	1		√
	LF481Q3-3802100B1	整体式里程表传感器	Speedometer sensor	1	integrative	√

1.26 换选档机构 Shift system




1.26 换选档机构 Shift system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1702141A	通气塞垫片	Vent valve gasket	1	1X14X1.5	√
2	LF481Q1-1702151A	换档盖	Shift cap	1		√
3	LF481Q1-1702138A	换挡导轴挡圈	Shift shaft circlip	1	A15X21X1.5	√
4	LF481Q1-1702128A	回位弹簧座	Return spring seat	1		√
5	LF481Q1-1702156A	回位弹簧	Return spring	1	A1.5x26.6x63x7.5	√
6	LF481Q1-1702035A	换位摇臂油封	Transposition swing arm seal	1	16x26x7	√
7	LF481Q1-1702115A	换位摆杆螺栓	Transposition swing lever bolt	1	M8X21	√
8	LF481Q1-1702030A	换位摇臂组件	Transposition swing arm	1		√
9	LF481Q1-1702142A	换档摆杆	Shift swinglever	1		√
10	LF481Q1-1702116A	换档摆杆弹性圆柱销	Pin	1	5.5X26	√
11	LF481Q1-1702155A	回位弹簧	Return spring	1	B1.2x13.2x63x9	√
12	LF481Q1-1702154A	换挡导轴尼龙垫圈	Shift shaft washer	1		√
13	LF481Q1-1702137A	换挡导轴挡圈	Shift shaft circlip	1	A1.5/3x21	√
14	LF481Q1-1702108A	换档摆杆互锁架	Shift swinglever interlock bracket	1		√
15	LF481Q1-1702120A	五倒档互锁凸轮	Fifth reverse cam	1		√
16	LF481Q1-1702122A	五倒档互锁凸轮弹簧	Fifth reverse cam spring	1		√
17	LF481Q1-1702016A	换挡盖定位环	Shift cap position ring	2	11X8.5X12	√
18	LF481Q1-1702121A	五倒档互锁凸轮密封球	Fifth reverse cam seal ball	1	6.2	√

1.26 换选档机构 Shift system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
19	LF481Q1-1702152A	换档盖衬套	Shift cap bush	1	18X21X1	√
20	LF481Q1-1702036A	换档导轴油封	Shift shaft seal	1	18x28x8	√
21	LF481Q1-1702105A	换档导轴护套	Shift shaft sleeve	1		√
22	LF481Q1-1702110A	换档导轴组件	Shift shaft component	1		√
23	LF481Q1-1702130A	通气塞总成	Vent valve assy.	1		
24	LF481Q1-1702114A	换位摆杆	Transposition swing lever	1		√
25	LF481Q1-1702123A	五倒档互锁凸轮销	Fifth reverse cam pin	1		√
26	LF481Q1-1701090A	倒档摆臂支架总成	Reverse swing arm bracket	1		√
27	LF481Q1-1701085A	倒档摆臂支架垫	Washer	1		√
28	LF481Q1-1701095A	倒档摆臂支架螺栓	Bolt	2		√


1.27 倒档中间齿轮 Reverse middle gear



1.27 倒档中间齿轮 Reverse middle gear

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1701081A	倒档中间齿轮轴	Reverse middle gear shaft	1		√
2	LF481Q1-1701080A	倒档中间齿轮总成	Reverse middle gear assy.	1		√
3	LF481Q1-1701083A	倒档中间齿轮螺栓	Bolt	1		√


1.28 里程表 Speedometer



1.28 里程表 Speedometer

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1701211A	里程表传动被动齿轮	Speedometer driven gear	1		√
2	LF481Q1-1701215A	里程表定位卡簧	Speedometer circlip	1		√
3	LF481Q1-1701214A	O型橡胶密封圈	O seal	1		√
4	LF481Q1-1701212A	里程表被动轮套	Speedometer driven gear sleeve	1		
5	LF481Q1-1701213A	里程表油封	Speedometer seal	1		√
6	LF481Q1-1600500A	里程表定位螺栓	Speedometer bolt	1		
7	LF481Q1-1701216A	里程表锁片	Speedometer locker	1		
8	LF481Q1-1701217A	里程表护套	Speedometer sleeve	1		√
9	LF481Q1-1701200A	里程表传动总成	Speedometer assy.	1		


2.01 Engine suspension(for LF481 engine)



2.01 Engine suspension(for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	231-1025TF3	六角法兰面螺栓	Hex flange bolt	7		√
2	BAC1001310	左悬置组件及安装支架	Left suspension component	1		√
3	231-12115TF3	六角法兰面螺栓	Hex flange bolt	2		√
4	101B-1212T13F3	六角法兰面螺母	Hex flange nut	2		√
5	BAC1001351	左悬置连接支架	Left suspension connecting bracket	1		√
6	BAC1001251	后悬置连接支架	Rear suspension connecting bracket	1		√
7	BAC1001210	后悬置支架带组件	Rear suspension component	1		√
8	231-1075TF3	六角法兰面螺栓	Hex flange bolt	2		√
9	GB/T889.2	I 型非金属嵌件六角锁紧螺母	I non metal hex lock nut	1	M10X1.25	√
10	231-1030TF30	六角法兰面螺栓	Hex flange bolt	2		√
11	231-1035TF30	六角法兰面螺栓	Hex flange bolt	1		√
12	BAC1001451	右悬置连接支架	Right suspension connecting bracket	1		
13	231-1030TF30	六角法兰面螺栓	Hex flange bolt	1		√
14	BAC1001410	右悬置组件及安装支架	Right suspension component	1		√
15	231-1050TF3	六角法兰面螺栓	Hex flange bolt	2		√
16	231-1050TF4	六角法兰面螺栓	Hex flange bolt	2		√
17	101-1212T2F3	六角法兰面螺母	Hex flange nut	2		√
18	Q33810T13F3	非金属嵌件六角法兰面锁紧螺母	Non-metal hex flange lock nut	2		√

2.02 Front suspension(for LF481 engine)




2.02 Front suspension(for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	Q32008	六角法兰面螺母	Hex flange nut	6		√
2	B2905011	前减震器上压板	Front shock absorber press plate	2		√
3	231-1560TF3	六角法兰面螺栓	Hex flange bolt	4		√
4	101-1514T13F3	六角法兰面螺母	Hex flange nut	4		√
5	101B-1212T13F3	六角法兰面螺母	Hex flange nut	4	M12*1.25	√
6	B2906200	前横向稳定杆连杆总成	Front stabilizer bar con-rod	2		√
7	231-1490TF3	六角法兰面螺栓	Hex flange bolt	6		√
8	BAC2901100	副车架总成	Sub-frame assy.	1		√
9	124-1417T13F3	六角法兰面开槽螺母	Hex flange nut	2		√
10	Q5003230	开口销	Cotter pin	2		√
11	B2904100	左前下摆臂总成	Front left swing arm	1		√
11-1	B2904810	球销组件	Ball joint	1		√
11-2	Q32012	六角法兰面螺母	Hex flange nut	2		√
11-3	Q1841216	六角法兰面螺栓	Hex flange bolt	1		√
12	231-1490TF3	六角法兰面螺栓	Hex flange bolt	2		√
13	B2901151	副车架胶塞	Sub-frame plug	2		√
14	B2906012	前横向稳定杆橡胶安装座	Front stabilizer bar rubber seat	2		√
15	B2906011	前横向稳定杆抱箍	Front stabilizer bar hoop	2		√

2.02 Front suspension(for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
16	Q1410825L	六角头螺栓带锥形垫圈组合件	Hex bolt and taper springness washer	4		√
17	101-1414T13F3	六角法兰面螺母	Hex flange nut	2		√
18	B2906100	前横向稳定杆总成	Front stabilizer bar assy.	1		√
19	B2904200	右前下摆臂总成	Front right swing arm	1		√
19-1	B2904810	球销组件	Ball joint	1		√
19-2	Q32012	六角法兰面螺母	Hex flange nut	2		√
19-3	Q1841216	六角法兰面螺栓	Hex flange bolt	1		√


2.03 Front shock absorber



2.03 Front shock absorber

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B2905100	左前减振器总成	Front left shock absorber assy.	1		√
1	B2905200	右前减振器总成	Front right shock absorber assy.	1		√
1-1	B2905120	左前减振器阻尼器总成	Front left shock absorber damper	1		√
1-1	B2905220	右前减振器阻尼器总成	Front right shock absorber damper	1		√
1-2	B2905182	弹簧下座	Spring lower seat	2		√
1-3	B2905181	前螺旋弹簧	Front coil spring	2		√
1-4	B2905183	限位块	Stopper	2		√
1-5	B2905184	防尘罩	Boot	2		√
1-6	B2905185	弹簧上座	Spring upper seat	2		√
1-7	B2905170	上连接盖板组件	Upper plate	2		√
1-8	B2905186	锁紧螺母盖板	Nut plate	2		√
1-9		六角法兰面螺母	Hex flange nut	2	only available with assembled parts	


2.04 Rear suspension



2.04 Rear suspension

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	Q32008T13F3	六角法兰面螺母	Hex flange nut	4		
2	231-1025TF3	六角法兰面螺栓	Hex flange bolt	2		√
3	Q40214	大垫圈	Big washer	2		√
4	101-1414T13F3	六角法兰面螺母	Hex flange nut	2		√
5	101B-1212T13F3	六角法兰面螺母	Hex flange nut	2		√
6	231-12130TF3	六角法兰面螺栓	Hex flange bolt	2		√
7	231B-1027TF3	六角法兰面螺栓	Hex flange bolt	8		√
8	B2911100	后桥总成	Rear axle assy.	1		√
8-1	B2916110	后桥焊接组件及安装套	Rear axle	2		
8-2	231B-1275TF3	六角法兰面螺栓	Hex flange bolt	2	only available with assembled parts	√
8-3	B2916140	后横向稳定杆总成	Rear stabilizer bar assy.	1		√
8-4	101B-1212T13F3	六角法兰面螺母	Hex flange nut	2	only available with assembled parts	√


2.05 Rear shock absorber



2.05 Rear shock absorber

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B2915100	左后减振器总成	Rear left shock absorber assy.	1		√
1	B2915200	右后减振器总成	Rear right shock absorber assy.	1		√
1-1	B2915120	后减振阻尼器总成	Rear shock absorber damper	2		√
1-2	B2915182	防尘罩及限位块	Stop boot	2		√
1-3	B2915181	后螺旋弹簧	Rear coil spring	2		√
1-4	B2915183	限位盖	Stop plate	2		√
1-5	B2915184	减振垫	Damper cushion	2		√
1-6	B2915185	弹簧上橡胶垫	Spring upper rubber cushion	2		√
1-7	B2915170	左后上连接板组件	Left connect plate	1		√
1-7	B2915270	右后上连接板组件	Right connect plate	1		√
1-8	B2915186	缓冲定位套	Positioning sleeve	2		√
1-9	B2915187	缓冲块	Damper block	2		√
1-10	B2915188	缓冲限位座	Damper seat	2		√
1-11		六角法兰面螺母	Hex flange nut	2	only available with assembled parts	

2.06 Fuel supply(for LF481 engine)




2.06 Fuel supply(for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	BAC1104030	燃油硬管/喷油嘴连接软管组件	Hose connecting fuel tube and nozzle	1		√
2	Q67512	A型蜗杆转动式软管软管	Hoop	7		√
3	LBA1130107B1	软管 V	Hose V	1		√
4	B1130300	燃油蒸汽控制阀总成	Fuel valve	1		
5	BAC1130152	碳罐/燃油蒸汽控制阀连接软管	Hose connecting canister and control vavle	1		√
6	B1130200	碳罐总成	Can Canister	1		√
7	B1130151	碳罐/回油硬管连接软管	Hose connecting canister and reflux tube	1		√
8	Q67512	油门拉索组件	Throttle cable	1		√
9	Q1400630	六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer	4		√
10	B1108100	油门踏板总成	Accelerator pedal assy.	1		√
11	B1104020	燃油硬管组件	Fuel tube	1		√
12	B1130110	油箱至碳罐连接硬管组件	Tube connecting fuel tank and canister	1		√
13	B1104251	燃油管路三管夹	Clamp	1		√
14	B1130120	油箱至碳罐连接软管组件	Hose connecting fuel tank and canister	1		√
15	B1117020	油箱回油管/燃油硬管连接组件	Fuel tank reflux pipe and fuel tube connecting component	1		√
16	B1117010	油箱/滤清器出油软管组件	Fuel filter hose	1		√
17	L1117100	汽油滤清器总成	Fuel filter	1		√
18	Q67516	A型蜗杆转动式软管软管	Hoop	2		√

2.06 Fuel supply(for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
19	Q1410616L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	2		√
20	B1132200	谐振腔总成	Cavity resonator	1		√
21	Q32006	六角法兰面螺母	Hex flange nut	2		√


2.07 Air filter(for LF481 engine)



2.07 Air filter(for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	L8212012	子母扣	Inlay button	1		√
2	Q1410616	六角法兰面螺栓和锥形弹性垫圈组合件	Hex bolt, taper springness washer and flat washer	1		√
3	B1109210	空滤器进气管总成	Air filter intake pipe	1		√
4	B1109100	空气滤清器总成	Air filter assy.	1		√
4-1	B1109110	空滤器上盖组件	Air filter upper shell	1		
4-2	B1109103	空滤器滤芯组件	Air filter element	1		
4-3	B1109241	弹簧卡夹	Spring clamp	2		
4-4	B1109120	空滤器下盖组件	Air filter lower shell	1		
5	Q1410632L	六角法兰面螺栓和锥形弹性垫圈组合件	Hex bolt, taper springness washer and flat washer	3		√
6	BAC1109220	发动机进气软管总成	Engine section pipe	1		√
6-1	Q67670	B型蜗杆传动式环箍	Hoop	1		
6-2	Q673B12	弹性钢带环箍	Steel spring hoop	1		√
6-3	BAC1109670	曲轴箱通风管组件	Crankcase vent hose	1		
6-4	Q67680	B型蜗杆传动式环箍	Hoop	1		
6-5	BAC1109221	发动机进气软管	Engine section pipe	1		

2.08 Fuel tank




2.08 Fuel tank

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B1101100	燃油箱总成	Fuel tank assy.	1		√
2	B1101200	加注管总成	Fuel filler tube assy.	1		√
2-1	B1101251	加油软管护套	Hose sleeve	1		
2-2	Q676B45	B型蜗杆传动式环箍	Hoop	2		√
2-3	B1101260	加油软管	Fuel filler hose	1		
2-4	B1101220	加油及出气硬管	Reurn tube	1		
2-5	B1101210	加油口盖组件	Fuel filler cap	1		
2-6	B1101285	加油口护罩上卡簧	Fuel filler cover lower circlip	1		
2-7	B1101281	加油口护罩	Fuel filler cover	1		
2-8	B1101286	加油口护罩下卡簧	Fuel filler cover upper circlip	1		
2-9	Q67625	B型蜗杆传动式环箍	Hoop	2		
2-10	B1101253	出气软管	Vent hose	1		
3	B1101254	加油管回气硬管卡座 I	Reurn tube clamp I	1		
4	B1101255	加油回气硬管卡座 II	Reurn tube clamp II	1		
5	B1101010	燃油左固定带组件	Fuel tank left fixation	1		√
6	Q1401030	六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer	4		√
7	B1101020	燃油箱右固定带组件	Fuel tank right fixation	1		√
8	B1123100	电子燃油泵总成	Fuel pump assy.	1		√

2.08 Fuel tank

[illegible]

2.09 Steering system(for LF481 engine)



2.09 Steering system(for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3404310	转向管柱防尘套组件	Dustproof, steering tube	1		
2	B3412410	转向机上隔音罩卡圈	Noise insulator circlip, steering gear	1		√
3	B3412511	转向机上隔音罩	Noise insulator, steering gear	1		√
4	231B-1256TF3	六角法兰面螺栓	Hex flange bolt	2		√
5	125-1215	六角开槽薄螺母	Hex nut	2		√
6	Q5002528	开口销	Cotter pin	2		√
7	B3406340	转向器油管固定支架B组件	Pipe bracket B	1		√
8	Q1410616	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	1		√
9	231-1225TF3	六角法兰面螺栓	Hex flange bolt	2		√
10	B3406300	转向器回油管总成	Steering reflux pipe assy.	1		√
10-1	B3406310	转向器回油管组件 I	Steering reflux pipe I	1		
10-2	Q67512	A型蜗杆传动式软管环箍	Hoop	5		√
10-3	B3406321	转向器回油管 II	Steering reflux pipe II	1		
10-4	B3406711	油管护套	Pipe sleeve	1		
10-5	B3406330	转向器回油管组件III	Steering reflux pipe III	1		
10-6	Q67520	A型蜗杆传动式软管环箍	Hoop	1		√
10-7	B3406341	转向器回油管IV	Steering reflux pipe IV	1		√
10-8	B3406820	转向器油管支架组件 II	Steering pipe bracket II	1		


2.09 Steering system(for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
10-9	B3406350	转向器回油管组件 V	Steering reflux pipe V	1		
10-10	B3406361	转向器回油管 VI	Steering reflux pipe VI	1		
10-11	B3406810	转向器油管支架组件 I	Steering pipe bracket I	1		
11	BAC3406200	转向器进油管总成	Steering intake pipe assy.	1		√
11-1	BAC3406210	转向器进油管组件	Steering pump intake pipe	1		
11-2	507-1602	平垫圈	Flat washer	2		
11-3	221-1630	轴向径向螺栓	Bolt	1		
12	BAC3406100	转向油泵进油管总成	Steering pump intake pipe assy.	1		√
12-1	Q67529	A型蜗杆传动式软管环箍	Hoop	2		
12-2	BAC3406111	转向油泵进油管	Steering pump intake pipe	1		
13	B3408100	动力转向油壶总成	Power steering reservior assy.	1		√
14	B3408010	动力转向油壶支架组件	Power steering reservior bracket assy.	1		√
14-1	B3408011	动力转向油壶支架	Power steering reservior bracket	1		
14-2	B3408012	动力转向油壶卡片	Power steering reservior clip	1		
15	Q1840616	六角法兰面螺栓	Hex flange bolt	4		√
16	400-1729	塑料卡扣	Plastic clip	2		
17	BAC3407100	动力转向油泵总成	Steering pump assy.	1		√
17-1	Q150B1030	六角螺栓	Hex bolt	1		

2.09 Steering system(for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
17-2	Q40310	弹簧垫圈	Springness washer	1		√
17-3	507-1024	平垫圈	Flat washer	1		
18	LBA3407102	转向油泵调节支架	Steering pump adjustor	1		√
19	231-1020TIF3	六角法兰面螺栓	Hex flange bolt	2		
20	LBA3407103	皮带	Belt, steering pump	1		√
21	LBA3407101	转向油泵支架	Steering pump bracket	1		√
21-1	Q150B1080	六角头螺栓	Hex bolt	1		
21-2	Q40310	弹簧垫圈	Springness washer	1		√
21-3	Q340B10	I 型六角螺母	I hex nut	1		√
21-4	LBA3407111	转向油泵支架座	Steering pump seat	1		
22	Q1410825L	六角头螺栓和锥形弹性垫圈组合	Hex bolt and taper springness washer	2		√
23	231-1025TIF30	六角法兰面螺栓	Hex flange bolt	1		


2.10 Power steering gear



2.10 Power steering gear

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3401100	转向器和转向拉杆总成	Steering gear assy.	1		✓
1-1	B3401200	右横向拉杆总成	Steering right rod	1		✓
1-2	Q351B14	六角薄螺母	Hex nut	2	only available with assembled parts	
1-3	B3401812	卡箍	Hoop	2		✓
1-4	B3401811	防尘罩	Dust shield	2		✓
1-5	B3401713	抱箍	Hoop	2		✓
1-6	B3401510	左缸油管组件	Left oil pipe	1		✓
1-7	B3401520	右缸油管组件	Right oil pipe	1		✓
1-8	B3401600	左横向拉杆总成	Steering left rod	1		✓
2	B3404200	下转向轴总成	Lower steering shaft assy.	1		✓
3	B3404100	上转向轴总成	Upper steering shaft assy.	1		✓
4	Q1460830	六角头螺栓和弹簧垫圈组合件	Hex bolt and washer	2		✓
5	101B-1212T13F3	六角法兰面螺母	Hex flange nut	1		✓
6	Q1840855	六角法兰面螺栓	Hex flange bolt	1		✓
7	Q1840816	六角法兰面螺栓	Hex flange bolt	2		✓


2.11 Shift system(for LF481 engine)



2.11 Shift system(for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	L1703016	变速拉索接头固定卡	Shift cable joint clip	2		
2	L1703017	E型卡	E clip	2		√
3	Q1840625	六角法兰面螺栓	Hex flange bolt	2		√
4	B1703200	选换档软轴总成	Gearshift cable	1		√
5	B1703019	软轴固定支架	Cable bracket	1		√
6	Q1410825L	六角头螺栓带锥形垫圈组合件	Hex bolt and taper springness washer	4		√
7	B170150	换档手柄球头组件	Gearlever handle	1		
8	B1703100	换档支座组件	Gear shift seat	1		√
9	Q1410620	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	1		√

2.12 Clutch controller system(for LF481 engine)





2.12 Clutch controller system(for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	L1600013	卡片	Clip	1		√
2	BAC1607120	离合主泵出油软管组件	Outtake hose, clutch master pump	1		
3	B1607111	离合主泵进油软管	Intake hose, clutch master pump	1		√
4	Q67512	A型蜗杆传动式软管环箍	Hoop	2		√
5	Q1410616	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	3		√
6	Q68618	单片管夹	Clamp	1		√
7	Q68610	单片管夹	Clamp	1		√
8	L1600014	垫密圈	washer	2		√
9	221-1018	带孔螺栓	Eye bolt	1	M10×1×18	√
10	B1608100	离合器总泵总成	Clutch master pump	1		√
11	Q32008	六角法兰面螺母	Hex flange nut	2		√
12	Q5101022	销轴	Axis pin	1		√
13	Q5003220	开口销	Cotter pin	1		√
14	B1602100	离合踏板总成	Clutch paddle assy.	1		√
14-1	B1602331	助力弹簧	Auxiliary spring	1		
14-2	B1602332	衬套I	Sleeve I	1		
14-3	B1602333	衬套II	Sleeve II	1		
14-4	B1602181	离合器板胶套	Clutch paddle sleeve	1		

2.12 Clutch controller system(for LF481 engine)

[illegible]


2.13 Transmission shaft(for LF481 engine)



2.13 Transmission shaft(for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	SBC22001	差速器侧万向节维修包（左）	Left universal joint kit,transmission side	1		
2	SB22002	差速器侧防护罩维修包	protection cover kit,transmission side	2		
3	SBC22003	车轮侧万向节维修包	Universal joint kit,wheel side	2		
4	SBC22004	车轮侧防护罩维修包	protection cover kit,wheel side	2		
5	SBC22005	差速器侧万向节维修包（右）	Right universal joint kit,transmission side	1		
6	BAC2203100	左传动轴总成	Left transmission shaft assy.	1		√
7	BAC2203200	右传动轴总成	Right transmission shaft assy.	1		√
	Q387B22	六角开槽薄螺母	Hex nut	2		√
	Q40122	平垫圈	Flat washer	2		
	Q5005032	开口销	Cotter pin	2		

2.14 Brake system



2.14 Brake system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3506160B1	比例阀-FR(左前硬管)	Front left tube, proportional valve	1		
1	B3506160	ABS-FR(左前硬管)	Front left tube, ABS	1		√
2	B3506210	ABS-RL(左后硬管 I)	Rear left tube I, ABS	1		√
3	B3506140B1	比例阀-MCP(一缸硬管)	Master cylinder tube, proportional valve	1		
3	B3506140	ABS-MCP(一缸硬管)	Master cylinder tube, ABS	1		√
4	B3506110B1	比例阀-FL(左前硬管 I)	Front left tube I, proportional valve	1		
4	B3506110	ABS-FL(左前硬管 I)	Front left tube I, ABS	1		√
5	B3506230	ABS-RR(右后硬管 I)	Rear right tube I, ABS	1		√
6	B3506150B1	比例阀-MCS(二缸硬管)	Sub cylinder tube, proportional valve	1		
6	B3506150	ABS-MCS(二缸硬管)	Sub cylinder tube, ABS	1		√
7	Q1410616	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	10		√
8	B3506320	六管夹组件	Clamp	3	for 6 tube	√
9	B3550100	ABS-机构总成	ABS ECU	1		√
10	Q1410820	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	5		√
11	B3550211	ABS支架总成	ABS bracket	1		√
12	B3506356	三管夹A	Clamp A	1	for 3 tube	√
13	Q5101022	销轴	Axis pin	1		√
14	Q5003220	开口销	Cotter pin	1		√


2.14 Brake system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
15	L3506106	E型卡片	E shape clip	4		√
16	B3506130	前制动软管	Front brake hose	2		√
17	B3506120	ABS-FL(左前硬管Ⅱ)	Front left tube II, ABS	1		√
18	B3506357	三管夹B	Clamp B	1	for 3 tube	√
19	Q1840645	六角法兰面螺栓	Hex flange bolt	2		√
20	B3550411	比例阀阀体	Proportional Valve	1		√
21	B3506310	七管夹组件	Clamp	1	for 7 tube	√
22	136-0813	六角法兰面螺母和弹簧垫圈组合件	Hex bolt and taper springness washer	4		
23	B3506240	比例阀阀体-RR(后-右后硬管Ⅱ)	Rear right tube II, Proportional Valve	1		√
24	B3508300	驻车制动操纵杆总成	Parking brake lever	1		√
24-1	B3508420	驻车制动拉索前段组件	Parking brake cable, fore part	1		√
24-2	B3508411	拉索过孔胶套	Cable sleeve	1		
24-3	B3781110	驻车制动开关	Parking brake switch	2		
25	B3506351	五管夹A	Clamp A	3	for 5 tube	√
26	B3506355	五管夹卡扣	Clamp clip	3		√
27	B3506352	五管夹卡B	Clamp B	1	for 5 tube	√
28	B3506362	制动管路下护板	Brake pipeline fender	1		√
29	B3506220	比例阀阀体-RL(左后硬管Ⅱ)	Rear left tube II, Proportional Valve	1		√

2.14 Brake system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
30	B3506250	后制动软管组件	Rear brake hose	2		√
31	B3506359	单管夹B	Clamp B	2	for 1 tube	√
32	B3506353	五管夹C	Clamp C	1	for 5 tube	√
33	B3506354	五管夹D	Clamp C	1	for 5 tube	√
34	B3506358	单管夹A	Clamp A	4	for 1 tube	√
35	B3508412	前/后拉索支架	Brake cable bracket	1		√
36	B3508413	驻车制动拉索后段固定支架	Parking brake cable bracket, rear part	2		√
37	B3506361	前轮制动管路过孔胶套	Front brake tube sleeve	2		√


2.15 Brake pedal



2.15 Brake pedal

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3504100	制动踏板支架总成	Brake pedal bracket assy.	1		√
1-1	B3781120	制动灯开关	Brake lamp switch	1		√
1-2	Q351C10	六角薄螺母	Hex nut	1		
1-3	B3504110	制动踏板支架组件	Brake paddle bracket	1		
1-4	Q351C10	六角头螺栓	Hex bolt	1		
1-5	B3504361	制动踏板销柱衬管	Liner tube	1		√
1-6	B3504351	制动踏板销柱衬套	Bush	2		√
1-7	101B-1010	法兰盘螺母	Flange nut	1		
1-8	B3506161	制动踏板限位胶垫	Rubber stopper	1		
1-9	B3504200	制动踏板组件	Brake paddle	1		
1-10	B3504141	制动踏板胶垫	Brake paddle rubber sleeve	1		√
2	178-0806	B型板簧螺母	“B”spring nut	1		√
3	204-0825T1F3	六角头螺栓和锥形弹簧垫圈组合件	Hex bolt and taper springness washer	1		√


2.16 Brake pump



2.16 Brake pump

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3540100	真空助力器带制动泵总成	Vacuum booster with pump assy.	1		√
1-1	B3540200	制动总泵带油壶组件	Brake pump with fluid pot	1		
1-1-1	B3540270	制动油壶盖组件	Fluid pot cap	1		√
1-1-2	B3540250	制动油壶组件	Fluid pot	1		√
1-1-3	B3540292	十字头螺钉	Philips screw	1		
1-1-4	B3540291	橡胶密封圈	Seal	2		
1-1-5	B3504210	制动总泵总成	Brake pump	1		√
1-2	Q32008	六角法兰面螺母	Hex flange nut	2		√
1-3	B3540420	左前制动硬管接头组件	Front left brake tube joint	1		
1-4	B3540300	真空助力器总成	Vacuum booster assy.	1		√
1-4-1	B3540341	推杆叉	Putter	1		
1-4-2	Q350B10	六角螺母	Hex nut	1	only available with assembled parts	
1-4-3	B3540342	衬垫	Washer	1		
1-4-4	B3540411	助力真空管接头	Vacuum hose joint	1		
2	Q673B12	A型蜗杆传动式软管环箍	Steel spring hoop	2		√
3	B3540011	真空助力器真空软管	Vacuum hose	1	for Tritec engine	√
3	BAC540011	真空助力器真空软管	Vacuum hose	1	for LF481 engine	

2.17 Front brake




2.17 Front brake

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3501100	左前制动器带转向节总成	Left front brake with steer knuckle assy.	1		✓
1	B3501600	右前制动器带转向节总成	Right front brake with steer knuckle assy.	1		✓
1-1	Q184A1235	六角法兰面螺栓	Hex flange bolt	4		✓
1-2	B2304100	左转向节总成	Left steering knuckle assy.	1		
1-2	B2304200	右转向节总成	Right steering knuckle assy.	1		
1-2-1	B2304111	左转向节	Left steering knuckle	1		✓
1-2-1	B2304611	右转向节	Right steering knuckle	1		✓
1-2-2	B2304510	转向节轴承组件	Steering knuckle bearing	2		
1-2-3	B2304561	轴承挡圈	Bearing circlip	2		
1-3	B3501410	左前制动器底板组件	Front left brake bottom	1		✓
1-3	B3501910	右前制动器底板组件	Front right brake bottom	1		✓
1-4		六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer	6	only available with assembled parts	
1-5	B3103100	前轮毂总成	Front wheel hub	2		✓
1-6	B3501240	左前内制动摩擦片	Front left brake pad, inner	1		✓
1-6	B3501740	右前内制动摩擦片	Front right brake pad, inner	1		✓
1-7	B3501260	前外制动摩擦片	Front brake pad, outer	2		✓
1-8	B3501110	左前制动卡钳总成	Front left brake caliper	1		✓
1-8	B3501610	右前制动卡钳总成	Front right brake caliper	1		✓

2.17 Front brake

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1-9	B3501111	前制动盘	Front brake disc	2	左右各一	√

2.18 Rear brake




2.18 Rear brake

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3502100	左后制动器总成	Rear left brake	1		√
1	B3502600	右后制动器总成	Rear right brake	1		√
1-1	B3502111	后制动盘	Rear brake disc	2		√
1-2	231B-1027TF3	六角法兰面螺栓	Hex flange bolt	8		√
1-3	B3502110	左后制动卡钳总成	Rear left brake caliper assy.	1		√
1-3	B3502610	右后制动卡钳总成	Rear right brake caliper assy.	1		√
1-4	B3502182	后制动卡钳安装螺栓	Bolt, rear brake caliper	4		
1-5	B3502240	左后内制动摩擦片	Rear left brake pad, inner	1		√
1-5	B3502730	右后内制动摩擦片	Rear right brake pad, inner	1		√
1-6	B3502260	后外制动摩擦片	Front brake pad, outer	2		√
1-7	B3104100	后轮毂总成	Rear wheel hub	2		√
1-8	B3502400	左后制动底板总成	Left rear brake bottom assy.	1		
1-8	B3502900	右后制动底板总成	Right rear brake bottom assy.	1		
1-8-1	B3508100	驻车制动左拉索总成	parking brake left cable	1		
1-8-1	B3508200	驻车制动右拉索总成	Parking brake right cable	1		
1-8-2	B3502410	左后制动底板组件	Left rear brake bottom	1		√
1-8-2	B3502910	右后制动底板组件	Right rear brake bottom	1		√
1-8-3	B3502597	制动蹄固定簧片销	Brake shoe pin	4		

2.18 Rear brake

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1-8-4	Q1400610	六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer	2	only available with assembled parts	
1-8-5	B3502571	驻车制动摇臂	Parking brake swing arm	2		
1-8-6	B3502230	后制动蹄片组件	Rear brake shoe	4		√
1-8-7	B3502596	制动蹄固定簧片	Brake shoe leafspring	4		
1-8-8	B3502580	驻车制动调节杆组件	parking brake adjust rod	2		
1-8-9	B3502591	制动蹄回位弹簧	Return spring	2		
1-8-10	B3502595	制动蹄调节拉杆固定弹簧	Fixing spring	2		
1-8-11	B3502593	制动蹄拉紧弹簧	Stretched spring	2		
1-8-12	B3502594	制动蹄支撑板	Support plate	2		
1-9	231B-1027TF3	六角法兰面螺栓	Hex flange bolt	8		√

2.19 Radiator(for LF481 engine)




2.19 Radiator(for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	204-0814T1F3	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	2		√
2	B1302111	散热器上安装支架	Radiator upper bracket	2		√
3	B1302151	散热器上安装衬套	Radiator upper fixing sleeve	2		
4	B1301100	散热器总成	Radiator assy.	1		√
4-1	B1301170	散热器加水口盖组件	Radiator water filler cap	1		
5	B1302161	散热器下安装衬套	Radiator lower fixing sleeve	2		
6	Q67645	B型蜗杆式传动软管环箍	Hoop	4		
7	BAC1303121	散热器进水管	Radiator intake pipe	1		√
8	Q32006	六角法兰面螺母	Hex flange nut	2		√
9	BAC1303111	散热器出水管	Radiator drain pipe	1		√
10	B1308100	电子风扇带护风罩总成	Cooling fan assy.	1		√
10-1	B3749100	冷却风扇 I	Cooling fan I	1		
10-2	B1308710	护风罩组件	Fan shield	1		
10-3	Q1840412	六角法兰面螺栓	Hex flange bolt	6		
10-4	B1308111	扇叶	Fan blade	2		
10-5	Q32005	六角法兰面螺母	Hex flange nut	2		√
10-6	B3749200	冷却风扇 II	Cooling fan II	1		
11	B1311100	储液壶总成带溢流管	Water can with return tube assy.	1		√

2.19 Radiator(for LF481 engine)

[illegible]

2.20 Exhaust system(for LF481 engine)




2.20 Exhaust system(for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	LAL1200018	前排气管密封圈	Front gasket	1		√
2	231-1030TF30	六角法兰面螺栓	Hex flange bolt	2		√
3	BAC1205100	前级净化器总成	Exhaust purifier,fore part	1		√
4	Q1410616	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	3		√
5	Q2006	六角法兰面螺母	Hex flange nut	3		
6	B1211510	压簧螺栓组件	Setting bolt spring assy.	4		
6-1	B1211511	压簧螺栓	Bolt	2		√
6-2	B1211512	压簧	Pressure spring	2		√
7	B1211112	球型密封垫	Ball shape gasket	2		√
8	B1211522	后消声器橡胶悬置块	Rear muffler rubber block	3		√
9	B1211521	前消声器橡胶悬置块	Front muffler rubber block	1		√
10	BAC1205200	后级净化器总成	Exhaust purifier,rear part	1		√
11	B1211525	排气管防脱架	Exhaust pipe bracket	1		√
12	Q32006	六角法兰面螺母	Hex flange nut	2		√
13	Q32206	六角头螺母和锥形垫圈组合件	Hex bolt and taper springness washer	4		√
14	B1208012	排气管前地板下隔热板	Exhaust pipe heat insulater I	1		√
15	B1208011	排气管前围板下隔热板	Exhaust pipe heat insulater II	1		√
16	B1208013	排气管油箱下隔热板	Exhaust pipe heat insulater III	1		√

2.20 Exhaust system(for LF481 engine)

[illegible]


2.21 Wheels



2.21 Wheels

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	189-1235T13F6	车轮螺母组件	Wheel bolt	16		√
2	B3102510	轮毂盖板组件	Rim cap assy.	4		√
2-1	B3102513	轮毂中心标牌	Wheel LOGO	1		
2-2	B3102511	轮毂盖板	Rim cap	1		
2-3	B3102512	卡簧	Circlip	1		
3	L3106200	轮胎气门嘴	Valve component	5		√
4	L3106202	气门嘴防护帽	Cap, valve of tyre	5		
5	L3113011	5g粘式平衡块	Glue balancing weight	Demand	60g	
6	B3101111	铝合金车轮	Aluminum rim	4		√
7	B3101210	钢制车轮	Steel rim	1		√
8	B3106100	轮胎	Tyre	5		√


3.01 Communication system & AV system



3.01 Communication system & AV system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B7901500	CD播放器总成	CD player	1		√
1	B7901700	DVD播放器总成	DVD player	1		√
1	B7901700B1	DVD播放器总成(GPS)	DVD player	1	with GPS	√
2	B7909220	右前高音头组件	Right alt loudspeaker	1		√
3	B7903170	收音机天线放大器总成	Antenna assy.	1		√
4	Q2726395	十字槽盘头螺钉-F型	Philips screw with washer	8		√
5	Q1800612	六角法兰面承面带齿螺栓	Hex flange bolt	1		√
6	Q41206	外锯齿锁紧垫圈	External teeth serrated lock washer	1		√
7	B7909510	后扬声器	Rear loadspeaker	2		√
8	B7909110	前门扬声器	Front door loadspeaker	2		√
9	Q4400516	开口扁头抽芯铆钉	Rivet	6		√
10	Q2734816F30	十字槽大半圆头自攻螺钉	Philips tapping screw	4		√
11	B7909210	左前高音头组件	Left alt loudspeaker	1		√

3.02 Electric equipment



3.02 Electric equipment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3721100	高音电喇叭	Alt horn	1		√
2	Q1840816	六角法兰面螺栓	Hex flange bolt	2		√
3	B3721200	低音电喇叭	Bass horn	1		√
4	B3741100	前刮水器电动机	Front wiper motor	1		√
5	B3747120	前风窗洗涤泵电机	Front wiper pump motor	1		
6	B7917730	倒车监控摄像头馈线	Reverse monitor harness	1	EX	√
7	B3723050	仪表线束管梁靠鼓风机接线器	Instrument harness adapter	1		
8	B3723010	仪表线束A柱下接线器	Instrument harness lower adapter	2	set on A pillar	
9	B3746500	左车门电动玻璃升降器电机	Glass lifter motor,left	4		√
9	B3746600	右车门电动玻璃升降器电机	Glass lifter motor,right	4		√
10	Q1840610	六角法兰面螺栓	Hex flange bolt	12		√
11	B3758110	前门接触开关	Contacter switch,front door	2		√
12	Q1840616T1F30	六角法兰面螺栓	Hex flange bolt	4		√
13	B3758120	后门接触开关	Contacter switch,rear door	2		√
14	Q1800612	六角法兰面承面带齿螺栓	Hex flange bolt	1		√
15	B7904310	静噪滤波器及支架	Noise filter	1		√
16	B271195	十字槽盘头自攻螺钉	Philips self-tapping screw	2		
17	B7917710	倒车监控摄像头	Reverse monitor camera	1	EX	√

3.02 Electric equipment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
18	Q2734295	十字槽盘头自攻螺钉	Philips self-tapping screw	2		
19	B7917711	摄像头装饰罩	Camera cap	1	EX	√
20	Q32006	六角法兰面螺母	Hex flange nut	2		√
21	B3605400	防盗报警器总成	Security warner	1		√
22	B3723060	车身线束接线器	Vehicle body harness adapter	1		
23	B3723030	仪表线束管梁左接线器	Instrument harness left adapter	1		
24	Q2706316	六角法兰面螺钉	Hex flange screw	1		√
25	B4104430	烟灰盒照明灯	Ashtray light	1		
26	B3725100	点烟器总成	Cigarette lighter	1		√
27	B3722200	发动机舱电器中央控制盒	Central control case	1	Engine room	
27-1	JD1926-30A/QC T73	继电器	Relay	1	speed regulation	√
27-1	JD1927-30A/QC T73	继电器	Relay	1	Front fog lamp	√
27-1	JD1927-30A/QC T73	继电器	Relay	1	Fan,High speed	√
27-1	JD1927-30A/QC T73	继电器	Relay	1	Fan,Low speed	√
27-1	JD1927-30A/QC T73	继电器	Relay	1	overtaking lamp	√
27-1	JD1927-30A/QC T73	继电器	Relay	1	Low beam	√
27-1	JD1927-30A/QC T73	继电器	Relay	1	High beam	√
27-1	JD1927-30A/QC T73	继电器	Relay	1	Compressor	√


3.02 Electric equipment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
27-1	JD1927-30A/QC T73	继电器	Relay	1	Main relay	√
27-1	JD101K-70A/QC T73	继电器	Relay	1	Blower	√
27-2	BX2011A1-30A/QC T73	保险丝	Fuse	2	ABS controller	√
27-2	BX2011A1-40A/QC T73	保险丝	Fuse	1	Blower	√
27-2	BX2011A1-60A/QC T73	保险丝	Fuse	1	Sub power	√
27-2	BX2011A1-60A/QC T73	保险丝	Fuse	1	Driving room power	√
27-2	BX2011A1-100A/QC T73	保险丝	Fuse	1	Main power	√
27-2	BX2011F-15A/QC T73	保险丝	Fuse	1	Low beam	√
27-2	BX2011F-15A/QC T73	保险丝	Fuse	1	High beam/overtaking lamp	√
27-2	BX2011F-15A/QC T73	保险丝	Fuse	1	Front fog lamp	√
27-2	BX2011F-25A/QC T73	保险丝	Fuse	1	Main relay	√
27-2	BX2011F-25A/QC T73	保险丝	Fuse	1	Fan,High speed	√
27-2	BX2011F-25A/QC T73	保险丝	Fuse	1	Fan,Low speed	√
27-2	BX2011F-10A/QC T73	保险丝	Fuse	1	Compressor	√
27-2	BX2011F-10A/QC T73	保险丝	Fuse	1	ECU	√
27-2	BX2011F-5A/QC T73	保险丝	Fuse	1	Fan,speed regulation/Compressor	√
27-2	BX2011F-10A/QC T73	保险丝	Fuse	1	Spare fuse	√
27-2	BX2011F-15A/QC T73	保险丝	Fuse	1	Spare fuse	√

3.02 Electric equipment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
27-2	BX2011F-20A/QC T73	保险丝	Fuse	1	Spare fuse	√
27-2	BX2011F-25A/QC T73	保险丝	Fuse	1	Spare fuse	√
27-2	BX2011F-30A/QC T73	保险丝	Fuse	1	Spare fuse	√
27-2	BX2011F-7.5A/QC T73	保险丝	Fuse	1	Spare fuse	√
27-3	B3722161B1	拨片器	Puller	1		
27-4	B3722211	发动机舱电器中央控制盒上盖	Central control case cap	1	Engine room	
28	Q32006	六角法兰面螺母	Hex flange nut	1		√
29	Q1410620	六角头螺栓和锥形弹性垫圈组合	Hex bolt and taper springness washer	1		√

3.03 Lamps




3.03 Lamps

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4116100	左前雾灯总成	Front left fog lamp	1		√
2	B4116200	右前雾灯总成	Front right fog lamp	1		√
3	Q2706316	六角法兰面螺钉	Hex flange screw	6		√
4	H3/GB 15776-2001	灯泡	Bulb	2		√
5	B4121100	左前组合灯	Front left head lamp	1	halogen lamp,unadjustable	√
5	B4121100B1	左前组合灯	Front left head lamp	1	EX,xenon lamp,adjustable	
5	B4121100C1	左前组合灯	Front left head lamp	1	halogen lamp,adjustable	
6	B4121200	右前组合灯	Front right head lamp	1	halogen lamp,unadjustable	√
6	B4121200B1	右前组合灯	Front right head lamp	1	EX,xenon lamp,adjustable	
6	B4121200C1	右前组合灯	Front right head lamp	1	halogen lamp,adjustable	
7	Q1410616LT1F30	六角头螺栓和锥形弹性垫圈组合	Hex bolt and taper springness washer	6		
8	H3/GB 15776-2001	灯泡	Bulb	2		√
9	H1/GB 15776-2001	灯泡	Bulb	2		√
9	D1S/GB 15776-2001	灯泡	Bulb	2	xenon bulb	
10	PY21W/GB 15776-2001	灯泡	Bulb	2		√
11	B4131100	左前门灯	Front left door lamp	1		√
12	B4123400	后顶灯	Rear ceiling light	1		√
13	C5W/GB 15776-2001	灯泡	Bulb	1		√

3.03 Lamps

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
14	B4131200	右前门灯	Front right door lamp	1		√
15	B4131400	右后门灯	Rear right door lamp	1		√
16	B4134100	高位制动灯	High-mount brake lamp	1		√
17	B4131300	左后门灯	Rear left door lamp	1		√
18	305-0508F3	六角法兰面螺栓	Hex flange bolt	1		√
19	B3758300	行李箱照明灯开关	Trunk light switch	1		√
20	PY21W/GB 15776-2001	灯泡	Bulb	2	Steering lamp	√
21	P21W/GB 15776-2001	灯泡	Bulb	2	Reverse lamp	√
22	W3W/GB 15776-2001	灯泡	Bulb	2	Registration lamp	√
23	Q32006	六角法兰面螺母	Hex flange nut	6		√
24	B4108200	右后牌照灯	Right registration lamp	1		√
25	B4108100	左后牌照灯	Left registration lamp	1		√
26	B4133400	右后组合灯	Right tail lamp	1		√
27	B4133300	左后组合灯	Left tail lamp	1		√
	B4123100	前顶灯	Front ceiling light	1		
	B4127100	行李箱照明灯	Trunk light	1		√


3.04 Locks



3.04 Locks

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3704100	点火开关	Ignition switch assy.	1		√
1-1	B3704162	防盗螺栓	Bolt	1		
1-2	B3704161	轴盖	Ignition Cap	2		
1-3	B3704170	点火开关锁芯总成	Ignition switch lock cylinder	1		
1-4	B3704300	点火开关光圈	Ignition switch coil	1		√
2						
2-1	B3704220	遥控钥匙 (LX)	Remote key	2	LX	
2-1	B3704220B1	遥控钥匙 (EX)	Remote key	2	EX, trunk unlock function	
2-1	B3704210	普通钥匙	Key	1		√
2-2	B3704221	钥匙片	Key plate	2		√
2-3	B3704240	遥控手柄 (LX)	key handle	2	LX	√
2-3	B3704240B1	遥控手柄 (EX)	key handle	2	EX	√
3	B3704510	左前门锁芯	Door lock cylinder, front left door	1		√
4	B3704520	右前门锁芯	Door lock cylinder, front right door	1		√
5	B3704550	行李舱锁芯总成	Trunk lock cylinder	1		√


3.05 Front suspension(for LF481 engine)



3.05 Front suspension(for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	Q33006	全金属六角法兰面锁紧螺母	Allmetal hex flange locknut	2		√
2	BAC3703211	蓄电池压板连杆	Battery press beam	1		√
3	BAC3703212	蓄电池塑料压块	Battery plastic press plate	2		√
4	L3703100	蓄电池总成	Battery assy.	1		√
5	BAC3703214	蓄电池底盖	Battery bottom	1		√
6	BAC3703213	蓄电池拉杆	Battery draglink	2		√
7	Q1840610	六角法兰面螺栓	Hex flange bolt	3		√
8	BAC3703215	蓄电池托架	Battery bracket	1		√


3.06 Instrument panel



3.06 Instrument panel

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	BAC3820000C1	组合仪表	Instrument cluster	1		√
1	BAC3820000D1	组合仪表	Instrument cluster	1	120KM/H warning	√
2	B3820021	簧片螺母	Spring nut	1		
3	B8112100	电动空调控制面板及开关总成	Air conditioner control panel	1	MT	√
3	B8112100B1	自动空调控制面板及开关总成	Air conditioner control panel	1	AT	√
4	Q2734816	十字槽半圆头自攻螺钉	Philips self-tapping screw	2		√
5	B3774200	雨刮组合开关总成	Wiper switch	1		√
6	B3774100	灯光组合开关总成	Lamp switch	1		√
7	B3750500	电动后视镜开关组件	Wing mirror switch assy.	1	DX, LX	√
7	B3750500B1	电动后视镜开关组件	Wing mirror switch assy.	1	EX	
7-1	B3750510	防盗指示灯	Security waring light	1		√
7-2	B3782070	电动外后视镜控制开关	Wing mirror switch	1		√
7-3	B3710210	背景光调整开关	Background light switch	1		
7-4	B3710230	近光灯光轴调整开关	Low beam adjust switch	1		√


3.07 Electric device



3.07 Electric device

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3674100	BCM车身控制器组件	Body control module (BCM)	1	LX	√
1	B3674100B1	BCM车身控制器组件	Body control module (BCM)	1	DX	
1	B3674100C1	BCM车身控制器组件	Body control module (BCM)	1	EX	
2	Q1840816	六角法兰面螺栓	Hex flange bolt	2		√
3	B3658300	安全气囊时钟弹簧	Airbag clock spring	1	3 loop	√
3	B3658300B1	安全气囊时钟弹簧	Airbag clock spring	1	7 loop	√
4	B3661220	环境光传感器	Ambient light sensor	1		√
5	B3612211	电喷ECU固定支架	ECU bracket	1		√
6	Q37106	焊接方螺母	Square nut	4		√
7	Q1410520L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	2		√
8	BAC3612100B4	电喷ECU	ECU	1	for LF481 engine	√
9	B3612212	电喷ECU防尘罩	ECU cap	1		√
10	Q1410625	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	4		√
11	Q1840616	安装螺栓	Bolt	3		√
12	B3658100	安全气囊ECU	Airbag ECU	1	2 loop	√


3.08 Headlining harness



3.08 Headlining harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4005100	顶棚线束总成	Headlining harness	1	LX, rear top light	√
1	B4005100B1	顶棚线束总成	Headlining harness	1	EX	√


3.09 Vehicle body harness



3.09 Vehicle body harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4002100	左车身线束	Left body harness	1		√
1	B4002100B1	左车身线束	Left body harness	1	EX	√
2	Q1800612	六角法兰面承面带齿螺栓	Hex flange bolt	3		√
3	Q41206	外锯齿锁紧垫圈	External teeth serrated lock washer	3		√
4	B3723060	车身线束接线器	Body harness adapter	1		
5	B4035003	车身线束油泵胶套	Body harness sleeve	1		
6	B4035005	倒车雷达接线胶套	Reverse radar harness sleeve	1		


3.10 Defrost earth wire



3.10 Defrost earth wire

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4002020	后除霜接地线总成	Defrost earth wire	1		√
2	Q1800612	六角法兰面承面带齿螺栓	Hex flange bolt	1		√
3	Q41206	外锯齿锁紧垫圈	External teeth serrated lock washer	1		√


3.11 Reverse radar harness



3.11 Reverse radar harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4002800	倒车雷达探头线束	Reverse radar harness	1		√
2	B3603841	安装支架	Bracket	3		√
3	B3603820	倒车雷达传感器	Reverse radar sensor	3		√


3.12 Power harness



3.12 Power harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4008120	蓄电池电源线束	Power harness	1		√


3.13 Rear door harness



3.13 Rear door harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4006300	左后门线束	Rear left door harness	1		√
2	B4006400	右后门线束	Rear right door harness	1		√


3.14 Wheel speed sensor harness



3.14 Wheel speed sensor harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3630400	右前轮轮速传感器总成	Front right wheel speed sensor	1		√
2	B3630452	右前轮速传感器线束支架B	Plastic bracket,FR speed sensor	1		
3	B3630451	右前轮速传感器线束支架A	Metal bracket,FR speed sensor	1		
4	Q1840620	六角法兰面螺栓	Hex flange bolt	2		√
5	B4009250	右后轮轮速传感器线束总成	Rear right wheel speed sensor	1		√
6	B4009288	电缆线胶套	Sleeve	2		
7	B4009286	右后轮速传感器线束支架A	Plastic bracket,RR speed sensor	1		√
8	B4009287	右后轮速传感器线束支架B	Metal bracket,RR speed sensor	1		√
9	B4009284	后轮速传感器线束支架A	Metal bracket,Rear speed sensor	2		√
10	B4009285	后轮速传感器线束支架B	Plastic bracket,Rear speed sensor	2		√
11	B4009283	左后轮速传感器线束支架B	Metal bracket,RL speed sensor	1		√
12	B4009282	左后轮速传感器线束支架A	Plastic bracket,RL speed sensor	1		√
13	B4009240	左后轮轮速传感器线束总成	Rear left wheel speed sensor	1		√
14	B3630351	左前轮速传感器线束支架A	Metal bracket,FL speed sensor	1		
15	B3630300	左前轮轮速传感器总成	Front left wheel speed sensor	1		√
16	B3630352	左前轮速传感器线束支架B	Plastic bracket,FL speed sensor	1		


3.15 Front harness



3.15 Front harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	Q1800612	六角法兰面承面带齿螺栓	Hex flange bolt	2		√
2	B4001600	前部线束总成	Front harness	1	halogen lamp,adjustable	√
2	B4001600B1	前部线束总成	Front harness	1	EX,xenon lamp,adjustable	√
3	Q41206	外锯齿锁紧垫圈	External teeth serrated lock washer	2		√


3.16 Front door harness



3.16 Front door harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4006100	左前门线束	Front left door harness	1		√
2	B4006200	右前门线束	Front right door harness	1		√


3.17 Antenna harness



3.17 Antenna harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B7903170	收放机天线放大器总成	Antenna harness	1		√
2	Q1800612	六角法兰面承面带齿螺栓	Hex flange bolt	1		√
3	Q41206	外锯齿锁紧垫圈	External teeth serrated lock washer	1		√


3.18 Battery negative wire



3.18 Battery negative wire

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	Q1800612	六角法兰面承面带齿螺栓	Hex flange bolt	1		√
2	B4001350	蓄电池负极线束	Battery negative wire	1		√
3	Q41206	外锯齿锁紧垫圈	External teeth serrated lock washer	1		√


3.19 Instrument panel harness



3.19 Instrument panel harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4003100	仪表板线束	Instrument panel harness	1	DX, LX	√
1	B4003100B1	仪表板线束	Instrument panel harness	1	EX	
2	Q1800612	六角法兰面承面带齿螺栓	Hex flange bolt	2		√
3	Q41206	外锯齿锁紧垫圈	External teeth serrated lock washer	2		√


3.20 Airbag harness



3.20 Airbag harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B4003600	安全气囊线束总成	Airbag harness	1		√
1	B4003600B1	安全气囊线束总成	Airbag harness	1	EX	√


3.21 Inner handrail switch



3.21 Inner handrail switch

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3746100	左前门扶手板开关	Inner handrail with switches,front left door	1		√
1-1	B3746120	左前门玻璃升降开关	Glass lifter,front left door	1		√
1-2	B3746110	左前门扶手板	Inner handrail,front left door	1		√
2	B3746300	左后门扶手板开关	Inner handrail with switches,rear left door	1		√
2-1	B3746220	玻璃升降开关	Glass lifter	1		√
2-2	B3746310	左后门扶手板	Inner handrail,raer left door	1		√
3	B3746200	右前门扶手板开关	Inner handrail with switches,front right door	1		√
3-1	B3746220	玻璃升降开关	Glass lifter	1		√
3-2	B3746210	右前门扶手板	Inner handrail,front right door	1		√
4	B3746400	右后门扶手板开关	Inner handrail with switches,rear right door	1		√
4-1	B3746220	玻璃升降开关	Glass lifter	1		√
4-2	B3746410	右后门扶手板	Inner handrail,rear right door	1		√
5	B3746130	自攻螺钉渡盖	Tapping screw cap	4		
6	Q2714819	十字槽盘头自攻螺钉	Philips self-tapping screw	4		√

3.22 Central control case



3.22 Central control case

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3722100	驾驶舱电器中央控制盒	Central control case	1	Driver room	√
1-1	JD1912-40A/QC T73	继电器	Relay	1	Sub power	√
1-1	JD1927-30A/QC T73	继电器	Relay	1	Horn	√
1-1	JD1927-30A/QC T73	继电器	Relay	1	Fuel	√
1-1	JD1927-30A/QC T73	继电器	Relay	1	Rear fog lamp	√
1-1	JD1927-30A/QC T73	继电器	Relay	1	Rear defroster	√
1-2	BX2011A1-30A/QC T73	保险丝	Fuse	1	Ignition AM1	√
1-2	BX2011A1-30A/QC T73	保险丝	Fuse	1	Ignition AM2	√
1-2	BX2011A1-30A/QC T73	保险丝	Fuse	1	Rear defroster	√
1-2	BX2011F-5A/QC T73	保险丝	Fuse	1	BCM central control lock power	√
1-2	BX2011F-5A/QC T73	保险丝	Fuse	1	Top light/trunk light	√
1-2	BX2011F-5A/QC T73	保险丝	Fuse	1	Air conditioner controller B+	√
1-2	BX2011F-5A/QC T73	保险丝	Fuse	1	Instrument cluster, ignition	√
1-2	BX2011F-5A/QC T73	保险丝	Fuse	1	A/V system power	√
1-2	BX2011F-5A/QC T73	保险丝	Fuse	1	BCM, ignition	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	Top light	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	Instrument cluster	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	Rear fog lamp	√


3.22 Central control case

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	sub lamps	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	Fuel pump	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	wing mirror	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	Air conditioner controller,ignition	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	Brake light	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	ABS control	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	1	airbag	√
1-2	BX2011F-15A/QC T73	保险丝	Fuse	1	top window	√
1-2	BX2011F-15A/QC T73	保险丝	Fuse	1	BCM steering light/indicator light	√
1-2	BX2011F-15A/QC T73	保险丝	Fuse	1	A/V system power	√
1-2	BX2011F-15A/QC T73	保险丝	Fuse	1	wiper	√
1-2	BX2011F-15A/QC T73	保险丝	Fuse	1	horn	√
1-2	BX2011F-15A/QC T73	保险丝	Fuse	1	cigarette	√
1-2	BX2011F-15A/QC T73	保险丝	Fuse	1	Brake light	√
1-2	BX2011F-25A/QC T73	保险丝	Fuse	1	magnetic field power/generator ECU/ignition coil/camshaft sensor/speed sensor	√
1-2	BX2011F-30A/QC T73	保险丝	Fuse	1	glass lifter power	√
1-2	BX2011F-5A/QC T73	保险丝	Fuse	1	Spare fuse	√
1-2	BX2011F-10A/QC T73	保险丝	Fuse	2	Spare fuse	√

3.22 Central control case

[illegible]


3.23 Harness clamps



3.23 Harness clamps

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	XJ-7X12-R	线束支架	Harness clamp			√
2	CL-7X17-B	线束L型卡钉	Harness clamp			√
3	M23408	线束卡钉扎带	Harness clamp			√
4	CS03	线束卡钉扎带	Harness clamp			√
5	M32481	线束支架	Harness clamp			√
6	AD37600013	线束支架	Harness clamp			√
7	T11-3724072	线束支架	Harness clamp			√
8	82711-1A890	线束支架	Harness clamp			√
9	DWJ-H26	线束F型支架	Harness clamp			√
10	M23438	线束支架	Harness clamp			√
11	M32483	线束支架	Harness clamp			√
12	ZD3143X5	线束卡钉扎带	Harness clamp			√
13	XD-67	线束F型卡钉	Harness clamp			√


4.01 Vehicle body



4.01 Vehicle body

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5009001	白车身总成	Vehicle body assy.			√


4.02 Engine hood



4.02 Engine hood

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B8402000	发动机罩总成	Engine hood	1		√
2	B8402620	发动机罩右铰链组件	Engine hood right hinge	1		√
3	Q1840820	六角法兰面螺栓	Hex flange bolt	4		√
4	Q1840816	六角法兰面螺栓	Hex flange bolt	4		√
5	B8402610	发动机罩左铰链组件	Engine hood left hinge	1		√


4.03 Front cowl



4.03 Front cowl

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5302000	前围板总成	Front cowl assy.	1		√
2	B5301000	前围上横梁总成	Front cowl upper beam	1		√


4.04 顶盖 Roof



4.04 顶盖 Roof

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5701000	顶盖骨架及盖板总成	Roof	1		√
2	B5701015	顶盖天窗加强板安装支架	Roof bracket	2		√
3	B5701016	顶盖天窗加强板安装支架2	Roof bracket 2	2		√
4	B5701017	顶盖天窗加强板安装支架3	Roof bracket 3	2		√
5	B5701000B1	顶盖骨架及盖板总成	Roof	1	with top window	√


4.05 Side cowl



4.05 Side cowl

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5401021	右侧前连接加强板	Right front connecting plate	1		√
2	B5401020	右侧围总成	Right cowl assy.	1		√
3	B5401300	加油口盖总成	Fuel filler cap	1		√
4	B5401010	左侧围总成	Left cowl assy.	1		√
5	B5401011	左侧前连接加强板	Left front connecting plate	1		√


4.06 Front door



4.06 Front door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B6101001	左前车门总成	Front left door assy.	1		√
2	B6106210	右前车门上铰链组件	Upper hinge,front right door	1		√
3	B6106220	右前车门下铰链组件	Lower hinge,front right door	1		√
4	B6106110	左前车门上铰链组件	Upper hinge,front left door	1		√
5	B6106120	左前车门下铰链组件	Lower hinge,front left door	1		√
6	Q1840820	六角法兰面螺栓	Hex flange bolt	16		√
7	B6101002	右前车门总成	Front right door assy.	1		√


4.07 Rear door



4.07 Rear door

[illegible]


4.08 Front side fender



4.08 Front side fender

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B8403111	左翼子板	Front left fender	1		√
2	B8403211	右翼子板	Front right fender	1		√


4.09 Front damping



4.09 Front damping

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B2803200	前保险杠骨架主体	Front bumper frame	1		√
2	B2803211	前保险杠左固定板	Front bumper frame left fixing plate	1		√
3	B2803212	前保险杠右固定板	Front bumper frame right fixing plate	1		√
4	B8401100	水箱上横梁总成	Radiator upper beam	1		√
5	B8400030	发动机罩锁体安装立柱总成	Engine hood lock fixing plate	1		√
6	B8400020	右前轮罩纵梁总成	Right front longeron and wheel cap assy.	1		√
7	B8400120	右前纵梁外板前段总成	Right front longeron fore part	1		√
8	B8400130	左前纵梁外板前段总成	Left front longeron fore part	1		√
9	B8400010	左前轮罩纵梁总成	Left front longeron and wheel cap assy.	1		√
10	B8401200	水箱下横梁总成	Radiator lower beam	1		√
11	B2804241	后保险杠骨架右安装支架	Rear bumper frame right fixing plate	1		√
12	B2804231	后保险杠骨架左安装支架	Rear bumper frame left fixing plate	1		√
13	B2804200	后保险杠骨架主体	Rear bumper frame	1		


4.10 Floor assy.



4.10 Floor assy.

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5120000	前地板总成	Front floor assy.	1		√
2	B5130000	后地板总成	Rear floor assy.	1		√


4.11 Rear cowl



4.11 Rear cowl

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5601100	搁物板总成	Shelf assy.	1		√
2	B5605200	行李箱盖右铰链总成	Trunk lid right hinge	1		√
3	B5605100	行李箱盖左铰链总成	Trunk lid left hinge	1		√
4	Q1840625	六角法兰面螺栓	Hex flange bolt	4		√
5	B5604000	行李箱盖总成	Trunk lid assy.	1		√
6	B5601200	后围板总成	Rear cowl assy.	1		√
7	B5601251	后保险杠右安装支架	Rear bumper right bracket	1		√
8	B5601241	后保险杠左安装支架	Rear bumper left bracket	1		√
9	Q32006	六角法兰面螺母	Hex flange nut	4		√


5.01 Steering wheel and Airbag



5.01 Steering wheel and Airbag

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3658300	安全气囊时钟弹簧	Airbag clock spring	1		√
1	B3658300B1	安全气囊时钟弹簧	Airbag clock spring	1	EX	√
2	B3402100B14	方向盘总成	Steering wheel	1	foam, deep grey	√
2	B3402100B1B14	方向盘总成	Steering wheel	1	leather,with multi-switches, deep grey	√
3	B5824100	驾驶员气囊模块	Driver's airbag	1		√
4	B3658100	安全气囊ECU	Airbag ECU	1	2 loop	√
4	B3658100B1	安全气囊ECU	Airbag ECU	1	4 loop	√
5	B5824200B14	副驾驶员气囊模块	Passengers airbag	1	deep grey	√
6	Q1840820	六角法兰面螺栓	Hex flange bolt	2		√

5.02 Side body



5.02 Side body

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	Q2215519F31	十字槽盘头自攻螺钉和大垫圈组合件	Philips screw with washer	14		✓
2	400-065	塑料卡扣	Plastic clip	14		✓
3	B5416225	左右裙板小堵盖	Skirt plate plug	14	small	✓
4	B5416223	左右裙板小卡扣	Skirt plate clip	14	small	
5	B5416224	左右裙板大卡扣	Skirt plate clip	16	big	
6	B5416226	左右裙板大堵盖	Skirt plate plug	16	big	✓
7	B5400113	隔音海绵	Sound proof cushion	2		✓
8	B5416222	A柱右三角窗装饰板橡胶条	Seal, right triangular window decoration	1		✓
8	B5416212	A柱左三角窗装饰板橡胶条	Seal, left triangular window decoration	1		✓
9	400-1405	塑料卡扣	Plastic clip	1		✓
10	B5416221	A柱右三角窗装饰板	Right triangular window decoration	1		✓
10	B5416211	A柱左三角窗装饰板	Left triangular window decoration	1		✓
11	B5402021	顶棚右前支撑架	Roof support, front right	1		✓
11	B5402011	顶棚左前支撑架	Roof support, front left	1		✓
12	B6107217	右前门框密封条	Front right door frame seal	1		✓
12	B6107117	左前门框密封条	Front left door frame seal	1		✓
13	B5402230B15	B柱右上护板组件	Right upper fender, B pillar	1	pale grey	✓
13	B5402130B15	B柱左上护板组件	Left upper fender, B pillar	1	pale grey	✓

5.02 Side body

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
14	B5402022	顶棚右后支撑架	Roof support, rear right	1		√
14	B5402012	顶棚左后支撑架	Roof support, rear left	1		√
15	B6207217	右后门框密封条	Rear right door frame seal	1		√
15	B6207117	左后门框密封条	Rear left door frame seal	1		√
16	B5107111	Φ30堵盖	Plug	19	Φ30	√
17	Q72725	Φ25橡胶堵盖	Rubber plug	2	Φ25	√
18	B8123630	通风口组件	Trunk ventilation	1		√
18-1	B8123631	行李舱通风口骨架	Trunk ventilation frame	2		
18-2	B8123632	行李舱通风口橡胶片 I	Trunk ventilation seal I	2		
18-3	B8123633	行李舱通风口橡胶片 II	Trunk ventilation seal II	2		
18-4	B5400121	侧围塑料螺母	Plastic nut, side bdoy	2	Φ15	√
19	B5402250B15	C柱右上护板组件	Right upper fender,C-pillar	1	pale grey	√
19	B5402150B15	C柱左上护板组件	Left upper fender,C-pillar	1	pale grey	√
20	400-1729	塑料卡扣	Plastic clip	7		√
21	400-256	塑料卡扣	Plastic clip	1		√
22	B5400341	右后轮挡泥板	Rear right mudguard	1		√
22	B5400331	左后轮挡泥板	Rear left mudguard	1		√
23	B5400342	右后挡泥板防溅板	Spray-proof, rear right mudguard	1		√


5.02 Side body

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
23	B5400337	左后挡泥板防溅板	Spray-proof, rear left mudguard	1		√
24	B5400338	后挡泥板防溅板卡扣	Clip, rear spray-proof	2		√
25	Q2754820	十字槽凹穴六角头自攻螺钉	Philips self-tapping screw	1		
26	B5400343	右后饰板	Rear right decoration,mudguard	1		√
26	B5400339	左后饰板	Rear left decoration,mudguard	1		√
27	400-1500	塑料卡扣	Plastic clip	1		√
28	B5402181B15	左后门槛护板	Rear left threshold fender	1	pale grey	√
28	B5402281B15	右后门槛护板	Rear right threshold fender	1	pale grey	√
29	B5400112	左右B柱海绵块	B pillar cushion	4		√
30	B5402241B15	B柱右下护板	Right lower fender,B-pillar	1	pale grey	√
30	B5402141B15	B柱左下护板	Left lower fender,B-pillar	1	pale grey	√
31	B5402171B15	左前门槛护板	Front left threshold fender	1	pale grey	√
31	B5402271B15	右前门槛护板	Front right threshold fender	1	pale grey	√
32	B5402220B15	A柱右下护板组件	Right lower fender,A-pillar	1	pale grey	√
32	B5402120B15	A柱左下护板组件	Left lower fender,A-pillar	1	pale grey	√
33	Q1840620	六角法兰面螺栓	Hex flange bolt	2		√
34	B5400316	小挡泥板	Small mudguard	2		√
35	B5400321	右前轮挡泥板	Front right mudguard	1		√

5.02 Side body

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
35	B5400311	左前轮挡泥板	Front left mudguard	1		√
36	B5400315	固定钣金	Fixing plate	1		√
37	400-1933	塑料卡扣	Plastic clip	2		√
38	B6105141	侧车门锁扣组件	Door buckle component	4		√
39	327-0820	内六角花形沉头螺钉	Inner hex flat head screw	8		
40	B5402211B15	A柱右上护板	Right upper fender,A-pillar	1	pale grey	√
40	B5402111B15	A柱左上护板	Left upper fender,A-pillar	1	pale grey	√
41	400-540	塑料卡扣	Plastic clip	1		√

5.03 Front attachment




5.03 Front attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B2803132	前保险杠右连接支架	Front bumper right connecting bracket	1		√
2	B8402300	发动机罩撑杆组件	Hood prop assy.	1		√
2-1	B8402313	发动机罩撑杆顶部塑料顶套	Hood prop top	1		
2-2	B8402321	发动机罩撑杆放置卡槽	Hood prop hodler	1		√
2-3	B8402311	发动机罩撑杆	Hood prop	1	φ7	
2-4	B8402312	发动机罩撑杆旋转塑料卡套	Hood prop sleeve	1		
3	B8402800	车前橡胶件总成	Engine room seal assy.	1		
3-1	B8402821	发动机仓后密封条	Engine room rear seal	1		√
3-2	B8402822	发动机仓后密封条卡扣	Engine room rear seal clip	8		√
4	B5301012	堵片	Plug	2	Φ35	√
5	B2803131	前保险杠左连接支架	Front bumper left connecting bracket	1		√
6	Q2734819	十字槽半圆头自攻螺钉	Philips self-tapping screw	2		√
7	B5400813	子母扣	Inlay clip	8		√
8	B2802111	发动机左下横挡泥板	Engine mudguard, left	1		√
9	B8402400	机仓锁拉索	Engine hood lock cable	1		√
10	B8402510	发动机罩锁体机仓锁	Engine hood lock	1		√
11	Q1840612	六角法兰面螺栓	Hex flange bolt	1		√
3-3	B8402811	发动机仓前密封条	Engine room front seal	1		√

5.03 Front attachment

[illegible]

5.04 Safety belt




5.04 Safety belt

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5811210B15	右前安全带卷收器总成	Front right safety belt retractor assy.	1	pale grey, ordinary	√
1	B5811210B1B15	右前安全带卷收器总成	Front right safety belt retractor assy.	1	pale grey, pretensioner	√
1	B5811210A2B15	右前安全带卷收器总成	Front right safety belt retractor assy.	1	pale grey, ordinary,E-mark	√
1	B5811210B2B15	右前安全带卷收器总成	Front right safety belt retractor assy.	1	pale grey, pretensioner,E-mark	√
1-1	B5811211	右前安全带卷收器	Front right safety belt retractor	1		
1-2	231-(7/16) " 42	六角法兰面螺栓	Hex flange bolt	1		
2	B5811114	安全带带头护盖	Safety belt end cap	2		√
3	231-0614	六角法兰面螺栓	Hex flange bolt	2		
4	231-(7/16) " 22	六角法兰面螺栓	Hex flange bolt	4		
5	231-1025TF3	六角法兰面螺栓	Hex flange bolt	2		√
6	B5811120	安全带高度调节器总成	Safety belt height adjuster	2		√
6	B5811120A2	安全带高度调节器总成	Safety belt height adjuster	2	E-mark	√
7	B5811110B15	左前安全带卷收器总成	Front left safety belt retractor assy.	1	pale grey, ordinary	√
7	B5811110B1B15	左前安全带卷收器总成	Front left safety belt retractor assy.	1	pale grey, pretensioner	√
7	B5811110A2B15	左前安全带卷收器总成	Front left safety belt retractor assy.	1	pale grey, ordinary,E-mark	√
7	B5811110B2B15	左前安全带卷收器总成	Front left safety belt retractor assy.	1	pale grey, pretensioner,E-mark	√
7-1	B5811111	左前安全带卷收器	Front left safety belt retractor	1		
7-2	231-(7/16) " 42	六角法兰面螺栓	Hex flange bolt	1		

5.04 Safety belt

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
8	B5812110B15	后安全带卷收器总成	Rear safety belt retractor assy.	2	pale grey	√
8	B5812110A2B15	后安全带卷收器总成	Rear safety belt retractor assy.	2	pale grey, E-mark	√
8-1	B5812111	后安全带卷收器	Rear safety belt retractor	2		
8-2	231-(7/16) " 34	六角法兰面螺栓	Hex flange bolt	2		
8-3	231-(7/16) " 22	六角法兰面螺栓	Hex flange bolt	2		
9	B5812230B15	后排双联锁扣总成	Rear safety belt twin buckle	1	pale grey	√
9	B5812230A2B15	后排双联锁扣总成	Rear safety belt twin buckle	1	pale grey, E-mark	√
10	B5812130B15	后排锁扣及腰带总成	Rear safety belt	1	pale grey	√
10	B5812130A2B15	后排锁扣及腰带总成	Rear safety belt	1	pale grey, E-mark	√


5.05 Ventilation



5.05 Ventilation

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5306400B14	右出风口总成	Right ventilation nozzle	1	deep grey	√
2	B5306520B16	中风口右风窗组件	Middle ventilation nozzle, right part	1	black	√
3	B5306510B16	中风口左风窗组件	Middle ventilation nozzle, left part	1	black	√
4	B5306300B14	左出风口总成	Left ventilation nozzle	1	deep grey	√

5.06 Floor attachment




5.06 Floor attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5110116	中地板右阻尼垫	Floor damper,right	1		
2	Q72716	地板Φ16橡胶堵盖	Floor rubber plug	2	Φ16	√
3	B5110115	中地板左阻尼垫	Floor damper,left	1		
4	B5110117	行李箱阻尼垫	Trunk damper	1		
5	B5107117	腰形堵盖	Plug	2		√
6	B5107123	油箱检修口盖	Fuel tank top cap	1		√
7	201-1020	六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer	2		
8	B7007000	后座椅支架	Rear seat bracket	1		
9	Q72745	地板Φ45橡胶堵盖	Floor rubber plug	6	Φ45	√
10	B2805111	后托钩	Rear hook	1		√
11	Q1401235	六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer	2		√
12	Q72730	地板Φ30橡胶堵盖	Floor rubber plug	2	Φ30	√
13	Q72725	Φ25橡胶堵盖	Floor rubber plug	7	Φ25	√
14	B5107124	加油管下隔架	Fuel filling pipe spacer	2		√
15	201-0820	六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer	4		
16	B5107122	后座椅挂钩塑料套	Rear hook sleeve	2		
17	B5107118	前地板中堵盖	Front floor middle plug	2		
18	B5107113	地板后左阻尼垫	Floor damper,rear left	1		

5.06 Floor attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
19	B5110111	地板前左阻尼垫	Floor damper,front left	1		
20	B8206000B16	驾驶员搁脚板	Driver's feet rest	1	black	
21	B5110112	地板前右阻尼垫	Floor damper,front right	1		
22	B5107111	Φ30堵片	Plug	12	Φ30	√
23	B5107112	Φ10橡胶堵盖	Rubber plug	6	Φ10	√
24	B5110114	地板后右阻尼垫	Floor damper,rear right	1		
25	B5109023	地毯前左内侧隔垫	Carpet spacer, left	1		
26	B5109023	地毯前右内侧隔垫	Carpet spacer, right	1		
27	B5109100B15	主地毯	Carpet assy.	1	pale grey	√
28	B5101210	备胎固定支架	Spare tyre fixing bracket	1		√
28-1	B5101214	备胎旋紧帽	Spare tyre cap 1	1		
28-2	B5101213	备胎缩紧盖背部毡垫	Felt washer	1		
28-3	B5101212	备胎缩紧盖	Spare tyre cap 2	1		√
28-4	B5101211	备胎固定杆	Spare tyre fixing rod	1		


5.07 Roof attachment



5.07 Roof attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5704112	车顶密封压条卡扣	Roof seal clip	4		√
2	B5704111	车顶左密封压条	Roof seal, left	1		√
3	B5704211	车顶右密封压条	Roof seal, right	1		√
4	B8215100B15	安全拉手	Safety handle	3		√
5	Q1840645	六角法兰面螺栓	Hex flange bolt	6		√
6	B5702111B15	顶蓬	Roof	1	pale grey	√
7	B8204200B15	右遮阳板总成	Right sunvisor	1	pale grey	√
8	B8204100B15	左遮阳板总成	Left sunvisor	1	pale grey	√
9	B8204030B15	遮阳板固定挂钩	Sunvisor fixing hook	2	pale grey	√
10	B8204020B15	右遮阳板大固定座组件	Right sunvisor fixing seat	1	pale grey	√
11	B8204010B15	左遮阳板大固定座组件	Left sunvisor fixing seat	1	pale grey	√
12	B5702012	顶蓬海绵块I	Roof foam cushion I	2		√
13	B5702013	顶蓬海绵块II	Roof foam cushion II	2		√


5.08 Roof attachment (Top window)



5.08 Roof attachment (Top window)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5702111B1B15	顶蓬	Roof	1	top window, pale grey	

5.09 Windsheild




5.09 Windsheild

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B8201000	内视镜	Rearview mirror	1		√
2	B8201121	内视镜底座	Rearview mirror seat	1		
3	B5206123	后挡风玻璃胶条	Rear wind-shield glass seal	1		√
4	B5206124	后挡风玻璃插片	Rear wind-shield glass insert	4		
5	B5206120	后挡风玻璃	Rear wind-shield glass	1		√
6	B5206116	挡风玻璃上限位卡 II	Wind-shield glass clip II	2		√
7	B5206115	挡风玻璃限位卡 I	Wind-shield glass clip I	2		√
8	B5206110	前挡风玻璃	Front wind-shield glass	1		√
9	333-0518	十字槽大盘头自攻螺钉	Philips self-tapping screw	2	only available with assembled parts	
10	B5206113	前挡风玻璃胶条	Front wind-shield glass seal	1		√
11	B5207330	洗涤喷嘴	Washer nozzle	2		√
12	B5207318	洗涤水管E	Washer hose E	1		
13	B5207317	两通水管节接头B	Two-way valve B	1		
14	B5205116	雨刮器摆臂安装螺母塑料盖帽	Wiper arm cap	2		√
15	127-0808	六角螺母和平垫圈组件	Hex nut and flat washer	2	only available with assembled parts	
16	B5205200	雨刮器左摆臂刮刷总成	Left wiper assy.	1		√
16-1	B5205210	雨刮器左摆臂组件	Left wiper arm	1		
16-2	B5205220	雨刮器左刮刷组件	Left wiper brush	1		

5.09 Windsheild

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
17	201-0630	六角头螺栓和垫圈组件	Hex bolt and flat washer	2	only available with assembled parts	
18	B5205100	雨刮器双连杆机构带电机总成	Wiper con-rod with front wiper motor assy.	1		√
19	B5205300	雨刮器右摆臂刮刷总成	Right wiper assy.	1		√
19-1	B5205310	雨刮器右摆臂组件	Right wiper arm	1		
19-2	B5205320	雨刮器右刮刷组件	Right wiper brush	1		
20	B5207100	洗涤壶组件	Washer can	1		√
21	Q1410620L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	3		√
22	B5207313	洗涤水管B	Washer hose B	1		
23	B5207312	两通水管接头A	Two-way valve A	1		
24	B5207311	洗涤水管A	Washer hose A	1		
25	B5207314	三通水管接头	T-valve	1		
26	B5207322	洗涤水管A固定卡扣条	Clip, washer hose A	1		
27	B5207316	洗涤水管D	Washer hose D	1		
28	B5207315	洗涤水管C	Washer hose C	1		
29	B8201100	内后视镜组件		1		
30	Q2140512F30	十字槽螺钉		1		
31	B8201121	内后视镜底座		1		


5.10 Sub-Instrument panel



5.10 Sub-Instrument panel

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5305300B16	中下部面罩总成	Middle-lower panel assy.	1	black	√
1-1	B5305311	中下部面罩本体	Middle-lower panel	1		√
1-2	B5305314	排档面板装饰框	Shift lever cover clamp	1		√
1-3	B5305312	排挡杆皮护套	Shift lever cover	1		√
2	B5305010B15	手刹盖板组件	Park braking panel	1	pale grey	√
3	B5305100B15	副仪表板总成	Sub-instrument panel assy.	1	pale grey	√
3-1	B5305111	副仪表板本体	Sub-instrument panel body	1		√
3-2	B5305114	前杯托盖外板	Outer panel, drinking cup placement	1		√
3-3	B5305115	前杯托盖内板	Outer panel, drinking cup placement	1		√
3-4	B5305117	前杯托盖翻转弹簧	Spring, drinking cup placement	3		√
3-5	B5305116	前杯托盖缓冲垫	Drinking cup placement damper	3		√
3-6	B5305118	前杯托盒隔板	Drinking cup placement spacer	1		√
3-7	B5305200	副仪表板杂物盒总成	Glove box, Sub-instrument panel	1		√
3-8	B5305214	开关锁舌	Box switch	1		√
3-9	B5305430	后烟灰缸总成	Rear ashtray assy.	1		√
4	B5305410B16	前烟灰缸总成	Front ashtray assy.	1	black	√


5.11 Rear bumper



5.11 Rear bumper

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B2804121	后保险杠缓冲块	Rear bumper damper	1		√
2	Q31208	板簧螺母	Nut	2		√
3	B2804131	后保险杠连接支架	Rear bumper bracket	2		√
4	400-1733	塑料卡扣	Plastic clip	4		√
5	B2804111	后保险杠	Rear bumper	1		√
6	Q150B0620T1F30	六角头螺栓	Hex bolt	2		√
7	Q1840820	六角法兰面螺栓	Hex flange bolt	2		√
8	Q40206	大垫圈	Big washer	2		√

5.12 Rear body attachment



5.12 Rear body attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5602311	行李舱后座隔热泡沫	Trunk heat insulator	1		
2	B5602211B16	后座椅饰板	Rear seat decoration	1	black	√
3	400-1868	塑料卡扣	Plastic clip	1		√
4	B5608415	搁物板左扬声器罩	Left speaker cap,shelf	1		
4	B5608416	搁物板右扬声器罩	Right speaker cap,shelf	1		
5	B5608400B15	搁物板护板	Shelf panel	1	pale grey	√
6	B5605113	行李箱缓冲垫	Trunk damper	1		√
7	B5608200B02	行李箱右侧护面组件	Trunk right fender	1	black	√
8	B5608314	行李箱右尾角盖板	Trunk right corner cover	1		√
9	B5600032	右缓冲块	Trunk right damper	1		√
10	Q1410620L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer	1		√
11	B5608112	检修盖板	Access panel	1		
12	B5602111B16	后裙板护板	Rear skirt fender	1	black	√
13	Q1840612	六角法兰面螺栓	Hex flange bolt	2		√
14	B5606110	行李箱锁体	Trunk lock	1		√
15	B5606212	行李箱锁拉杆	Trunk lock rod	1		
16	101-0505	六角法兰面螺母	Hex flange nut	2		
17	B5606210	行李箱锁锁芯	Trunk lock cylinder	1		


5.12 Rear body attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
18	B3921012A2	车后标识牌	Rear LOGO"LLL"	1		√
19	B5506210A2	后牌照饰板	License plate trim	1		√
20	B5608511B02	行李箱盖内饰板	Trunk lid interior	1	black	√
21	B5604401	行李箱密封条	Trunk seal	1		√
22	400-540	塑料卡扣	plastic clip	2		√
23	B5506203	中间安装卡扣毡垫	Felt washer	2		
24	B5606424	行李舱锁车内开关卡扣	Trunk buckle	1		√
25	B5101210	备胎固定支架	Spare tyre fixing bracket	1		√
26	B5608322	盖板背部定位支架	Spare tyre bracket	3		
27	B5608320	备胎盖板组件	Spare tyre cover	1		√
28	B5608311B02	行李箱地毯	Trunk carpet	1	black	√
29	B5608313	行李箱左尾角盖板	Trunk right corner cover	1		√
30	B5600031	行李舱盖左缓冲块	Trunk left damper	1		√
31	B5608100B02	行李舱左侧护面组件	Trunk left fender	1	black	√
32	B5606430	加油口锁体	Fuel filler lock	1		
33	B5606423	行李舱锁车内开关拉索	Trunk lid cable	1		
34	B5606420	行李箱\油箱口拉索开关总成	Cable switch,trunk/fuel filler	1		
35	400-1932	塑料卡扣	plastic clip	3		√

5.12 Rear body attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
36	B5606427	加油口锁车内开关拉索	Fuel filler cable	1		
37	B5605011	行李箱左弹力扭杆	Trunk left torsion rod	1		√
38	400-244	塑料卡扣	plastic clip	11		√
39	B5605012	行李箱右弹力扭杆	Trunk right torsion rod	1		√

5.13 Rear seat




5.13 Rear seat

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B7005400B15	后座椅右侧背	Rear seat right side rest	1	woolen, pale grey	√
1	B7005400A2B15	后座椅右侧背	Rear seat right side rest	1	leather, pale grey	√
1	B7005400A3B15	后座椅右侧背	Rear seat right side rest	1	leatherette, pale grey	√
2	B7005200B15	后座椅右靠背	Rear seat right back rest assy.	1	woolen, pale grey	√
2	B7005200A2B15	后座椅右靠背	Rear seat right back rest assy.	1	leather, pale grey	√
2	B7005200A3B15	后座椅右靠背	Rear seat right back rest assy.	1	leatherette, pale grey	√
2-1	B7008100	后座椅头枕	Rear seat pillow	1	woolen	
2-1	B7008100A2	后座椅头枕	Rear seat pillow	1	leather	√
2-2	B7005211	后座椅右靠背本体	Rear seat right back rest	1	woolen	√
2-2	B7005211A2	后座椅右靠背本体	Rear seat right back rest	1	leather	√
3	B7005100B15	后座椅左靠背	Rear seat left back rest assy.	1	woolen, pale grey	√
3	B7005100A2B15	后座椅左靠背	Rear seat left back rest assy.	1	leather, pale grey	√
3	B7005100A3B15	后座椅左靠背	Rear seat left back rest assy.	1	leatherette, pale grey	√
3-1	B7008100	后座椅头枕	Rear seat pillow	1	woolen	
3-1	B7008100A2	后座椅头枕	Rear seat pillow	1	leather	√
3-2	B7005111	后座椅左靠背本体	Rear seat left back rest	1	woolen	
3-2	B7005111A2	后座椅左靠背本体	Rear seat left back rest	1	leather	√
3-3	B7006100	中央扶手总成	Middle handrail	1	woolen	

5.13 Rear seat

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
3-3	B7006100A2	中央扶手总成	Middle handrail	1	leather	√
4	B7005300B15	后座椅左侧背	Rear seat left side rest	1	woolen, pale grey	√
4	B7005300A2B15	后座椅左侧背	Rear seat left side rest	1	leather, pale grey	√
4	B7005300A3B15	后座椅左侧背	Rear seat left side rest	1	leatherette, pale grey	√
5	B7003000B15	后座椅座垫	Rear seat cushion	1	woolen, pale grey	√
5	B7003000A2B15	后座椅座垫	Rear seat cushion	1	leather, pale grey	√
5	B7003000A3B15	后座椅座垫	Rear seat cushion	1	leatherette, pale grey	√
6	B7007111	左靠背左铰链	Left hinge, rear seat	1		√
7	B7007300	后座椅靠背中间铰链	Middle hinge, rear seat	1		√
8	B7007211	右靠背右铰链	Right hinge, rear seat	1		√


5.14 Front bumper



5.14 Front bumper

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B2803121	前保险杠缓冲块	Front bumper damper	1		√
2	400-1733	塑料卡扣	Plastic clip	1		√
3	Q32006	六角法兰面螺母	Hex flange nut	2		√
4	Q150B620T1F30	六角法兰面螺栓	Hex flange bolt	2		
5	B2803133	带胶头螺栓	Plastic head bolt	2	M6	√
6	Q2706316	六角法兰面螺钉	Hex flange screw	4		√
7	B2803132	前保险杠右连接支架	Right bracket,front bumper	1		√
8	B3921011A2	车前标识牌	Front LOGO"LLL"	1		√
9	B2803150A2	前格栅	Front grille	1		√
10	B2803131	前保险杠左连接支架	Left bracket,front bumper	1		√
11	B2803110	前保险杠组件	Front bumper	1		√
12	Q39748202	簧片螺母	Spring nut	6		√
13	Q40206	大垫圈	Big washer	6		√
14	Q2714825	十字槽凹穴六角头自攻螺钉	Philips self-tapping screw	6		√
15	Q40206	大垫圈	Big washer	2		√
16	Q2215519F31	十字槽盘头子攻螺钉和大垫圈组合件	Philips screw with washer	2		√

5.15 Front body attachment




5.15 Front body attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	400-136	塑料卡扣	Plastic clip	2	cancelled	
2	B5304220	右通风盖板组件	Ventilation right cover	1		√
3	B5304222	风窗右盖板密封条	Ventilation right cover seal	1		√
4	B5304241	前挡风玻璃下流水槽	Front windshield water deflector	1		√
5	B5310120	发动机仓隔热垫	Engine room heat insulator	1		√
6	B5310110	前围隔热垫总成	Front cowl heat insulator	1		√
7	B5302200	仪表板管梁总称	Instrument panel beam assy.	1		√
7-1	B5306230	仪表板横梁组件	Instrument panel beam	1		√
7-2	B5306220	仪表板横梁右固定板组件	Right fixing plate,instrument panel beam	1		√
7-3	B5306270	仪表板横梁拉杆	Drag link,instrument panel beam	1		√
7-4	B5306210	仪表板横梁左固定板组件	Left fixing plate,instrument panel beam	1		√
7-5	B5306250	仪表板横梁左撑杆组件	Left stay bar,instrument panel beam	1		√
7-6	B5306260	仪表板横梁右撑杆组件	Right stay bar,instrument panel beam	1		√
8	B5301019	前围板大堵盖 (R)	Front cowl bigger plug,right	1		
9	B5301012	Φ25堵片	Plug	2	Φ25	√
10	B5301021	前围板小堵盖	Front cowl smaller plug	2		
11	B5301018	前围板大堵盖 (L)	Front cowl bigger plug,left	1		
12	B5307112	Φ10橡胶堵盖	Rubber plug	3	Φ10	√

5.15 Front body attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
13	B5301011	前围Φ18橡胶堵盖	Front cowl rubber plug	2	Φ18	√
14	B5304212	风窗左盖板密封条	Ventilation left cover seal	1		√
15	B5304210	右通风盖板组件	Ventilation left cover	1		√
16	B5304231	风窗盖板膨胀卡扣	Ventilation cover cap	2		
17	B8402810	发动机仓盖隔热垫	Engine hood heat insulator	1		√

5.16 Driver's seat




5.16 Driver's seat

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B6800100B15	驾驶员座椅总成	Front passenger's seat assy.	1	woolen,pale grey,without waist adjuster	√
1	B6800100A2B15	驾驶员座椅总成	Front passenger's seat assy.	1	woolen,pale grey,with waist adjuster	√
1	B6800100A3B15	驾驶员座椅总成	Front passenger's seat assy.	1	leather,pale grey,with waist adjuster	
1	B6800100A4B15	驾驶员座椅总成	Front passenger's seat assy.	1	leatherette,pale grey,with waist adjuster	√
1	B6800100B1B15	驾驶员座椅总成	Front passenger's seat assy.	1	leather,pale grey,with waist adjuster, heater	√
1-1	B6808100	前座椅头枕	Front seat pillow	1	woolen	
1-1	B6808100A2	前座椅头枕	Front seat pillow	1	leather	√
1-2	B6802116	驾驶员座椅右盖板	Driver's seat cap,right	1		√
1-3	B6802119	调腰器提钮盖板	Waist adjuster cap	1		√
1-4	B6802115	驾驶员座椅左盖板	Driver's seat cap,left	1		√
1-5	B6802118	座椅靠背角度提钮盖板	Backrest adjuster cap, driver's seat	1		√
1-6	B6802117	座垫高度调节旋钮盖板	Driver's Seat cushion adjuster cap	1		√
1-7	B6804000	驾驶员座滑轨总成	Driver's seat slide	1		√
1-8	B6802111B15	驾驶员座椅下护板	Driver's seat bottom fender	1	pale grey	√
1-9	B6802114B15	驾驶员座椅后脚盖	Driver's seat stand,rear	1	pale grey	√
1-10	B6802113B15	驾驶员座椅前脚盖	Driver's seat stand,front	1	pale grey	√
1-11	B6800110	驾驶员座本体总成	Driver's seat body	1		√
2	Q2101030TF2	内六角花形圆柱头螺钉	Inner hex screw	4		√

5.16 Driver's seat

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
3	B5811130B15	左前安全带锁扣总成	Front left safety belt buckle	1	pale grey	√
3	B5811130A2B15	左前安全带锁扣总成	Front left safety belt buckle	1	pale grey, E-mark	√
4	231-7/1622	六角法兰面螺栓	Hex flange bolt	1		


5.17 Front passenger's seat



5.17 Front passenger's seat

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B6900100B15	副驾驶座椅总成	Front passenger's seat assy.	1	woolen,pale grey	√
1	B6900100A2B15	副驾驶座椅总成	Front passenger's seat assy.	1	leather,pale grey	√
1	B6900100A3B15	副驾驶座椅总成	Front passenger's seat assy.	1	leatherette,pale grey	√
1-1	B6808100	前座椅头枕	Front seat pillow	1	woolen	
1-1	B6808100A2	前座椅头枕	Front seat pillow	1	leather	√
1-2	B6900110	副驾驶员座本体总成	Front passenger's seat body	1		√
1-3	B6902115	副驾驶员座椅左盖板	Front passenger's seat cap,left	1		√
1-4	B6902116	副驾驶员座椅右盖板	Front passenger's seat cap,right	1		√
1-5	B6902118	座椅靠背角度提钮盖板	Front passenger's seat backrest adjuster cap	1		√
1-6	B6902111B15	副驾驶座椅下护板	Front passenger's seat bottom fender	1	pale grey	√
1-7	B6904000	副驾驶员座滑轨总成	Front passenger's seat slide	1		√
1-8	B6902113B15	副驾驶座椅前脚盖	Front passenger's seat stand,front	1	pale grey	√
1-9	B6902114B15	副驾驶座椅后脚盖	Front passenger's seat stand,rear	1	pale grey	√
2	Q2101030TF2	内六角花形圆柱头螺钉	Inner hex screw	4		√
3	B5811230B15	右前安全带锁扣总成	Front right safety belt buckle	1	pale grey	√
3	B5811230A2B15	右前安全带锁扣总成	Front right safety belt buckle	1	pale grey, E-mark	√
4	231-7/1622	六角法兰面螺栓	Hex flange bolt	1		

5.18 Rear right door attachment



5.18 Rear right door attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B6205230A2	右后侧车门门把手总成	Outer handle assy, rear right door	1		√
1-1	B6105131	侧车门门把手	Outer handle	1		√
1-2	B6205222	右后侧车门门把手B	Door outer handle B, rear right door	1		√
1-3	B6105133	侧门门把手塑料垫圈B	Plastic ring B, door handle	1		√
1-4	B6105132	侧门门把手塑料垫圈A	Plastic ring A, door handle	1		√
1-5	B6205225	右后侧车门门把手座	Handle seat, rear right door	1		√
2	B6200220	右后侧车门活动导轨总成	Glass rail assy, rear right door	1		√
2-1	B6200221	右后侧车门玻璃活动导轨	Glass rail, rear right door	1		√
2-2	B6200222	右后侧车门玻璃活动导轨上支架	Glass rail bracket, rear right door	1		√
2-3	321-0508	十字槽沉头螺钉	Philips screw	1		
2-4	B6200227	右后车门导轨胶套	Glass rail sleeve, rear right door	1		√
3	B6203212	右后门三角玻璃	Triangular glass, rear right door	1		√
4	Q1840610	六角法兰面螺栓	Hex flange bolt	1		√
5	Q2400820	十字槽沉头螺钉和锥形锁紧垫圈组合	Philips screw and washer	2		√
6	B6109112	侧车门缓冲块	Door damper	2		√
7	B6105141	侧车门锁扣组件	Door buckle component	1		√
8	B6207213	右后侧车门三角玻璃密封条	Triangular glass seal, rear right door	1		√
9	B6207211	右后侧车门玻璃泥槽	Glass seal, rear right door	1		√


5.18 Rear right door attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
10	B6207214	右后侧车门密封条	Rear right door seal	1		√
11	B6107114	侧车门密封条卡扣A	Door seal clip A	15		√
12	B6202217	右后门扶手软垫板	Inner handrail cushion, rear right door	1		
13	B6202118	后门螺钉堵盖	Rear right door screw cap	1		√
14	Q2734216	十字槽大半圆头自攻螺钉	Philips self-tapping screw	1		√
15	B3746400	右后门扶手板开关总成	Inner handrail with switches, rear right door	1		√
16	Q2734216	十字槽盘半圆头自攻螺钉	Philips self-tapping screw	1		√
17	B6105400	右侧车门内扣手总成	Inner handle, rear right door	1		√
18	B6202211	右后门内护板装饰条	Interior trim, rear right door	1		√
19	B6202210B97	右后门内护板总成	Rear right door interior	1	grey, upper deep lower pale	√
20	400-540	塑料卡扣	Plastic clip	8		√
21	B6202020	右后门防雨帘组件	Rain shield, rear right door	1		√
22	Q2540508	十字沉头螺钉	Philips screw	2		√
23	Q398B03	塑料螺母	Plastic nut	2		√
24	Q1840610	六角法兰面螺栓	Hex flange bolt	4		√
25	B6206220	右后侧车门下铰链组件	Lower hinge, rear right door	1		√
26	Q1840820	六角法兰面螺栓	Hex flange bolt	4		√
27	Q1840816T1F30	六角法兰面螺栓	Hex flange bolt	1		√

5.18 Rear right door attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
28	B6209100	后车门限位器	Rear door stopper	1		√
29	Q1840820	六角法兰面螺栓	Hex flange bolt	4		√
30	B6206210	右后侧门上铰链组件	Upper hinge, rear right door	1		√
31	B6203200	右后侧车门车窗玻璃	Rear right door glass	1		√
32	B6205210	右后门锁体	Rear door lock	1		√
32	B6205210B1	右后门锁体	Rear door lock	1	central lock	√
33	B6207212	右后侧车门玻璃外切水条	Weather Strip, rear right door	1		√
34	B6204200	右后侧车门玻璃升降器总成	Glass lifter, rear right door	1		√

5.19 Front right door



5.19 Front right door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B6105230A2	右前侧车门门把手总成	Outer handle assy, front right door	1		√
1-1	B6105131	侧车门门把手	Outer handle	1		√
1-2	B6105234	右前侧车门门把手座	Handle seat, front right door	1		√
1-3	B6105133	侧车门门把手塑料垫圈B	Plastic ring B, door handle	1		√
1-4	B6105132	侧车门门把手塑料垫圈A	Plastic ring A, door handle	1		√
2	B6103200B1	右前侧车门车窗玻璃	Front right door glass	1		√
3	B6100220	右前侧车门活动导轨总成	Glass rail assy, front right door	1		√
3-1	B6100221	右前侧车门玻璃活动导轨	Glass rail, front right door	1		√
3-2	B6100222	右前侧车门玻璃活动导轨下支架	Glass rail bracket, front right door	1		√
3-3	Q1840610	六角法兰面螺栓	Hex flange bolt	1		√
4	Q1840612T1F30	六角法兰面螺栓	Hex flange bolt	2		√
5	B6104200B1	右前侧车门玻璃升降器总成	Glass lifter, front right door	1		√
6	B6107212	右前侧车门玻璃外切水条	Weather Strip, front right door	1		√
7	B6105210	右前侧门锁体	Front right door lock	1	DX	√
7	B6105210B1	右前侧门锁体	Front right door lock	1	LX, EX	√
8	Q2560620F13	十字槽半沉头螺钉	Philips screw	3		√
9	B8202200	右外后视镜总成	Right wing mirror	1	Dongguang	√
9	B8202200B1	右外后视镜总成	Right wing mirror	1	Donnelly	√


5.19 Front right door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
10	Q2400820	十字槽沉头螺钉和锥形锁紧垫圈组合	Philips screw and washer	2		√
11	B6105141	侧车门锁扣组件	Door buckle component	1		√
12	B6109112	侧车门缓冲块	Door damper	3		√
13	Q1840610	六角法兰面螺栓	Hex flange bolt	1		√
14	B6105318	塑料螺母	Plastic nut	1		√
15	309-3516	十字槽盘头螺钉和平垫圈组合件	Philips screw with washer	1		
16	Q1840610	六角法兰面螺栓	Hex flange bolt	8		√
17	Q1840616T1F30	六角法兰面螺栓	Hex flange bolt	2		√
18	Q1840816T1F30	六角法兰面螺栓	Hex flange bolt	1		√
19	B6109100	前车门限位器	Front door stopper	1		√
20	B6107211	右前侧车门玻璃泥槽	Glass seal,front right door	1		√
21	B6107213	右前侧车门密封条	Front right door seal	1		√
22	B6107114	侧车门密封条卡扣A	Door seal clip A	15		√
23	B6102020	右前门防雨帘组件	Rain shield,front right door	1		√
24	400-540	塑料卡扣	Plastic clip	8		√
25	B6102214	右前门上装饰条	Interior trim,front right door	1		√
26	B6102217	右前门扶手垫板	Inner handrail cushion,front right door	1		
27	Q2734216	十字槽盘半圆头自攻螺钉	Philips self-tapping screw	1		√

5.19 Front right door

[illegible]

5.20 Rear left door



5.20 Rear left door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B6205130A2	左后侧车门门把手总成	Outer handle assy, rear left door	1		√
1-1	B6105131	侧车门门把手	Outer handle	1		√
1-2	B6205125	左后侧车门门把手座	Handle seat, rear left door	1		√
1-3	B6105132	侧门门把手塑料垫圈A	Plastic ring B, door handle	1		√
1-4	B6105133	侧门门把手塑料垫圈B	Plastic ring A, door handle	1		√
1-5	B6205122	左后侧车门门把手B	Door outer handle B, rear left door	1		√
2	B6200120	左后侧车门活动导轨总成	Glass rail assy, rear left door	1		√
2-1	B6200121	左后侧车门玻璃活动导轨	Glass rail, rear left door	1		√
2-2	B6200127	左后车门导轨胶套	Glass rail sleeve, rear left door	1		√
2-3	B6200122	左后侧车门玻璃活动导轨上支架	Glass rail bracket, rear left door	1		√
2-4	Q2540608	十字槽沉头螺钉	Philips screw	1		
3	B6204100	左后侧车门玻璃升降器总成	Glass lifter, rear left door	1		√
4	B6207112	左后侧车门玻璃外切水条	Weather Strip, rear left door	1		√
5	B6205110	左后门锁体	Rear left door lock	1		√
5	B6205110B1	左后门锁体	Rear left door lock	1	central locking	√
6	B6203100	左后侧车门车窗玻璃	Rear left door glass	1		√
7	B6206110	左后侧门上铰链组件	Upper hinge, rear left door	1		√
8	Q1840820	六角法兰面螺栓	Hex flange bolt	8		√


5.20 Rear left door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
9	Q1840816T1F30	六角法兰面螺栓	Hex flange bolt	1		√
10	B6209100	后车门限位器	Rear door stopper	1		√
11	Q1840616T1F30	六角法兰面螺栓	Hex flange bolt	2		√
12	B6206120	左后侧车门下铰链组件	Lower hinge,rear left door	1		√
13	Q1840610	六角法兰面螺栓	Hex flange bolt	4		√
14	Q398B03	塑料螺母	Plastic nut	2		√
15	Q2540508	十字沉头螺钉	Philips screw	2		√
16	B6202010	左后门防雨帘组件	Rain shield,rear left door	1		√
17	400-540	塑料卡扣	Plastic clip	7		√
18	B6202110B97	左后门内护板总成	Rear left door interior	1	grey, upper deep lower pale	√
19	B6105300	左侧车门内扣手总成	Inner handle, left door	1		√
20	Q2734216	十字槽大半圆头自攻螺钉	Philips self-tapping screw	1		√
21	B3746300	左后门扶手板开关总成	Inner handrail with switches,rear left door	1		√
22	Q2734216	十字槽半圆头自攻螺钉	Philips self-tapping screw	1		√
23	B6202118	后门螺钉堵盖	Rear door screw cap	1		√
24	B6202117	左后门扶手软垫板	Inner handrail cushion,rear left door	1		
25	B6202111	左后门内护板装饰条	Interior trim,rear left door	1		√
26	B6107114	侧车门密封条卡扣A	Door seal clip A	15		√

5.20 Rear left door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
27	B6207114	左后侧车门密封条	Front right door seal	1		√
28	B6207111	左后侧车门玻璃泥槽	Glass seal, rear left door	1		√
29	B6207113	左后侧车门三角玻璃密封条	Triangular glass seal, rear left door	1		√
30	B6105141	侧车门锁扣组件	Door buckle component	1		√
31	B6109112	侧车门缓冲块	Door damper	2		√
32	Q2400820	十字槽沉头螺钉和锥形锁紧垫圈组合	Philips screw and washer	2		√
33	224-0616	六角头头部带十字槽螺栓	Philips hex bolt	1		
34	B6203112	左后门三角玻璃	Triangular glass, rear left door	1		√

5.21 Front left door



5.21 Front left door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B6105130A2	左前侧车门门把手总成	Outer handle assy, rear left door	1		√
1-1	B6105134	左前侧车门门把手座	Handle seat, rear left door	1		√
1-2	B6105132	侧车门门把手塑料垫圈A	Plastic ring B, door handle	1		√
1-3	B6105133	侧车门门把手塑料垫圈B	Plastic ring A, door handle	1		√
1-4	B6105131	侧车门门把手	Outer handle	1		√
2	B6103100B1	左前侧车门车窗玻璃	Front left door glass	1		√
3	B6100120	左前侧车门活动导轨总成	Glass rail assy, front left door	1		√
3-1	B6100121	左前侧车门玻璃活动导轨	Glass rail, front left door	1		√
3-2	B6100122	左前侧车门玻璃活动导轨下支架	Glass rail bracket, front left door	1		√
3-3	224-0616	六角头头部带十字槽螺栓	Philips hex bolt	1		
4	Q1840610	六角法兰面螺栓	Hex flange bolt	2		√
5	B6104100B1	左前侧车门玻璃升降器总成	Glass lifter, front left door	1		√
6	B6107112	左前侧车门玻璃外切水条	Weather Strip, front left door	1		√
7	Q2560620F13	十字槽半沉头螺钉	Philips screw	3		√
8	B6105110	左前侧门锁体	Front left door lock	1	DX	√
8	B6105110B1	左前侧门锁体	Front left door lock	1	LX, EX	√
9	B8202100	左外后视镜总成	Left wing mirror	1	Dongguang	√
9	B8202100B1	左外后视镜总成	Left wing mirror	1	Donnelly	√


5.21 Front left door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
10	B6109100	前车门限位器	Front door stopper	1		√
11	Q1840816T1F30	六角法兰面螺栓	Hex flange bolt	1		√
12	Q1840616T1F30	六角法兰面螺栓	Hex flange bolt	2		√
13	Q1840610	六角法兰面螺栓	Hex flange bolt	9		√
14	B6105318	塑料螺母	Plastic nut	1		√
15	309-3516	十字槽盘头螺钉和平垫圈组合件	Philips screw with washer	1		
16	224-0616	六角头头部带十字槽螺栓	Philips hex bolt	2		
17	B6109112	侧车门缓冲块	Door damper	3		√
18	B6105141	侧车门锁扣组件	Door buckle component	1		√
19	Q2400820	十字槽沉头螺钉和锥形锁紧垫圈组合	Philips screw and washer	2		√
20	B6107111	左前侧车门玻璃泥槽	Glass seal,front left door	1		√
21	B6107114	侧车门密封条卡扣A	Door seal clip A	15		√
22	B6107113	左前侧车门密封条	Front left door seal	1		√
23	B6102010	左前门防雨帘组件	Rain shield,front left door	1		√
24	400-540	塑料卡扣	Plastic clip	8		√
25	B6102110B97	左前门内护板总成	Front left door interior	1	grey, upper deep lower pale	√
26	B6102114	左前门上装饰条	Interior trim,front left door	1		√
27	B6105300	左侧车门内扣手总成	Inner handle, left door	1		√

5.21 Front left door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
28	309-3516	十字槽盘头螺钉和平垫圈组合件	Philips screw with washer	1		
29	B3746100	左前门扶手板开关总成	Inner handrail with switches,front left door	1		√
30	Q2734216	十字槽半圆头自攻螺钉	Philips self-tapping screw	1		√
31	B6102119	前门螺钉堵盖	Front door screw cap	1		√
32	B6102117	左前门扶手垫板	Inner handrail cushion,front left door	1		


5.22 Glove box



5.22 Glove box

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5303100B15	仪表板杂物箱总成	Glove box assy.	1	pale grey	√
1-1	B5303112	杂物箱加强面板	Glove box panel	1		
1-2	B5306020	气体阻尼器	Glove box damper	1		√
1-3	B5303110	杂物箱锁组件	Glove box lock	1		
1-3-1	B5303117	杂物箱锁拉手板	Glove box handle	1		
1-3-2	B5303114	杂物箱锁本体	Glove box lock body	1		
1-3-3	B5303115	杂物箱锁舌	Glove box locking dog	1		
1-4	B5303111	物箱本体	Glove box body	1		


5.23 LOGO



5.23 LOGO

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B3921011A2	车前标识牌	Front LOGO"LLL"	1		√
2	B3921012A2	车后标识牌	Rear LOGO"LLL"	1		√
3	B3102513	轮毂中心标牌	Wheel LOGO	4		
4	B3921015	车尾车型标识牌	Rear model LOGO"LF7162"	1	for Tritec engine	
5	B3921019A2	车尾车型标识 II	Rear model LOGO"620"	1		
6	L3921013B1	车尾车名标识牌	Rear LOGO"LIFAN"	1		√
7	L3921018	车侧门标牌	Side LOGO"1.6L"	1		√
8	BAC3921015	车尾车型标识牌	Rear model LOGO"LF7162C"	1	for LF481 engine	

5.24 Instrument panel




5.24 Instrument panel

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5306125B14	副安全气囊盖板	Passengers airbag panel	1	deep grey, for configuration without passenger's airbag	√
2	B5306117	光敏传感器堵盖	Cap, optical sensor	1		
3	B5306118	阳光传感器堵盖	Cap, sunlight sensor	1		
4	Q1840616T1F30	六角法兰面螺栓	Hex flange bolt	6		√
5	B5306110B14	仪表板上护板	Instrument panel fender,upper	1	deep grey	√
6	Q2734816F30	十字槽大半圆头自攻螺钉	Philips self-tapping screw	2		√
7	B5306011B16	组合仪表罩	Instrument cluster cover	1	black	√
8	Q2734216	十字槽大半圆头自攻螺钉	Philips self-tapping screw	2		√
9	400-0243	塑料卡扣	Plastic clip	2		√
10	B5306137	组合仪表安装卡簧	Instrument cluster snap spring	2		
11	B5306820C03	仪表板右装饰条组件	Instrument panel trim assy,right	1	peachwood	√
11-1	B5306821	仪表板右装饰条	Instrument panel trim,right	1		
11-2	B5305315	塑料卡扣	Plastic clip	12		
12	B5306810C03	仪表板左装饰条组件	Instrument panel trim assy,left	1	peachwood	√
12-1	B5306811	仪表板左装饰条	Instrument panel trim,left	1		
13	B5306130B15	仪表板下护板	Instrument panel fender,lower	1	pale grey	√
14	Q2706316	六角法兰面螺钉	Hex flange screw	3		√
15	B5306711B14	转向柱上护罩	Steering pillar shield upper	1	deep grey	√

5.24 Instrument panel

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
16	B5306712B14	转向柱下护罩	Steering pillar shield lower	1	deep grey	√
17	Q2734816	十字槽大半圆头自攻螺钉	Philips self-tapping screw	2		√
18	Q2214219	十字槽盘头自攻螺钉和大垫圈组合	Philips screw with washer	1		√
19	B5306132	票据盒	Notes box	1		√
20	B5306134	票据盒缓冲胶套	Notes box damper	2		
21	B5306133	票据盒锁紧簧片	Notes box locker	1		
22	B5306138	杂物箱锁扣	Glovebox buckle	1		
	B5306000	仪表台总成	Instrument panel assy.	1		

Air conditioner assy. (for LF481 engine)



Air conditioner assy. (for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B8105100	冷凝器总成	Condensor	1		√
1-1	Q184A0612	六角法兰面螺栓	Hex flange bolt	2		√
1-2	B8105130	冷凝器芯子组件	Condensor core	1		
2	Q1400625	六角头螺栓与平垫圈组合件	Hex bolt and flat washer	2		√
3	B8108331	高压硬管加注口盖	Filler cap,high-pressure tube	1		√
4	B8108300	空调高压硬管总成	High-pressure tube	1		√
5	BAC8108100	空调高压软管总成	High-pressure hose	1		√
6	B8108322	空调高压硬管支架A	High-pressure tube bracket A	1		√
7	Q184A0612	六角法兰面螺栓	Hex flange bolt	1		√
8	Q2300512	十字槽盘头螺钉与平垫圈组合件	Philips screw with washer	1		√
9	BAC8108500	空调低压软管总成	Low-pressure hose	1		√
10	B8108310	空调高低压管夹	Clamp	1		√
11	Q1400616	六角头螺栓与平垫圈组合件	Hex bolt and flat washer	1		√
12	Q340B06	1型六角螺母	Hex nut	2		√
13	B8108510	空调高低压管支架总成	Pipe bracket assy.	1		√
13-1	B8108513	双头缓冲螺栓	Stud	1		√
13-2	B8108512	支撑板	Support plate	1		√
13-3	B8108514	空调高低压管支架	Pipe bracket	1		√


Air conditioner assy. (for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
14	B8111014	高/低压管隔离圈	Separate plate,H/L pressure pipes	1		√
15	127-0607	六角螺母和平垫圈组合件	Hex nut and flat washer	5		√
16	B8100100	HVAC总成	HVAC assy.	1		√
17	B8111012	暖气进/出管隔离圈	Separate plate,I/O heater pipes	1		√
18	Q67525	A型蜗杆式弹性环箍	Hoop	2		√
19	BAC8108013	暖风机出水管	Heater outtake pipe	1		√
20	BAC8108012	暖风机进水管	Heater intake pipe	1		√
21	Q67525	A型蜗杆式弹性环箍	Hoop	2		√
22	Q184A08100	六角法兰面螺栓	Hex flange bolt	1		
23	LBA8103101B1	空调压缩机支架	Compressor bracket	1		√
24	LBA8103100B1	空调压缩机总成	Compressor	1		√
25	Q18408105	六角法兰面螺栓	Hex flange bolt	4		√
26	Q1840835	六角法兰面螺栓	Hex flange bolt	2		√
27	LBA8103120	压缩机皮带张紧轮组件	Compressor tensioner	1		√
27-1	Q33010	自锁螺母	Lock nut	2		√
27-2	LBA8103123	张紧轮防护罩	Tensioner shield	1		√
27-3	LBA8103124	皮带轮	Pulley	1		
27-4	LBA8103122	主轴轴套	Shaft sleeve	1		√

Air conditioner assy. (for LF481 engine)

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
27-5	LBA8103121	主轴	Main shaft	1		√
27-6	Q14608100Q	六角头螺栓、弹簧垫圈和平垫圈组合件	Hex bolt and washers	1		√
28	LBA8103109	压缩机皮带	Compressor belt	1		√


6.02 Ventilations



6.02 Ventilations

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B5306415	除霜风口中段风道	Defroster ventilation,middle part	1		
2	B5306414	左右风口风管和除霜风口风道	L/R ventilation assy.	1		
3	B5306424	风道左右风口连接卡扣	Clip	2		√
4	B8121431	乘客席左风管前段	Left ventilation fore part,Passenger side	1		√
5	B8121432	乘客席左风口后段	Left ventilation rear part,Passenger side	1		√
6	B8121442	乘客席右风口后段	Right ventilation rear part,Passenger side	1		√
7	B8121441	乘客席右风管前段	Right ventilation fore part,Passenger side	1		√
8	B5306411	连接卡扣	Connect clip	2		
9	B5306412	中风口风管	Middle ventilation	1		
10	Q2213513	左右风管连接螺钉	Connect screw	2		


6.03 Evaporator



6.03 Evaporator

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B8107100	蒸发器暖风机总成	Evaporator heater	1		
1-1	B8114200	蒸发器温度传感器	Evaporator Temperature sensor	1		√
1-2	B8106010	膨胀阀	Expansion Valve	1		√
1-3	B8107110	蒸发器芯子组件	Evaporator core	1		√
1-4	B3745300	吹风模式执行器	Actuator,blow Mode	1		√
1-5	B3745400	冷暖风执行器安装组件	Actuator assy,A/C Mode	1		√
1-5-1	B3745411	冷暖风执行器	Actuator,A/C Mode	1		√
1-5-2	B3745412	冷暖风执行器安装支架	Actuator bracket	1		√
1-6	Q2706316A	六角法兰面自攻螺钉	Hex flange tapping screw	5		√
1-7	B8107140	蒸发器左壳体	Evaporator shell,L	1		√
1-8	B8107150	蒸发器右壳体	Evaporator shell,R	1		√
1-9	B8107160	暖风机散热器总成	Heater radiator	1		√
1-10	Q2704216A	十字槽沉头螺钉	Philips screw	9		√
1-11	B8107151	暖风机散热器进出管管夹	Clamp	1		√

6.04 Blower



6.04 Blower

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	SUPPLY
1	B8104100	鼓风机总成	Blower assy.	1		
1-1	B3745100	鼓风机电机	Blower motor	1		√
1-2	B8121150	进风箱上壳体	Bellow shell,upper	1		√
1-3	B8121160	进风箱下壳体	Bellow shell,lower	1		√
1-4	B3745200	内外循环风执行器	Actuator,blower	1		√
1-5	B8211170	空滤器	Air filter,blower	1		√
1-6	B3745180	空调鼓风机调速模块	Governor,blower	1		√
1-7	Q2704216A	十字槽沉头螺钉	Philips screw	5		√
1-8	Q2706316A	六角法兰面自攻螺钉	Hex flange tapping screw	8		√
	B8121100	进风箱总成	Bellow assy.	1		

LF7162/LF7162C spare parts price list

(Version:200904)

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
101-1212T2F3	六角法兰面螺母	Hex flange nut		PCS	0.74
101-1414T13F3	六角法兰面螺母	Hex flange bolt		PCS	1.58
101-1514T13F3	六角法兰面螺母	Hex flange nut		PCS	1.48
101B-1010T13F3	六角法兰面螺母	Hex flange nut		PCS	1.16
101B-1212T13F3	六角法兰面螺母	Hex flange bolt		PCS	1.42
124-1417T13F3	六角法兰面开槽螺母	Hex flange nut		PCS	1.60
125-1215	六角开槽薄螺母	Hex nut		PCS	1.03
127-0607	六角螺母和平垫圈组合件	Hex nut and flat washer		PCS	1.32
178-0806	B型板簧螺母	"B"spring nut		PCS	1.12
189-1235T13F6	车轮螺母组件	Wheel bolt		PCS	8.98
204-0814T1F3	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer		PCS	0.84
204-0825T1F3	六角头螺栓和锥形弹簧垫圈组合件	Hex bolt and taper springness washer		PCS	1.50
221-1018	带孔螺栓	Eye bolt	M10×1×18	PCS	0.66
231-1016TF3	六角法兰面螺栓	Hex flange bolt		PCS	0.78
231-1025TF3	六角法兰面螺栓	Hex flange bolt		PCS	0.97
231-1025TF30	六角法兰面螺栓	Hex flange bolt		PCS	0.49
231-1030TF30	六角法兰面螺栓	Hex flange bolt		PCS	0.68
231-1035TF3	六角法兰面螺栓	Hex flange bolt		PCS	1.28
231-1035TF30	六角法兰面螺栓	Hex flange bolt		PCS	1.28
231-1045TF3	六角法兰面螺栓	Hex flange bolt		PCS	2.16
231-1050TF3	六角法兰面螺栓	Hex flange bolt		PCS	0.91
231-1050TF4	六角法兰面螺栓	Hex flange bolt		PCS	0.91
231-1075TF3	六角法兰面螺栓	Hex flange bolt		PCS	1.26
231-12115TF3	六角法兰面螺栓	Hex flange bolt		PCS	2.77
231-12130TF3	六角法兰面螺栓	Hex flange bolt		PCS	4.09
231-1225TF3	六角法兰面螺栓	Steering reflux pipe I		PCS	0.85

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
231-1260TF30	六角法兰面螺栓	Hex flange bolt		PCS	1.78
231-1275TF3	六角法兰面螺栓	Hex flange bolt		PCS	2.31
231-1280TF30	六角法兰面螺栓	Hex flange bolt		PCS	2.20
231-1290TF30	六角法兰面螺栓	Hex flange bolt		PCS	2.35
231-1490TF3	六角法兰面螺栓	Hex flange bolt		PCS	4.62
231-1560TF3	六角法兰面螺栓	Hex flange bolt		PCS	4.22
231B-1027TF3	六角法兰面螺栓	Hex flange bolt		PCS	2.11
231B-1256TF3	六角法兰面螺栓	Hex flange bolt		PCS	2.31
231B-1275TF3	六角法兰面螺栓	Hex flange bolt	only available with assembled parts	PCS	3.50
305-0508F3	六角法兰面螺栓	Hex flange bolt		PCS	0.20
400-0243	塑料卡扣	Plastic clip		PCS	0.42
400-065	塑料卡扣	Plastic clip		PCS	0.54
400-136	塑料卡扣	Plastic clip		PCS	0.70
400-1405	塑料卡扣	Plastic clip		PCS	0.29
400-1500	塑料卡扣	Plastic clip		PCS	0.65
400-1729	塑料卡扣	Plastic clip		PCS	0.75
400-1733	塑料卡扣	Plastic clip		PCS	0.66
400-1868	塑料卡扣	Plastic clip		PCS	1.17
400-1932	塑料卡扣	plastic clip		PCS	0.53
400-1933	塑料卡扣	Plastic clip		PCS	0.70
400-244	塑料卡扣	plastic clip		PCS	0.28
400-256	塑料卡扣	Plastic clip		PCS	0.57
400-540	塑料卡扣	Plastic clip		PCS	0.46
82711-1A890	线束支架	Harness clamp		PCS	0.38
AD37600013	线束支架	Harness clamp		PCS	0.61
B1001110	辅助悬置连接支架组件	Suspension bracket bracket		PCS	16.99

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B1001130	辅助悬置安装支架组件	Suspension set bracket		PCS	18.48
B1001320	连接支架焊接总成	Connecting bracket		PCS	25.08
B1001330	左悬置安装支座组件	Left suspension seat		PCS	23.64
B1101010	燃油左固定带组件	Fuel tank left fixation		PCS	13.07
B1101020	燃油箱右固定带组件	Fuel tank right fixation		PCS	13.07
B1101100	燃油箱总成	Fuel tank assy.		PCS	433.22
B1101183	油泵压紧盖	Fuel pump cap		PCS	13.20
B1101200	加注管总成	Fuel filler tube assy.		PCS	149.78
B1104020	燃油硬管组件	Fuel tube		PCS	25.86
B1104030	燃油硬管/喷油嘴连接软管组件	Hose connecting fuel tube and nozzle		PCS	21.38
B1104251	燃油管路三管夹	Clamp		PCS	2.97
B1108100	油门踏板总成	Accelerator pedal assy.		PCS	16.26
B1108310	油门拉索组件	Throttle cable		PCS	14.18
B1109100	空气滤清器总成	Air filter assy.		PCS	62.55
B1109210	空滤器进气管总成	Air filter intake pipe		PCS	62.55
B1109210B1	空滤器进气管总成	Air filter intake pipe		PCS	29.40
B1109220	发动机进气软管总成	Engine section pipe		PCS	37.36
B1117010	油箱/滤清器出油软管组件	Fuel filter hose		PCS	19.32
B1117020	油箱回油管/燃油硬管连接组件	Fuel tank reflux pipe and fuel tube connecting component		PCS	29.58
B1123100	电子燃油泵总成	Fuel pump assy.		PCS	205.92
B1130110	油箱至碳罐连接硬管组件	Tube connecting fuel tank and canister		PCS	17.23
B1130120	油箱至碳罐连接软管组件	Hose connecting fuel tank and canister		PCS	34.32
B1130151	碳罐/回油硬管连接软管	Hose connecting canister and reflux tube		PCS	51.74
B1130152	碳罐/燃油蒸汽控制阀连接软管	Hose connecting canister and control vavle		PCS	6.05
B1130153	燃油蒸汽控制阀/节气门连接软管	Hose connecting fuel valve and throttle		PCS	6.88
B1130200	碳罐总成	Can Canister		PCS	41.28

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B1130451	燃油蒸汽控制阀支架	Fuel valve bracket		PCS	1.28
B1132200	谐振腔总成	Cavity resonator		PCS	21.56
B1201200	后消声器总成	Rear muffler		PCS	258.06
B1203100	排气管总成	Exhaust pipe assy.		PCS	125.80
B1205100	前消声器带催化器总成	Front muffler with catalyst assy.		PCS	1370.56
B1208011	排气管前围板下隔热板	Exhaust pipe heat insulater II	Front cowl part	PCS	43.26
B1208012	排气管前地板下隔热板	Exhaust pipe heat insulater I	Front floor part	PCS	63.95
B1208013	排气管油箱下隔热板	Exhaust pipe heat insulater III	Fuel tank part	PCS	22.44
B1208014	排气管右后纵梁下隔热板	Exhaust pipe heat insulater IV	Rear right longeron part	PCS	39.49
B1211112	球型密封垫	Ball shape gasket		PCS	6.86
B1211511	压簧螺栓	Bolt		PCS	3.96
B1211512	压簧	Pressure spring		PCS	1.45
B1211521	前消声器橡胶悬置块	Front muffler rubber block		PCS	5.68
B1211522	后消声器橡胶悬置块	Rear muffler rubber block		PCS	7.39
B1211525	排气管防脱架	Exhaust pipe bracket		PCS	2.38
B1211526	隔热板减振垫	Heat insulater washer		PCS	0.13
B1301100	散热器总成	Radiator assy.		PCS	323.40
B1302111	散热器上安装支架	Radiator upper bracket		PCS	2.44
B1303111	散热器出水管	Radiator drain pipe		PCS	11.11
B1303121	散热器进水管	Radiator intake pipe		PCS	23.44
B1308100	电子风扇带护风罩总成	Cooling fan assy.		PCS	231.00
B1311100	储液壶总成带溢流管	Water can with return tube assy.		PCS	19.80
B1602100	离合踏板总成	Clutch paddle assy.		PCS	56.10
B1607111	离合主泵进油软管	Intake hose, clutch master pump		PCS	5.81
B1607120	离合主泵出油软管组件	Outtake hose, clutch master pump		PCS	11.48
B1607210	离合主泵出油硬管组件	Outtake tube, clutch master pump		PCS	5.54

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B1608100	离合器总泵总成	Clutch master pump		PCS	69.64
B1611111	离合软管管夹	Clip		PCS	0.79
B1703019	软轴固定支架	Cable bracket		PCS	2.64
B1703100	换档支座组件	Gear shift seat		PCS	75.13
B1703150	换档手柄球头组件	Gearlever handle		PCS	23.76
B1703150B1	换档手柄球头组件	Gearlever handle	EX	PCS	46.20
B1703200	选换档软轴总成	Gearshift cable		PCS	59.40
B2203100	左传动轴总成	Left transmission shaft assy.		PCS	334.23
B2203200	右传动轴总成	Right transmission shaft assy.		PCS	362.23
B2304111	左转向节	Left steering knuckle		PCS	142.56
B2304611	右转向节	Right steering knuckle		PCS	142.56
B2802111	发动机左下横挡泥板	Engine mudguard, left		PCS	64.68
B2802211	发动机右下横挡泥板	Engine mudguard, right		PCS	64.68
B2803110	前保险杠组件	Front bumper		PCS	376.20
B2803121	前保险杠缓冲块	Front bumper damper		PCS	30.18
B2803131	前保险杠左连接支架	Front bumper left connecting bracket		PCS	4.62
B2803132	前保险杠右连接支架	Front bumper right connecting bracket		PCS	4.62
B2803133	带胶头螺栓	Plastic head bolt	M6	PCS	0.86
B2803150A2	前格栅	Front grille		PCS	198.00
B2803200	前保险杠骨架主体	Front bumper frame		PCS	174.11
B2803211	前保险杠左固定板	Front bumper frame left fixing plate		PCS	45.89
B2803212	前保险杠右固定板	Front bumper frame right fixing plate		PCS	51.35
B2804111	后保险杠	Rear bumper		PCS	389.40
B2804121	后保险杠缓冲块	Rear bumper damper		PCS	41.95
B2804131	后保险杠连接支架	Rear bumper bracket		PCS	3.96
B2804231	后保险杠骨架左安装支架	Rear bumper frame left fixing plate		PCS	10.99

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B2804241	后保险杠骨架右安装支架	Rear bumper frame right fixing plate		PCS	12.40
B2805111	后托钩	Rear hook		PCS	12.05
B2901100	副车架总成	Sub-frame assy.		PCS	455.40
B2901151	副车架胶塞	Sub-frame plug		PCS	0.20
B2904100	左前下摆臂总成	Front left swing arm		PCS	181.50
B2904200	右前下摆臂总成	Front right swing arm		PCS	181.50
B2904810	球销组件	Ball joint		PCS	72.60
B2905011	前减震器上压板	Front shock absorber press plate		PCS	11.88
B2905100	左前减振器总成	Front left shock absorber assy.		PCS	340.30
B2905120	左前减振器阻尼器总成	Front left shock absorber damper		PCS	187.64
B2905170	上连接盖板组件	Upper plate		PCS	49.37
B2905181	前螺旋弹簧	Front coil spring		PCS	51.63
B2905182	弹簧下座	Spring lower seat		PCS	5.08
B2905183	限位块	Stopper		PCS	19.32
B2905184	防尘罩	Boot		PCS	14.24
B2905185	弹簧上座	Spring upper seat		PCS	10.11
B2905186	锁紧螺母盖板	Nut plate		PCS	1.39
B2905200	右前减振器总成	Front right shock absorber assy.		PCS	340.30
B2905220	右前减振器阻尼器总成	Front right shock absorber damper		PCS	187.64
B2906011	前横向稳定杆抱箍	Front stabilizer bar hoop		PCS	2.64
B2906012	前横向稳定杆橡胶安装座	Front stabilizer bar rubber seat		PCS	3.96
B2906100	前横向稳定杆总成	Front stabilizer bar assy.		PCS	116.16
B2906200	前横向稳定杆连杆总成	Front stabilizer bar con-rod		PCS	34.32
B2910123	副车架胶塞	Sub-frame plug		PCS	0.20
B2911100	后桥总成	Rear axle assy.		PCS	679.80
B2915100	左后减振器总成	Rear left shock absorber assy.		PCS	220.44

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B2915120	后减振阻尼器总成	Rear shock absorber damper		PCS	116.03
B2915170	左后上连接板组件	Left connect plate		PCS	21.27
B2915181	后螺旋弹簧	Rear coil spring		PCS	48.05
B2915182	防尘罩及限位块	Stop boot		PCS	19.03
B2915183	限位盖	Stop plate		PCS	1.19
B2915184	减振垫	Damper cushion		PCS	5.08
B2915185	弹簧上橡胶垫	Spring upper rubber cushion		PCS	4.33
B2915186	缓冲定位套	Positioning sleeve		PCS	1.14
B2915187	缓冲块	Damper block		PCS	1.53
B2915188	缓冲限位座	Damper seat		PCS	0.87
B2915200	右后减振器总成	Rear right shock absorber assy.		PCS	220.44
B2915270	右后上连接板组件	Right connect plate		PCS	21.27
B2916140	后横向稳定杆总成	Rear stabilizer bar assy.		PCS	72.60
B3101111	铝合金车轮	Aluminum rim		PCS	314.82
B3101210	钢制车轮	Steel rim		PCS	116.16
B3102510	轮毂盖板组件	Rim cap assy.		PCS	5.94
B3103100	前轮毂总成	Front wheel hub		PCS	55.44
B3104100	后轮毂总成	Rear wheel hub		PCS	250.80
B3106100	轮胎	Tyre		PCS	316.21
B3401100	转向器和转向拉杆总成	Steering gear assy.		PCS	910.80
B3401200	右横向拉杆总成	Steering right rod		PCS	65.74
B3401510	左缸油管组件	Left oil pipe		PCS	8.62
B3401520	右缸油管组件	Right oil pipe		PCS	12.91
B3401600	左横向拉杆总成	Steering left rod		PCS	65.74
B3401713	抱箍	Hoop		PCS	6.36
B3401811	防尘罩	Dust shield		PCS	15.58

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B3401812	卡箍	Hoop		PCS	3.01
B3402100B14	方向盘总成	Steering wheel	foam, deep grey	PCS	164.67
B3402100B1B14	方向盘总成	Steering wheel	leather,with multi-switches, deep grey	PCS	248.81
B3404100	上转向轴总成	Upper steering shaft assy.		PCS	187.58
B3404200	下转向轴总成	Lower steering shaft assy.		PCS	95.04
B3406100	转向油泵进油管总成	Steering pump intake pipe assy.		PCS	26.40
B3406200	转向器进油管总成	Steering intake pipe assy.		PCS	79.20
B3406300	转向器回油管总成	Steering reflux pipe assy.		PCS	83.16
B3406340	转向器油管固定支架B组件	Pipe bracket B		PCS	3.96
B3406341	转向器回油管IV	Steering reflux pipe IV		PCS	2.38
B3408010	动力转向油壶支架组件	Power steering reservior bracket assy.		PCS	7.22
B3408100	动力转向油壶总成	Power steering reservior assy.		PCS	20.59
B3412410	转向机上隔音罩卡圈	Noise insulator circlip, steering gear		PCS	5.54
B3412511	转向机上隔音罩	Noise insulator, steering gear		PCS	11.56
B3501100	左前制动器带转向节总成	Left front brake with steer knuckle assy.		PCS	495.00
B3501110	左前制动卡钳总成	Front left brake caliper		PCS	209.96
B3501111	前制动盘	Front brake disc	左右各一	PCS	92.40
B3501240	左前内制动摩擦片	Front left brake pad, inner		PCS	13.20
B3501260	前外制动摩擦片	Front brake pad, outer		PCS	13.20
B3501410	左前制动器底板组件	Front left brake bottom		PCS	11.88
B3501600	右前制动器带转向节总成	Right front brake with steer knuckle assy.		PCS	495.00
B3501610	右前制动卡钳总成	Front right brake caliper		PCS	209.96
B3501730	右前内制动摩擦片	Front right brake pad, inner		PCS	13.20
B3501910	右前制动器底板组件	Front right brake bottom		PCS	11.88
B3502100	左后制动器总成	Rear left brake		PCS	594.00
B3502110	左后制动卡钳总成	Rear left brake caliper assy.		PCS	142.56

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B3502111	后制动盘	Rear brake disc		PCS	66.00
B3502230	后制动蹄片组件	Rear brake shoe		PCS	13.20
B3502240	左后内制动摩擦片	Rear left brake pad, inner		PCS	10.56
B3502260	后外制动摩擦片	Front brake pad, outer		PCS	10.56
B3502410	左后制动底板组件	Left rear brake bottom		PCS	46.20
B3502600	右后制动器总成	Rear right brake		PCS	594.00
B3502610	右后制动卡钳总成	Rear right brake caliper assy.		PCS	142.56
B3502730	右后内制动摩擦片	Rear right brake pad, inner		PCS	10.56
B3502910	右后制动底板组件	Right rear brake bottom		PCS	46.20
B3504100	制动踏板支架总成	Brake pedal bracket assy.		PCS	58.61
B3504141	制动踏板胶垫	Brake paddle rubber sleeve		PCS	1.98
B3504210	制动总泵总成	Brake pump		PCS	92.40
B3504351	制动踏板销柱衬套	Bush		PCS	1.98
B3504361	制动踏板销柱衬管	Liner tube		PCS	1.98
B3506110	ABS-FL(左前硬管 I)	Front left tube I, ABS		PCS	13.93
B3506120	ABS-FL(左前硬管 II)	Front left tube II, ABS		PCS	5.56
B3506130	前制动软管	Front brake hose		PCS	17.56
B3506140	ABS-MCP(一缸硬管)	Master cylinder tube, ABS		PCS	15.00
B3506150	ABS-MCS(二缸硬管)	Sub cylinder tube, ABS		PCS	15.79
B3506160	ABS-FR(左前硬管)	Front left tube, ABS		PCS	9.89
B3506210	ABS-RL(左后硬管 I)	Rear left tube I, ABS		PCS	11.05
B3506220	比例阀阀体-RL(左后硬管 II)	Rear left tube II, Proportional Valve		PCS	24.90
B3506230	ABS-RR(右后硬管 I)	Rear right tube I, ABS		PCS	11.62
B3506240	比例阀阀体-RR(后-右后硬管 II)	Rear right tube II, Proportional Valve		PCS	28.87
B3506250	后制动软管组件	Rear brake hose		PCS	11.09
B3506310	七管夹组件	Clamp	for 7 tube	PCS	3.56

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B3506320	六管夹组件	Clamp	for 6 tube	PCS	2.44
B3506351	五管夹A	Clamp A	for 5 tube	PCS	3.13
B3506352	五管夹卡B	Clamp B	for 5 tube	PCS	3.08
B3506353	五管夹C	Clamp C	for 5 tube	PCS	2.75
B3506354	五管夹D	Clamp C	for 5 tube	PCS	2.97
B3506355	五管夹卡扣	Clamp clip		PCS	1.19
B3506356	三管夹A	Clamp A	for 3 tube	PCS	2.48
B3506357	三管夹B	Clamp B	for 3 tube	PCS	2.86
B3506358	单管夹A	Clamp A	for 1 tube	PCS	0.92
B3506359	单管夹B	Clamp B	for 1 tube	PCS	1.20
B3506361	前轮制动管路过孔胶套	Front brake tube sleeve		PCS	0.66
B3506362	制动管路下护板	Brake pipeline fender		PCS	29.04
B3508300	驻车制动操纵杆总成	Parking brake lever		PCS	44.88
B3508412	前/后拉索支架	Brake cable bracket		PCS	1.32
B3508413	驻车制动拉索后段固定支架	Parking brake cable bracket, rear part		PCS	1.12
B3508420	驻车制动拉索前段组件	Parking brake cable, fore part		PCS	5.28
B3540011	真空助力器真空软管	Vacuum hose	for Tritec engine	PCS	18.10
B3540100	真空助力器带制动泵总成	Vacuum booster with pump assy.		PCS	295.17
B3540250	制动油壶组件	Fluid pot		PCS	33.92
B3540270	制动油壶盖组件	Fluid pot cap		PCS	2.64
B3540300	真空助力器总成	Vacuum booster assy.		PCS	196.55
B3550100	ABS-机构总成	ABS ECU		PCS	1378.05
B3550211	ABS支架总成	ABS bracket		PCS	8.79
B3550411	比例阀阀体	Proportional Valve		PCS	54.12
B3603820	倒车雷达传感器	Reverse radar sensor		PCS	63.36
B3603841	安装支架	Bracket		PCS	2.64

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B3605400	防盗报警器总成	Security warner		PCS	21.12
B3612100B2	电喷ECU	ECU	for Tritec engine	PCS	930.60
B3612211	电喷ECU固定支架	ECU bracket		PCS	6.73
B3612212	电喷ECU防尘罩	ECU cap		PCS	8.32
B3630300	左前轮轮速传感器总成	Front left wheel speed sensor		PCS	40.26
B3630400	右前轮轮速传感器总成	Front right wheel speed sensor		PCS	40.26
B3658100	安全气囊ECU	Airbag ECU	2 loop	PCS	410.85
B3658100B1	安全气囊ECU	Airbag ECU	4 loop	PCS	417.12
B3658300	安全气囊时钟弹簧	Airbag clock spring		PCS	113.22
B3658300B1	安全气囊时钟弹簧	Airbag clock spring	EX	PCS	113.22
B3661220	环境光传感器	Ambient light sensor		PCS	39.60
B3674100	BCM车身控制器组件	Body control module (BCM)	LX	PCS	326.04
B3703211	蓄电池压板	Battery press plate		PCS	2.64
B3703212	蓄电池拉杆	Battery draglink		PCS	2.38
B3703215	蓄电池底盖	Battery bottom		PCS	8.58
B3703216	蓄电池压板胶垫	Battery press beam		PCS	0.92
B3703220	蓄电池托架	Battery bracket		PCS	11.88
B3703230	蓄电池托架支撑架	Battery bracket mount		PCS	6.60
B3704100	点火开关	Ignition switch assy.		PCS	101.34
B3704210	普通钥匙	Key		PCS	13.20
B3704221	钥匙片	Key plate		PCS	9.24
B3704240	遥控手柄 (LX)	key handle	LX	PCS	35.64
B3704240B1	遥控手柄 (EX)	key handle	EX	PCS	26.40
B3704300	点火开关光圈	Ignition switch coil		PCS	7.92
B3704510	左前门锁芯	Door lock cylinder,front left door		PCS	19.80
B3704520	右前门锁芯	Door lock cylinder,front right door		PCS	19.80

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B3704550	行李舱锁芯总成	Trunk lock cylinder		PCS	19.80
B3710230	近光灯光轴调整开关	Low beam adjust switch		PCS	34.32
B3721100	高音电喇叭	Alt horn		PCS	17.97
B3721200	低音电喇叭	Bass horn		PCS	17.82
B3722100	驾驶舱电器中央控制盒	Central control case	Driver room	PCS	277.33
B3725100	点烟器总成	Cigarette lighter		PCS	27.31
B3741100	前刮水器电动机	Front wiper motor		PCS	138.60
B3745100	鼓风机电机	Blower motor		PCS	99.00
B3745180	空调鼓风机调速模块	Governor,blower		PCS	46.20
B3745200	内外循环风执行器	Actuator,blower		PCS	64.68
B3745300	吹风模式执行器	Actuator,blow Mode		PCS	64.68
B3745400	冷暖风执行器安装组件	Actuator assy,A/C Mode		PCS	1.98
B3745411	冷暖风执行器	Actuator,A/C Mode		PCS	64.68
B3745412	冷暖风执行器安装支架	Actuator bracket		PCS	5.28
B3746100	左前门扶手板开关总成	Inner handrail with switches,front left door		PCS	195.50
B3746110	左前门扶手板	Inner handrail,front left door		PCS	25.63
B3746120	左前门玻璃升降开关	Glass lifter,front left door		PCS	120.49
B3746200	右前门扶手板开关	Inner handrail with switches,front right door		PCS	54.05
B3746210	右前门扶手板	Inner handrail,front right door		PCS	25.63
B3746220	玻璃升降开关	Glass lifter		PCS	20.86
B3746300	左后门扶手板开关总成	Inner handrail with switches,rear left door		PCS	54.05
B3746310	左后门扶手板	Inner handrail,raer left door		PCS	25.63
B3746400	右后门扶手板开关总成	Inner handrail with switches,rear right door		PCS	54.05
B3746410	右后门扶手板	Inner handrail,rear right door		PCS	25.63
B3746500	左车门电动玻璃升降器电机	Glass lifter motor,left		PCS	73.92
B3746600	右车门电动玻璃升降器电机	Glass lifter motor,right		PCS	73.92

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B3750500	电动后视镜开关组件	Wing mirror switch assy.	DX, LX	PCS	87.78
B3750510	防盗指示灯	Security waring light		PCS	6.60
B3758110	前门接触开关	Contacter switch,front door		PCS	4.62
B3758120	后门接触开关	Contacter switch,rear door		PCS	4.62
B3758300	行李箱照明灯开关	Trunk light switch		PCS	5.15
B3774100	灯光组合开关总成	Lamp switch		PCS	56.10
B3774200	雨刮组合开关总成	Wiper switch		PCS	56.10
B3781120	制动灯开关	Brake lamp switch		PCS	9.90
B3782070	电动外后视镜控制开关	Wing mirror switch		PCS	40.26
B3820000	组合仪表	Instrument cluster	for TRIEC engine	PCS	407.55
B3820000B1	组合仪表	Instrument cluster	120KM/H warning,for TRIEC engine	PCS	407.55
B3921011A2	车前标识牌	Front LOGO"LLL"		PCS	15.84
B3921012A2	车后标识牌	Rear LOGO"LLL"		PCS	15.84
B4001350	蓄电池负极线束	Battery negative wire		PCS	28.43
B4001600	前部线束总成	Front harness	halogen lamp,adjustable	PCS	543.84
B4001600B1	前部线束总成	Front harness	EX,xenon lamp,adjustable	PCS	543.84
B4002020	后除霜接地线总成	Defrost earth wire		PCS	5.94
B4002100	左车身线束	Left body harness		PCS	309.54
B4002100B1	左车身线束	Left body harness	EX	PCS	309.54
B4002800	倒车雷达探头线束	Reverse radar harness		PCS	6.07
B4003100	仪表板线束	Instrument panel harness	DX, LX	PCS	324.72
B4003600	安全气囊线束总成	Airbag harness		PCS	59.40
B4003600B1	安全气囊线束总成	Airbag harness	EX	PCS	59.40
B4005100	顶棚线束总成	Headlining harness	LX, rear top light	PCS	12.28
B4005100B1	顶棚线束总成	Headlining harness	EX	PCS	12.28
B4006100	左前门线束	Front left door harness		PCS	28.38

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B4006200	右前门线束	Front right door harness		PCS	17.16
B4006300	左后门线束	Rear left door harness		PCS	26.76
B4006400	右后门线束	Rear right door harness		PCS	26.76
B4008120	蓄电池电源线束	Power harness		PCS	39.20
B4009240	左后轮轮速传感器线束总成	Rear left wheel speed sensor		PCS	29.04
B4009250	右后轮轮速传感器线束总成	Rear right wheel speed sensor		PCS	29.04
B4009282	左后轮速传感器线束支架A	Plastic bracket,RL speed sensor		PCS	2.05
B4009283	左后轮速传感器线束支架B	Metal bracket,RL speed sensor		PCS	2.05
B4009284	后轮速传感器线束支架A	Metal bracket,Rear speed sensor		PCS	1.32
B4009285	后轮速传感器线束支架B	Plastic bracket,Rear speed sensor		PCS	1.32
B4009286	右后轮速传感器线束支架A	Plastic bracket,RR speed sensor		PCS	2.05
B4009287	右后轮速传感器线束支架B	Metal bracket,RR speed sensor		PCS	2.05
B4108100	左后牌照灯	Left registration lamp		PCS	13.20
B4108200	右后牌照灯	Right registration lamp		PCS	13.20
B4116100	左前雾灯总成	Front left fog lamp		PCS	59.40
B4116200	右前雾灯总成	Front right fog lamp		PCS	59.40
B4121100	左前组合灯	Front left head lamp	halogen lamp,unadjustable	PCS	381.48
B4121200	右前组合灯	Front right head lamp	halogen lamp,unadjustable	PCS	381.48
B4123400	后顶灯	Rear ceiling light		PCS	25.02
B4127100	行李箱照明灯	Trunk light		PCS	7.92
B4131100	左前门灯	Front left door lamp		PCS	13.41
B4131200	右前门灯	Front right door lamp		PCS	13.41
B4131300	左后门灯	Rear left door lamp		PCS	13.41
B4131400	右后门灯	Rear right door lamp		PCS	13.41
B4133300	左后组合灯	Left tail lamp		PCS	212.51
B4133400	右后组合灯	Right tail lamp		PCS	212.51

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B4134100	高位制动灯	High-mount brake lamp		PCS	39.62
B5009001	白车身总成	Vehicle body assy.		PCS	10586.22
B5101210	备胎固定支架	Spare tyre fixing bracket		PCS	3.59
B5101212	备胎缩紧盖	Spare tyre cap 2		PCS	0.46
B5107111	Φ30堵片	Plug	Φ30	PCS	0.26
B5107112	Φ10橡胶堵盖	Rubber plug	Φ10	PCS	0.33
B5107117	腰形堵盖	Plug		PCS	0.73
B5107123	油箱检修口盖	Fuel tank top cap		PCS	8.05
B5107124	加油管下隔架	Fuel filling pipe spacer		PCS	1.70
B5109100B15	主地毯	Carpet assy.	pale grey	PCS	298.07
B5120000	前地板总成	Front floor assy.		PCS	714.32
B5130000	后地板总成	Rear floor assy.		PCS	1259.01
B5205100	雨刮器双连杆机构带电机总成	Wiper con-rod with front wiper motor assy.		PCS	138.60
B5205116	雨刮器摆臂安装螺母塑料盖帽	Wiper arm cap		PCS	0.66
B5205200	雨刮器左摆臂刮刷总成	Left wiper assy.		PCS	19.80
B5205300	雨刮器右摆臂刮刷总成	Right wiper assy.		PCS	19.80
B5206110	前挡风玻璃	Front wind-shield glass		PCS	304.27
B5206113	前挡风玻璃胶条	Front wind-shield glass seal		PCS	22.73
B5206115	挡风玻璃限位卡 I	Wind-shield glass clip I		PCS	5.94
B5206116	挡风玻璃上限位卡 II	Wind-shield glass clip II		PCS	5.94
B5206120	后挡风玻璃	Rear wind-shield glass		PCS	142.56
B5206123	后挡风玻璃胶条	Rear wind-shield glass seal		PCS	12.86
B5207100	洗涤壶组件	Washer can		PCS	34.19
B5207330	洗涤喷嘴	Washer nozzle		PCS	2.64
B5301000	前围上横梁总成	Front cowl upper beam		PCS	355.21

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B5301011	前围Φ18橡胶堵盖	Front cowl rubber plug	Φ18	PCS	1.02
B5301012	Φ25堵片	Plug	Φ25	PCS	0.26
B5302000	前围板总成	Front cowl assy.		PCS	397.76
B5302200	仪表板管梁总称	Instrument panel beam assy.		PCS	122.76
B5303100B15	仪表板杂物箱总成	Glove box assy.	pale grey	PCS	69.96
B5304210	右通风盖板组件	Ventilation left cover		PCS	22.44
B5304212	风窗左盖板密封条	Ventilation left cover seal		PCS	2.49
B5304220	右通风盖板组件	Ventilation right cover		PCS	22.44
B5304222	风窗右盖板密封条	Ventilation right cover seal		PCS	2.49
B5304241	前挡风玻璃下流水槽	Front windshield water deflector		PCS	5.28
B5305010B15	手刹盖板组件	Park braking panel	pale grey	PCS	6.60
B5305100B15	副仪表板总成	Sub-instrument panel assy.	pale grey	PCS	191.40
B5305111	副仪表板本体	Sub-instrument panel body		PCS	118.80
B5305114	前杯托盖外板	Outer panel, drinking cup placement		PCS	19.80
B5305115	前杯托盖内板	Outer panel, drinking cup placement		PCS	13.20
B5305116	前杯托盖缓冲垫	Drinking cup placement damper		PCS	1.32
B5305117	前杯托盖翻转弹簧	Spring, drinking cup placement		PCS	3.96
B5305118	前杯托盒隔板	Drinking cup placement spacer		PCS	3.96
B5305200	副仪表板杂物盒总成	Glove box, Sub-instrument panel		PCS	59.40
B5305214	开关锁舌	Box switch		PCS	6.60
B5305300B16	中下部面罩总成	Middle-lower panel assy.	black	PCS	39.60
B5305311	中下部面罩本体	Middle-lower panel		PCS	19.80
B5305312	排挡杆皮护套	Shift lever cover		PCS	13.20
B5305314	排档面板装饰框	Shift lever cover clamp		PCS	19.80
B5305410B16	前烟灰缸总成	Front ashtray assy.	black	PCS	52.80
B5305430	后烟灰缸总成	Rear ashtray assy.		PCS	13.20

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B5306011B16	组合仪表罩	Instrument cluster cover	black	PCS	50.16
B5306020	气体阻尼器	Glove box damper		PCS	13.20
B5306110B14	仪表板上护板	Instrument panel fender,upper	deep grey	PCS	488.40
B5306125B14	副安全气囊盖板	Passengers airbag panel	deep grey, for configuration without passenger's airbag	PCS	13.20
B5306130B15	仪表板下护板	Instrument panel fender,lower	pale grey	PCS	226.87
B5306132	票据盒	Notes box		PCS	13.20
B5306210	仪表板横梁左固定板组件	Left fixing plate,instrument panel beam		PCS	13.20
B5306220	仪表板横梁右固定板组件	Right fixing plate,instrument panel beam		PCS	13.20
B5306230	仪表板横梁组件	Instrument panel beam		PCS	76.56
B5306250	仪表板横梁左撑杆组件	Left stay bar,instrument panel beam		PCS	6.60
B5306260	仪表板横梁右撑杆组件	Right stay bar,instrument panel beam		PCS	6.60
B5306270	仪表板横梁拉杆	Drag link,instrument panel beam		PCS	6.60
B5306300B14	左出风口总成	Left ventilation nozzle	deep grey	PCS	59.40
B5306400B14	右出风口总成	Right ventilation nozzle	deep grey	PCS	59.40
B5306424	风道左右风口连接卡扣	Clip		PCS	0.45
B5306510B16	中风口左风窗组件	Middle ventilation nozzle, left part	black	PCS	19.80
B5306520B16	中风口右风窗组件	Middle ventilation nozzle, right part	black	PCS	19.80
B5306711B14	转向柱上护罩	Steering pillar shield upper	deep grey	PCS	12.37
B5306712B14	转向柱下护罩	Steering pillar shield lower	deep grey	PCS	22.66
B5306810C03	仪表板左装饰条组件	Instrument panel trim assy,left	peachwood	PCS	19.80
B5306820C03	仪表板右装饰条组件	Instrument panel trim assy,right	peachwood	PCS	48.84
B5307112	Φ10橡胶堵盖	Rubber plug	Φ10	PCS	0.33
B5310110	前围隔热垫总成	Front cowl heat insulator		PCS	151.80
B5310120	发动机仓隔热垫	Engine room heat insulator		PCS	36.96
B5400112	左右B柱海绵块	B pillar cushion		PCS	1.32
B5400113	隔音海绵	Sound proof cushion		PCS	0.92

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B5400121	侧围塑料螺母	Plastic nut, side bdoy	Φ15	PCS	0.67
B5400311	左前轮挡泥板	Front left mudguard		PCS	43.08
B5400315	固定钣金	Fixing plate		PCS	1.25
B5400316	小挡泥板	Small mudguard		PCS	3.96
B5400321	右前轮挡泥板	Front right mudguard		PCS	43.08
B5400331	左后轮挡泥板	Rear left mudguard		PCS	31.57
B5400337	左后挡泥板防溅板	Spray-proof, rear left mudguard		PCS	11.88
B5400338	后挡泥板防溅板卡扣	Clip, rear spray-proof		PCS	0.54
B5400339	左后饰板	Rear left decoration,mudguard		PCS	5.94
B5400341	右后轮挡泥板	Rear right mudguard		PCS	31.57
B5400342	右后挡泥板防溅板	Spray-proof, rear right mudguard		PCS	11.88
B5400343	右后饰板	Rear right decoration,mudguard		PCS	5.94
B5400813	子母扣	Inlay clip		PCS	0.75
B5401010	左侧围总成	Left cowl assy.		PCS	1623.60
B5401011	左侧前连接加强板	Left front connecting plate		PCS	33.17
B5401020	右侧围总成	Right cowl assy.		PCS	1635.91
B5401021	右侧前连接加强板	Right front connecting plate		PCS	33.17
B5401300	加油口盖总成	Fuel filler cap		PCS	18.84
B5402011	顶棚左前支撑架	Roof support, front left		PCS	7.92
B5402012	顶棚左后支撑架	Roof support, rear left		PCS	7.92
B5402021	顶棚右前支撑架	Roof support, front right		PCS	7.92
B5402022	顶棚右后支撑架	Roof support, rear right		PCS	7.92
B5402111B15	A柱左上护板	Left upper fender,A-pillar	pale grey	PCS	17.95
B5402120B15	A柱左下护板组件	Left lower fender,A-pillar	pale grey	PCS	13.20
B5402130B15	B柱左上护板组件	Left upper fender, B pillar	pale grey	PCS	15.67
B5402141B15	B柱左下护板	Left lower fender,B-pillar	pale grey	PCS	21.57

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B5402150B15	C柱左上护板组件	Left upper fender,C-pillar	pale grey	PCS	31.15
B5402171B15	左前门槛护板	Front left threshold fender	pale grey	PCS	13.20
B5402181B15	左后门槛护板	Rear left threshold fender	pale grey	PCS	13.20
B5402211B15	A柱右上护板	Right upper fender,A-pillar	pale grey	PCS	17.95
B5402220B15	A柱右下护板组件	Right lower fender,A-pillar	pale grey	PCS	13.20
B5402230B15	B柱右上护板组件	Right upper fender, B pillar	pale grey	PCS	15.67
B5402241B15	B柱右下护板	Right lower fender,B-pillar	pale grey	PCS	21.57
B5402250B15	C柱右上护板组件	Right upper fender,C-pillar	pale grey	PCS	31.15
B5402271B15	右前门槛护板	Front right threshold fender	pale grey	PCS	13.20
B5402281B15	右后门槛护板	Rear right threshold fender	pale grey	PCS	13.20
B5416211	A柱左三角窗装饰板	Left triangular window decoration		PCS	3.96
B5416212	A柱左三角窗装饰板橡胶条	Seal, left triangular window decoration		PCS	1.32
B5416221	A柱右三角窗装饰板	Right triangular window decoration		PCS	3.96
B5416222	A柱右三角窗装饰板橡胶条	Seal, right triangular window decoration		PCS	1.32
B5416225	左右裙板小堵盖	Skirt plate plug	small	PCS	0.26
B5416226	左右裙板大堵盖	Skirt plate plug	big	PCS	0.33
B5506210A2	后牌照饰板	License plate trim		PCS	59.40
B5600031	行李舱盖左缓冲块	Trunk left damper		PCS	1.78
B5600032	右缓冲块	Trunk right damper		PCS	1.78
B5601100	搁物板总成	Shelf assy.		PCS	147.38
B5601200	后围板总成	Rear cowl assy.		PCS	398.03
B5601241	后保险杠左安装支架	Rear bumper left bracket		PCS	5.85
B5601251	后保险杠右安装支架	Rear bumper right bracket		PCS	5.85
B5602111B16	后裙板护板	Rear skirt fender	black	PCS	27.52
B5602211B16	后座椅饰板	Rear seat decoration	black	PCS	23.76

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B5604000	行李箱盖总成	Trunk lid assy.		PCS	309.74
B5604401	行李箱密封条	Trunk seal		PCS	40.00
B5605011	行李箱左弹力扭杆	Trunk left torsion rod		PCS	9.90
B5605012	行李箱右弹力扭杆	Trunk right torsion rod		PCS	9.90
B5605100	行李箱盖左铰链总成	Trunk lid left hinge		PCS	20.02
B5605113	行李箱缓冲垫	Trunk damper		PCS	0.46
B5605200	行李箱盖右铰链总成	Trunk lid right hinge		PCS	20.02
B5606110	行李箱锁体	Trunk lock		PCS	23.76
B5606424	行李舱锁车内开关卡扣	Trunk buckle		PCS	0.53
B5608100B02	行李舱左侧护面组件	Trunk left fender	black	PCS	90.70
B5608200B02	行李舱右侧护面组件	Trunk right fender	black	PCS	90.70
B5608311B02	行李箱地毯	Trunk carpet	black	PCS	53.76
B5608313	行李箱左尾角盖板	Trunk right corner cover		PCS	7.26
B5608314	行李箱右尾角盖板	Trunk right corner cover		PCS	6.60
B5608320	备胎盖板组件	Spare tyre cover		PCS	52.80
B5608400B15	搁物板护板	Shelf panel	pale grey	PCS	109.82
B5608511B02	行李箱盖内饰板	Trunk lid interior	black	PCS	66.41
B5701000	顶盖骨架及盖板总成	Roof		PCS	219.36
B5701000B1	顶盖骨架及盖板总成	Roof	with top window	PCS	317.00
B5701015	顶盖天窗加强板安装支架	Roof bracket		PCS	2.81
B5701016	顶盖天窗加强板安装支架2	Roof bracket 2		PCS	1.14
B5701017	顶盖天窗加强板安装支架3	Roof bracket 3		PCS	1.17
B5702012	顶蓬海绵块I	Roof foam cushion I		PCS	1.32
B5702013	顶蓬海绵块II	Roof foam cushion II		PCS	1.32
B5702111B15	顶蓬	Roof	pale grey	PCS	197.04
B5704111	车顶左密封压条	Roof seal, left		PCS	12.41

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B5704112	车顶密封压条卡扣	Roof seal clip		PCS	0.46
B5704211	车顶右密封压条	Roof seal, right		PCS	12.41
B5811110A2B15	左前安全带卷收器总成	Front left safety belt retractor assy.	pale grey, ordinary,E-mark	PCS	72.47
B5811110B15	左前安全带卷收器总成	Front left safety belt retractor assy.	pale grey, ordinary	PCS	52.67
B5811110B1B15	左前安全带卷收器总成	Front left safety belt retractor assy.	pale grey, pretensioner	PCS	211.20
B5811110B2B15	左前安全带卷收器总成	Front left safety belt retractor assy.	pale grey, pretensioner,E-mark	PCS	231.00
B5811114	安全带带头护盖	Safety belt end cap		PCS	1.32
B5811120	安全带高度调节器总成	Safety belt height adjuster		PCS	23.76
B5811120A2	安全带高度调节器总成	Safety belt height adjuster	E-mark	PCS	26.40
B5811130A2B15	左前安全带锁扣总成	Front left safety belt buckle	pale grey, E-mark	PCS	25.61
B5811130B15	左前安全带锁扣总成	Front left safety belt buckle	pale grey	PCS	20.33
B5811210A2B15	右前安全带卷收器总成	Front right safety belt retractor assy.	pale grey, ordinary,E-mark	PCS	72.47
B5811210B15	右前安全带卷收器总成	Front right safety belt retractor assy.	pale grey, ordinary	PCS	52.67
B5811210B1B15	右前安全带卷收器总成	Front right safety belt retractor assy.	pale grey, pretensioner	PCS	211.20
B5811210B2B15	右前安全带卷收器总成	Front right safety belt retractor assy.	pale grey, pretensioner,E-mark	PCS	231.00
B5811230A2B15	右前安全带锁扣总成	Front right safety belt buckle	pale grey, E-mark	PCS	25.61
B5811230B15	右前安全带锁扣总成	Front right safety belt buckle	pale grey	PCS	20.33
B5812110A2B15	后安全带卷收器总成	Rear safety belt retractor assy.	pale grey, E-mark	PCS	73.92
B5812110B15	后安全带卷收器总成	Rear safety belt retractor assy.	pale grey	PCS	56.10
B5812130A2B15	后排锁扣及腰带总成	Rear safety belt	pale grey, E-mark	PCS	37.62
B5812130B15	后排锁扣及腰带总成	Rear safety belt	pale grey	PCS	34.06
B5812230A2B15	后排双联锁扣总成	Rear safety belt twin buckle	pale grey, E-mark	PCS	29.30
B5812230B15	后排双联锁扣总成	Rear safety belt twin buckle	pale grey	PCS	25.34
B5824100	驾驶员气囊模块	Driver's airbag		PCS	493.68
B5824200B14	副驾驶员气囊模块	Passengers airbag	deep grey	PCS	524.04
B6100120	左前侧车门活动导轨总成	Glass rail assy, front left door		PCS	8.98

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B6100121	左前侧车门玻璃活动导轨	Glass rail, front left door		PCS	7.13
B6100122	左前侧车门玻璃活动导轨下支架	Glass rail bracket, front left door		PCS	1.85
B6100220	右前侧车门活动导轨总成	Glass rail assy, front right door		PCS	8.98
B6100221	右前侧车门玻璃活动导轨	Glass rail, front right door		PCS	7.13
B6100222	右前侧车门玻璃活动导轨下支架	Glass rail bracket, front right door		PCS	1.85
B6101001	左前车门总成	Front left door assy.		PCS	761.79
B6101002	右前车门总成	Front right door assy.		PCS	761.79
B6102010	左前门防雨帘组件	Rain shield,front left door		PCS	19.40
B6102020	右前门防雨帘组件	Rain shield,front right door		PCS	19.40
B6102110B97	左前门内护板总成	Front left door interior	grey,upper deep lower pale	PCS	154.81
B6102114	左前门上装饰条	Interior trim,front left door		PCS	35.68
B6102119	前门螺钉堵盖	Front door screw cap		PCS	0.13
B6102210B97	右前门内护板总成	Front right door interior	grey,upper deep lower pale	PCS	154.81
B6102214	右前门上装饰条	Interior trim,front right door		PCS	35.68
B6103100B1	左前侧车门车窗玻璃	Front left door glass		PCS	46.89
B6103200B1	右前侧车门车窗玻璃	Front right door glass		PCS	46.89
B6104100B1	左前侧车门玻璃升降器总成	Glass lifter,front left door		PCS	122.10
B6104200B1	右前侧车门玻璃升降器总成	Glass lifter,front right door		PCS	122.10
B6105110	左前侧门锁体	Front left door lock	DX	PCS	66.88
B6105110B1	左前侧门锁体	Front left door lock	LX, EX	PCS	109.90
B6105130A2	左前侧车门门把手总成	Outer handle assy, rear left door		PCS	59.40
B6105131	侧车门门把手	Outer handle		PCS	39.60
B6105132	侧车门门把手塑料垫圈A	Plastic ring A, door handle		PCS	1.32
B6105133	侧车门门把手塑料垫圈B	Plastic ring B, door handle		PCS	1.32
B6105134	左前侧车门门把手座	Handle seat, rear left door		PCS	10.56
B6105141	侧车门锁扣组件	Door buckle component		PCS	5.33

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B6105210	右前侧门锁体	Front right door lock	DX	PCS	63.28
B6105210B1	右前侧门锁体	Front right door lock	LX, EX	PCS	108.24
B6105230A2	右前侧车门门把手总成	Outer handle assy, front right door		PCS	59.40
B6105234	右前侧车门门把手座	Handle seat, front right door		PCS	10.56
B6105300	左侧车门内扣手总成	Inner handle, left door		PCS	16.82
B6105318	塑料螺母	Plastic nut		PCS	0.46
B6105400	右侧车门内扣手总成	Inner handle, rear right door		PCS	16.82
B6106110	左前车门上铰链组件	Upper hinge,front left door		PCS	12.61
B6106120	左前车门下铰链组件	Lower hinge,front left door		PCS	12.61
B6106210	右前车门上铰链组件	Upper hinge,front right door		PCS	12.61
B6106220	右前车门下铰链组件	Lower hinge,front right door		PCS	12.61
B6107111	左前侧车门玻璃泥槽	Glass seal,front left door		PCS	30.12
B6107112	左前侧车门玻璃外切水条	Weather Strip, front left door		PCS	32.67
B6107113	左前侧车门密封条	Front left door seal		PCS	42.06
B6107114	侧车门密封条卡扣A	Door seal clip A		PCS	0.26
B6107117	左前门框密封条	Front left door frame seal		PCS	21.04
B6107211	右前侧车门玻璃泥槽	Glass seal,front right door		PCS	30.12
B6107212	右前侧车门玻璃外切水条	Weather Strip, front right door		PCS	32.67
B6107213	右前侧车门密封条	Front right door seal		PCS	42.06
B6107217	右前门框密封条	Front right door frame seal		PCS	21.04
B6109100	前车门限位器	Front door stopper		PCS	10.96
B6109112	侧车门缓冲块	Door damper		PCS	0.53
B6200120	左后侧车门活动导轨总成	Glass rail assy, rear left door		PCS	22.70
B6200121	左后侧车门玻璃活动导轨	Glass rail, rear left door		PCS	15.18
B6200122	左后侧车门玻璃活动导轨上支架	Glass rail bracket, rear left door		PCS	2.51
B6200127	左后车门导轨胶套	Glass rail sleeve, rear left door		PCS	0.26

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B6200220	右后侧车门活动导轨总成	Glass rail assy, rear right door		PCS	22.70
B6200221	右后侧车门玻璃活动导轨	Glass rail, rear right door		PCS	15.18
B6200222	右后侧车门玻璃活动导轨上支架	Glass rail bracket, rear right door		PCS	2.51
B6200227	右后车门导轨胶套	Glass rail sleeve, rear right door		PCS	0.26
B6201001	左后车门总成	Rear left door assy.		PCS	751.72
B6201002	右后车门总成	Rear right door assy.		PCS	751.72
B6202010	左后门防雨帘组件	Rain shield,rear left door		PCS	19.40
B6202020	右后门防雨帘组件	Rain shield,rear right door		PCS	19.40
B6202110B97	左后门内护板总成	Rear left door interior	grey,upper deep lower pale	PCS	154.81
B6202111	左后门内护板装饰条	Interior trim,rear left door		PCS	35.80
B6202118	后门螺钉堵盖	Rear right door screw cap		PCS	0.86
B6202210B97	右后门内护板总成	Rear right door interior	grey,upper deep lower pale	PCS	154.81
B6203100	左后侧车门车窗玻璃	Rear left door glass		PCS	38.43
B6203112	左后门三角玻璃	Triangular glass, rear left door		PCS	14.60
B6203200	右后侧车门车窗玻璃	Rear right door glass		PCS	38.43
B6203212	右后门三角玻璃	Triangular glass, rear right door		PCS	14.60
B6204100	左后侧车门玻璃升降器总成	Glass lifter,rear left door		PCS	122.10
B6204200	右后侧车门玻璃升降器总成	Glass lifter, rear right door		PCS	122.10
B6205110	左后门锁体	Rear left door lock		PCS	66.88
B6205110B1	左后门锁体	Rear left door lock	central locking	PCS	109.90
B6205122	左后侧车门门把手B	Door outer handle B, rear left door		PCS	6.60
B6205125	左后侧车门门把手座	Handle seat, rear left door		PCS	10.56
B6205130A2	左后侧车门门把手总成	Outer handle assy, rear left door		PCS	59.40
B6205210	右后门锁体	Rear door lock		PCS	66.88
B6205210B1	右后门锁体	Rear door lock	central lock	PCS	109.90
B6205222	右后侧车门门把手B	Door outer handle B, rear right door		PCS	6.60

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B6205225	右后侧车门门把手座	Handle seat, rear right door		PCS	10.56
B6205230A2	右后侧车门门把手总成	Outer handle assy, rear right door		PCS	59.40
B6206110	左后侧门上铰链组件	Upper hinge,Rear left door		PCS	11.22
B6206120	左后侧车门下铰链组件	Lower hinge,Rear left door		PCS	11.22
B6206210	右后侧门上铰链组件	Upper hinge,Rear right door		PCS	11.22
B6206220	右后侧车门下铰链组件	Lower hinge,Rear right door		PCS	11.22
B6207111	左后侧车门玻璃泥槽	Glass seal,rear left door		PCS	25.37
B6207112	左后侧车门玻璃外切水条	Weather Strip, rear left door		PCS	32.67
B6207113	左后侧车门三角玻璃密封条	Triangular glass seal, rear left door		PCS	17.97
B6207114	左后侧车门密封条	Front right door seal		PCS	37.04
B6207117	左后门框密封条	Rear left door frame seal		PCS	21.04
B6207211	右后侧车门玻璃泥槽	Glass seal,rear right door		PCS	25.37
B6207212	右后侧车门玻璃外切水条	Weather Strip, rear right door		PCS	32.67
B6207213	右后侧车门三角玻璃密封条	Triangular glass seal, rear right door		PCS	17.97
B6207214	右后侧车门密封条	Rear right door seal		PCS	37.04
B6207217	右后门框密封条	Rear right door frame seal		PCS	21.04
B6209100	后车门限位器	Rear door stopper		PCS	10.82
B6800100A2B15	驾驶员座椅总成	Front passenger's seat assy.	woolen,pale grey,with waist adjuster	PCS	621.72
B6800100A4B15	驾驶员座椅总成	Front passenger's seat assy.	leatherette,pale grey,with waist adjuster	PCS	660.00
B6800100B15	驾驶员座椅总成	Front passenger's seat assy.	woolen,pale grey,without waist adjuster	PCS	674.30
B6800100B1B15	驾驶员座椅总成	Front passenger's seat assy.	leather,pale grey,with waist adjuster, heater	PCS	718.74
B6800110	驾驶员座本体总成	Driver's seat body		PCS	349.80
B6802111B15	驾驶员座椅下护板	Driver's seat bottom fender	pale grey	PCS	3.43
B6802113B15	驾驶员座椅前脚盖	Driver's seat stand,front	pale grey	PCS	1.12
B6802114B15	驾驶员座椅后脚盖	Driver's seat stand,rear	pale grey	PCS	1.12
B6802115	驾驶员座椅左盖板	Driver's seat cap,left		PCS	19.14

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B6802116	驾驶员座椅右盖板	Driver's seat cap,right		PCS	19.14
B6802117	座垫高度调节旋钮盖板	Driver's Seat cushion adjuster cap		PCS	4.22
B6802118	座椅靠背角度提钮盖板	Backrest adjuster cap, driver's seat		PCS	1.58
B6802119	调腰器提钮盖板	Waist adjuster cap		PCS	9.64
B6804000	驾驶员座滑轨总成	Driver's seat slide		PCS	211.09
B6808100A2	前座椅头枕	Front seat pillow	leather	PCS	59.40
B6900100A2B15	副驾驶座椅总成	Front passenger's seat assy.	leather,pale grey	PCS	522.06
B6900100A3B15	副驾驶座椅总成	Front passenger's seat assy.	leatherette,pale grey	PCS	521.40
B6900100B15	副驾驶座椅总成	Front passenger's seat assy.	woolen,pale grey	PCS	480.72
B6900110	副驾驶员座本体总成	Front passenger's seat body		PCS	237.60
B6902111B15	副驾驶座椅下护板	Front passenger's seat bottom fender	pale grey	PCS	3.43
B6902113B15	副驾驶座椅前脚盖	Front passenger's seat stand,front	pale grey	PCS	1.12
B6902114B15	副驾驶座椅后脚盖	Front passenger's seat stand,rear	pale grey	PCS	1.12
B6902115	副驾驶员座椅左盖板	Front passenger's seat cap,left		PCS	19.14
B6902116	副驾驶员座椅右盖板	Front passenger's seat cap,right		PCS	19.14
B6902118	座椅靠背角度提钮盖板	Front passenger's seat backrest adjuster cap		PCS	1.58
B6904000	副驾驶员座滑轨总成	Front passenger's seat slide		PCS	154.41
B7003000A2B15	后座椅座垫	Rear seat cushion	leather, pale grey	PCS	323.40
B7003000A3B15	后座椅座垫	Rear seat cushion	leatherette, pale grey	PCS	297.00
B7003000B15	后座椅座垫	Rear seat cushion	woolen, pale grey	PCS	252.12
B7005100A2B15	后座椅左靠背	Rear seat left back rest assy.	leather, pale grey	PCS	333.30
B7005100A3B15	后座椅左靠背	Rear seat left back rest assy.	leatherette, pale grey	PCS	306.53
B7005100B15	后座椅左靠背	Rear seat left back rest assy.	woolen, pale grey	PCS	258.72
B7005111A2	后座椅左靠背本体	Rear seat left back rest	leather	PCS	287.10
B7005200A2B15	后座椅右靠背	Rear seat right back rest assy.	leather, pale grey	PCS	226.45
B7005200A3B15	后座椅右靠背	Rear seat right back rest assy.	leatherette, pale grey	PCS	207.24

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B7005200B15	后座椅右靠背	Rear seat right back rest assy.	woolen, pale grey	PCS	175.56
B7005211	后座椅右靠背本体	Rear seat right back rest	woolen	PCS	3.83
B7005211A2	后座椅右靠背本体	Rear seat right back rest	leather	PCS	180.25
B7005300A2B15	后座椅左侧背	Rear seat left side rest	leather, pale grey	PCS	63.16
B7005300A3B15	后座椅左侧背	Rear seat left side rest	leatherette, pale grey	PCS	58.08
B7005300B15	后座椅左侧背	Rear seat left side rest	woolen, pale grey	PCS	46.20
B7005400A2B15	后座椅右侧背	Rear seat right side rest	leather, pale grey	PCS	63.16
B7005400A3B15	后座椅右侧背	Rear seat right side rest	leatherette, pale grey	PCS	58.08
B7005400B15	后座椅右侧背	Rear seat right side rest	woolen, pale grey	PCS	46.20
B7006100A2	中央扶手总成	Middle handrail	leather	PCS	79.20
B7007111	左靠背左铰链	Left hinge, rear seat		PCS	3.83
B7007211	右靠背右铰链	Right hinge, rear seat		PCS	3.83
B7007300	后座椅靠背中间铰链	Middle hinge, rear seat		PCS	17.29
B7008100A2	后座椅头枕	Rear seat pillow	leather	PCS	46.20
B7901500	CD播放器总成	CD player		PCS	693.00
B7901700	DVD播放器总成	DVD player		PCS	3498.00
B7901700B1	DVD播放器总成(GPS)	DVD player	with GPS	PCS	5002.80
B7903170	收放机天线放大器总成	Antenna assy.		PCS	92.40
B7904310	静音滤波器及支架	Noise filter		PCS	14.06
B7909110	前门扬声器	Front door loudspeaker		PCS	23.76
B7909210	左前高音头组件	Left alt loudspeaker		PCS	13.20
B7909220	右前高音头组件	Right alt loudspeaker		PCS	13.20
B7909510	后扬声器	Rear loudspeaker		PCS	36.96
B7917710	倒车监控摄像头	Reverse monitor camera	EX	PCS	283.14
B7917711	摄像头装饰罩	Camera cap	EX	PCS	1.98
B7917730	倒车监控摄像头馈线	Reverse monitor harness	EX	PCS	38.28

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B8100100	HVAC总成	HVAC assy.		PCS	1010.18
B8105100	冷凝器总成	Condensor		PCS	277.20
B8106010	膨胀阀	Expansion Valve		PCS	62.55
B8107110	蒸发器芯子组件	Evaporator core		PCS	237.60
B8107140	蒸发器左壳体	Evaporator shell,L		PCS	63.36
B8107150	蒸发器右壳体	Evaporator shell,R		PCS	67.32
B8107151	暖风机散热器进出管管夹	Clamp		PCS	2.64
B8107160	暖风机散热器总成	Heater radiator		PCS	118.80
B8108012	暖风机进水管	Heater intake pipe		PCS	6.60
B8108013	暖风机出水管	Heater outtake pipe		PCS	6.60
B8108100	空调高压软管总成	High-pressure hose		PCS	36.30
B8108300	空调高压硬管总成	High-pressure tube		PCS	87.12
B8108310	空调高低压管夹	Clamp		PCS	6.60
B8108322	空调高压硬管支架A	High-pressure tube bracket A		PCS	2.64
B8108331	高压硬管加注口盖	Filler cap,high-pressure tube		PCS	0.66
B8108500	空调低压软管总成	Low-pressure hose		PCS	63.36
B8108510	空调高低压管支架总成	Pipe bracket assy.		PCS	6.60
B8108512	支撑板	Support plate		PCS	0.66
B8108513	双头缓冲螺栓	Stud		PCS	0.66
B8108514	空调高低压管支架	Pipe bracket		PCS	0.66
B8111012	暖气进/出管隔离圈	Separate plate,I/O heater pipes		PCS	3.96
B8111014	高低压管隔离圈	Separate plate,H/L pressure pipes		PCS	3.96
B8112100	电动空调控制面板及开关总成	Air conditioner control panel	MT	PCS	356.40
B8112100B1	自动空调控制面板及开关总成	Air conditioner control panel	AT	PCS	604.56
B8114200	蒸发器温度传感器	Evaporator Temperature senser		PCS	10.56
B8121150	进风箱上壳体	Bellow shell,upper		PCS	26.40

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B8121160	进风箱下壳体	Bellow shell,lower		PCS	22.44
B8121431	乘客席左风管前段	Left ventilation fore part,Passenger side		PCS	5.28
B8121432	乘客席左风口后段	Left ventilation rear part,Passenger side		PCS	5.28
B8121441	乘客席右风管前段	Right ventilation fore part,Passenger side		PCS	5.28
B8121442	乘客席右风口后段	Right ventilation rear part,Passenger side		PCS	5.28
B8123630	通风口组件	Trunk ventilation		PCS	8.58
B8202100	左外后视镜总成	Left wing mirror	Dongguang	PCS	140.45
B8202100B1	左外后视镜总成	Left wing mirror	Donnelly	PCS	198.61
B8202200	右外后视镜总成	Right wing mirror	Dongguang	PCS	140.45
B8202200B1	右外后视镜总成	Right wing mirror	Donnelly	PCS	198.61
B8204010B15	左遮阳板大固定座组件	Left sunvisor fixing seat	pale grey	PCS	3.96
B8204020B15	右遮阳板大固定座组件	Right sunvisor fixing seat	pale grey	PCS	3.96
B8204030B15	遮阳板固定挂钩	Sunvisor fixing hook	pale grey	PCS	1.32
B8204100B15	左遮阳板总成	Left sunvisor	pale grey	PCS	38.28
B8204200B15	右遮阳板总成	Right sunvisor	pale grey	PCS	38.28
B8211170	空滤器	Air filter,blower		PCS	19.80
B8215100B15	安全拉手	Safety handle		PCS	8.18
B8400010	左前轮罩纵梁总成	Left front longeron and wheel cap assy.		PCS	511.63
B8400020	右前轮罩纵梁总成	Right front longeron and wheel cap assy.		PCS	533.64
B8400030	发动机罩锁体安装立柱总成	Engine hood lock fixing plate		PCS	27.82
B8400120	右前纵梁外板前段总成	Right front longeron fore part		PCS	10.64
B8400130	左前纵梁外板前段总成	Left front longeron fore part		PCS	10.97
B8401100	水箱上横梁总成	Radiator upper beam		PCS	138.68
B8401200	水箱下横梁总成	Radiator lower beam		PCS	83.33
B8402000	发动机罩总成	Engine hood		PCS	701.60
B8402300	发动机罩撑杆组件	Hood prop assy.		PCS	4.22

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
B8402321	发动机罩撑杆放置卡槽	Hood prop hodler		PCS	1.06
B8402400	机仓锁拉索	Engine hood lock cable		PCS	14.52
B8402510	发动机罩锁体机仓锁	Engine hood lock		PCS	29.04
B8402610	发动机罩左铰链组件	Engine hood left hinge		PCS	11.71
B8402620	发动机罩右铰链组件	Engine hood right hinge		PCS	11.71
B8402810	发动机仓盖隔热垫	Engine hood heat insulator		PCS	46.20
B8402811	发动机仓前密封条	Engine room front seal		PCS	2.64
B8402812	发动机仓前密封条卡扣	Engine room front seal clip		PCS	0.26
B8402821	发动机仓后密封条	Engine room rear seal		PCS	2.68
B8402822	发动机仓后密封条卡扣	Engine room rear seal clip		PCS	0.26
B8403111	左翼子板	Front left fender		PCS	134.03
B8403211	右翼子板	Front right fender		PCS	134.03
BAC1001210	后悬置支架带组件	Rear suspension component		PCS	47.41
BAC1001251	后悬置连接支架	Rear suspension connecting bracket		PCS	43.56
BAC1001310	左悬置组件及安装支架	Left suspension component		PCS	58.38
BAC1001351	左悬置连接支架	Left suspension connecting bracket		PCS	44.88
BAC1001410	右悬置组件及安装支架	Right suspension component		PCS	132.50
BAC1104030	燃油硬管/喷油嘴连接软管组件	Hose connecting fuel tube and nozzle		PCS	16.33
BAC1109220	发动机进气软管总成	Engine section pipe		PCS	26.94
BAC1130152	碳罐/燃油蒸汽控制阀连接软管	Hose connecting canister and control vavle		PCS	1.72
BAC1205100	前级净化器总成	Exhaust purifier,fore part		PCS	314.38
BAC1205200	后级净化器总成	Exhaust purifier,rear part		PCS	727.76
BAC1303111	散热器出水管	Radiator drain pipe		PCS	7.39
BAC1303121	散热器进水管	Radiator intake pipe		PCS	15.27
BAC2901100	副车架总成	Sub-frame assy.		PCS	435.60
BAC3406100	转向油泵进油管总成	Steering pump intake pipe assy.		PCS	19.80

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
BAC3406200	转向器进油管总成	Steering intake pipe assy.		PCS	72.60
BAC3407100	动力转向油泵总成	Steering pump assy.		PCS	392.04
BAC3612100B4	电喷ECU	ECU	for LF481 engine	PCS	864.60
BAC3703211	蓄电池压板连杆	Battery press beam		PCS	2.47
BAC3703212	蓄电池塑料压块	Battery plastic press plate		PCS	0.92
BAC3703213	蓄电池拉杆	Battery draglink		PCS	2.13
BAC3703214	蓄电池底盖	Battery bottom		PCS	8.58
BAC3703215	蓄电池托架	Battery bracket		PCS	9.86
BAC8108012	暖风机进水管	Heater intake pipe		PCS	6.60
BAC8108013	暖风机出水管	Heater outtake pipe		PCS	6.60
BAC8108100	空调高压软管总成	High-pressure hose		PCS	36.30
BAC8108500	空调低压软管总成	Low-pressure hose		PCS	66.00
BX2011A1-100A/QC T73	保险丝	Fuse	Main power	PCS	5.28
BX2011A1-30A/QC T73	保险丝	Fuse	Rear defroster	PCS	4.62
BX2011A1-40A/QC T73	保险丝	Fuse	Blower	PCS	4.62
BX2011A1-60A/QC T73	保险丝	Fuse	Driving room power	PCS	4.62
BX2011F-10A/QC T73	保险丝	Fuse	wing mirror	PCS	0.60
BX2011F-10A/QC T73	保险丝	Fuse	Spare fuse	PCS	0.60
BX2011F-15A/QC T73	保险丝	Fuse	Spare fuse	PCS	0.60
BX2011F-20A/QC T73	保险丝	Fuse	Spare fuse	PCS	0.60
BX2011F-25A/QC T73	保险丝	Fuse	Spare fuse	PCS	0.60
BX2011F-30A/QC T73	保险丝	Fuse	Spare fuse	PCS	0.60
BX2011F-5A/QC T73	保险丝	Fuse	Spare fuse	PCS	0.60
BX2011F-7.5A/QC T73	保险丝	Fuse	Spare fuse	PCS	0.60
C5W/GB 15776-2001	灯泡	Bulb		PCS	1.19
CL-7X17-B	线束L型卡钉	Harness clamp		PCS	0.24

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
CS03	线束卡钉扎带	Harness clamp		PCS	0.53
DWJ-H26	线束F型支架	Harness clamp		PCS	0.49
GB/T889.2	I 型非金属嵌件六角锁紧螺母	I non metal hex lock nut	M10X1.25	PCS	0.71
H1/GB 15776-2001	灯泡	Bulb		PCS	13.20
H3/GB 15776-2001	灯泡	Bulb		PCS	13.20
JD101K-70A/QC T73	继电器	Relay	Blower	PCS	23.76
JD1912-40A/QC T73	继电器	Relay	Sub power	PCS	8.58
JD1926-30A/QC T73	继电器	Relay	speed regulation	PCS	8.58
JD1927-30A/QC T73	继电器	Relay	Rear defroster	PCS	8.58
L1001120	发动机辅助悬置组件	Engine suspension component		PCS	43.79
L1001201	后悬置支架	Rear suspension bracket		PCS	36.96
L1001210	后悬置支架带组件	Rear suspension bracket component		PCS	36.37
L1001310	发动机左悬置组件	Left suspension component		PCS	56.43
L1001410	发动机右悬置及支架总成	Engine right suspension assy.		PCS	117.59
L1117100	汽油滤清器总成	Fuel filter		PCS	7.51
L1200011	前密封垫	Front gasket		PCS	12.42
L1600013	卡片	Clip		PCS	0.29
L1600014	垫密圈	washer		PCS	0.24
L1600015	支架	Bracket		PCS	1.25
L1609000	离合器工作缸	Clutch slave cylinder		PCS	49.21
L1703015	软轴支架	Cable bracket		PCS	11.26
L1703017	E型卡	E clip		PCS	0.96
L2203014	中间支撑安装支架	Mounting bracket		PCS	52.54
L3106200	轮胎气门嘴	Valve component		PCS	2.99
L3506106	E型卡片	E shape clip		PCS	2.88
L3703100	蓄电池总成	Battery assy.		PCS	507.47

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
L3921018	车侧门标牌	Side LOGO“1.6L”		PCS	6.00
B8201000	内视镜	Rearview mirror		PCS	36.96
L8212012	子母扣	Inlay button		PCS	0.49
LAA8103100B1	空调压缩机总成	Compressor		PCS	827.40
LAL1200018	前排气管密封圈	Front gasket		PCS	5.77
LBA1130107B1	软管 V	Hose V		PCS	22.46
LBA3407101	转向油泵支架	Steering pump bracket		PCS	18.35
LBA3407102	转向油泵调节支架	Steering pump adjustor		PCS	9.66
LBA3407103	皮带	Belt, steering pump		PCS	6.60
LBA8103100B1	空调压缩机总成	Compressor		PCS	516.00
LBA8103101B1	空调压缩机支架	Compressor bracket		PCS	43.20
LBA8103109	压缩机皮带	Compressor belt		PCS	15.43
LBA8103120	压缩机皮带张紧轮组件	Compressor tensioner		PCS	31.28
LBA8103121	主轴	Main shaft		PCS	1.80
LBA8103122	主轴轴套	Shaft sleeve		PCS	0.60
LBA8103123	张紧轮防护罩	Tensioner shield		PCS	0.60
M23408	线束卡钉扎带	Harness clamp		PCS	0.71
M23438	线束支架	Harness clamp		PCS	0.63
M32481	线束支架	Harness clamp		PCS	0.91
M32483	线束支架	Harness clamp		PCS	0.63
P21W/GB 15776-2001	灯泡	Bulb	Reverse lamp	PCS	3.96
PY21W/GB 15776-2001	灯泡	Bulb	Steering lamp	PCS	2.64
Q1400616	六角头螺栓与平垫圈组合件	Hex bolt and flat washer		PCS	1.32
Q1400625	六角头螺栓与平垫圈组合件	Hex bolt and flat washer		PCS	1.32
Q1400630	六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer		PCS	0.40
Q1400825	六角头螺栓与平垫圈组合件	Hex bolt and flat washer		PCS	0.37

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
Q1401030	六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer		PCS	0.90
Q1401235	六角头螺栓和平垫圈组合件	Hex bolt, taper springness washer and flat washer		PCS	1.29
Q1410516	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer		PCS	0.21
Q1410520L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer		PCS	0.21
Q1410616	六角头螺栓和锥形弹性垫圈组合件	Hex bolt, taper springness washer and flat washer		PCS	0.21
Q1410616L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer		PCS	0.23
Q1410620	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer		PCS	0.40
Q1410620L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer		PCS	0.46
Q1410625	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer		PCS	0.28
Q1410630	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer		PCS	0.28
Q1410632L	六角法兰面螺栓和锥形弹性垫圈组合件	Hex bolt, taper springness washer and flat washer		PCS	0.38
Q1410820	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper springness washer		PCS	0.35
Q1410825L	六角头螺栓带锥形垫圈组合件	Hex bolt and taper springness washer		PCS	0.49
Q1410830	六角头螺栓和锥形弹性垫圈组合件	Bolt with springness washer		PCS	0.45
Q1460620	六角头螺栓弹簧垫圈和平垫圈组合件	Hex bolt and taper springness washer		PCS	0.50
Q14608100Q	六角头螺栓、弹簧垫圈和平垫圈组合件	Hex bolt and washers		PCS	0.96
Q1460825	六角头螺栓弹簧垫圈和平垫圈组合件	Hex bolt and taper springness washer		PCS	0.74
Q1460830	六角头螺栓和弹簧垫圈组合件	Hex bolt and washer		PCS	0.38
Q150B0620T1F30	六角头螺栓	Hex bolt		PCS	0.21
Q1800612	六角法兰面承面带齿螺栓	Hex flange bolt		PCS	0.34
Q1840610	六角法兰面螺栓	Hex flange bolt		PCS	0.18
Q1840612	六角法兰面螺栓	Hex flange bolt		PCS	0.18
Q1840612T1F30	六角法兰面螺栓	Hex flange bolt		PCS	0.21
Q1840616	安装螺栓	Hex flange bolt		PCS	0.22
Q1840616T1F30	六角法兰面螺栓	Hex flange bolt		PCS	0.21
Q1840620	六角法兰面螺栓	Hex flange bolt		PCS	0.20

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
Q1840625	六角法兰面螺栓	Hex flange bolt		PCS	0.28
Q1840645	六角法兰面螺栓	Hex flange bolt		PCS	0.40
Q18408105	六角法兰面螺栓	Hex flange bolt		PCS	1.03
Q1840816	六角法兰面螺栓	Hex flange bolt		PCS	0.33
Q1840816T1F30	六角法兰面螺栓	Hex flange bolt		PCS	0.32
Q1840820	六角法兰面螺栓	Hex flange bolt		PCS	0.35
Q1840835	六角法兰面螺栓	Hex flange bolt		PCS	0.49
Q1840855	六角法兰面螺栓	Hex flange bolt		PCS	0.67
Q1841216	六角法兰面螺栓	Hex flange bolt	only available with assembled parts	PCS	0.99
Q184A0612	六角法兰面螺栓	Hex flange bolt		PCS	1.32
Q184A1235	六角法兰面螺栓	Hex flange bolt		PCS	1.32
Q2101030TF2	内六角花形圆柱头螺钉	Inner hex screw		PCS	1.67
Q2214219	十字槽盘头自攻螺钉和大垫圈组合	Philips screw with washer		PCS	0.20
Q2215519F31	十字槽盘头自攻螺钉和大垫圈组合件	Philips screw with washer		PCS	0.26
Q2300512	十字槽盘头螺钉与平垫圈组合件	Philips screw with washer		PCS	1.32
Q2400820	十字槽沉头螺钉和锥形锁紧垫圈组合	Philips screw and washer		PCS	0.38
Q2540508	十字沉头螺钉	Philips screw		PCS	0.07
Q2560620F13	十字槽半沉头螺钉	Philips screw		PCS	0.17
Q2704216A	十字槽沉头螺钉	Philips screw		PCS	0.66
Q2706316	六角法兰面螺钉	Hex flange screw		PCS	0.18
Q2706316A	六角法兰面自攻螺钉	Hex flange tapping screw		PCS	0.66
Q2714819	十字槽盘头自攻螺钉	Philips self-tapping screw		PCS	0.12
Q2714825	十字槽凹穴六角头自攻螺钉	Philips self-tapping screw		PCS	0.12
Q2726395	十字槽盘头螺钉-F型	Philips screw with washer		PCS	0.11
Q2734216	十字槽大半圆头自攻螺钉	Philips self-tapping screw		PCS	0.07
Q2734816	十字槽大半圆头自攻螺钉	Philips self-tapping screw		PCS	0.09

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
Q2734816F30	十字槽大半圆头自攻螺钉	Philips tapping screw		PCS	0.09
Q2734819	十字槽半圆头自攻螺钉	Philips self-tapping screw		PCS	0.17
Q31208	板簧螺母	Nut		PCS	0.79
Q32005	六角法兰面螺母	Hex flange nut		PCS	0.30
Q32006	六角法兰面螺母	Hex flange bolt		PCS	0.24
Q32008	六角法兰面螺母	Hex flange nut		PCS	0.28
Q32008T13F3	六角法兰面螺母	Hex flange nut		PCS	0.30
Q32012	六角法兰面螺母	Hex flange bolt	only available with assembled parts	PCS	0.71
Q32206	六角头螺母和锥形垫圈组合件	Hex bolt and taper springness washer		PCS	0.50
Q33006	全金属六角法兰面锁紧螺母	Allmetal hex flange locknut		PCS	0.36
Q33010	自锁螺母	Lock nut		PCS	0.24
Q33810T13F3	非金属嵌件六角法兰面锁紧螺母	Non-metal hex flange lock nut		PCS	0.76
Q340B06	1型六角螺母	Hex nut		PCS	1.06
Q340B10	I 型六角螺母	I hex nut		PCS	0.20
Q350B06	六角薄螺母	Hex nut		PCS	0.13
Q37106	焊接方螺母	Square nut		PCS	0.09
Q387B22	六角开槽薄螺母	Hex nut		PCS	3.60
Q39748202	簧片螺母	Spring nut		PCS	0.15
Q398B03	塑料螺母	Plastic nut		PCS	0.42
Q40206	大垫圈	Big washer		PCS	0.14
Q40214	大垫圈	Big washer		PCS	0.78
Q40310	弹簧垫圈	Springness washer		PCS	0.10
Q41206	外锯齿锁紧垫圈	External teeth serrated lock washer		PCS	0.36
Q4400516	开口扁头抽芯铆钉	Rivet		PCS	0.16
Q5002528	开口销	Cotter pin		PCS	0.13
Q5003220	开口销	Cotter pin		PCS	0.07

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
Q5003230	开口销	Cotter pin		PCS	0.07
Q5101022	销轴	Axis pin		PCS	0.59
Q673B12	A型蜗杆传动式软管环箍	Steel spring hoop		PCS	1.18
Q67512	A型蜗杆传动式软管环箍	Hoop		PCS	2.15
Q67516	A型蜗杆转动式软管软管	Hoop		PCS	2.09
Q67520	A型蜗杆传动式软管环箍	Hoop		PCS	1.43
Q67525	A型蜗杆式弹性环箍	Hoop		PCS	2.43
Q676B45	B型蜗杆传动式环箍	Hoop		PCS	3.00
Q68610	单片管夹	Clamp		PCS	0.79
Q68618	单片管夹	Clamp		PCS	0.66
Q72716	地板Φ16橡胶堵盖	Floor rubber plug	Φ16	PCS	0.66
Q72725	Φ25橡胶堵盖	Rubber plug	Φ25	PCS	1.32
Q72730	地板Φ30橡胶堵盖	Floor rubber plug	Φ30	PCS	0.92
Q72745	地板Φ45橡胶堵盖	Floor rubber plug	Φ45	PCS	1.32
T11-3724072	线束支架	Harness clamp		PCS	1.00
W3W/GB 15776-2001	灯泡	Bulb	Registration lamp	PCS	1.32
XD-67	线束F型卡钉	Harness clamp		PCS	0.69
XJ-7X12-R	线束支架	Harness clamp		PCS	0.30
ZD3143X5	线束卡钉扎带	Harness clamp		PCS	1.07
BAC2203100	左传动轴总成	Left transmission shaft assy.		PCS	264.00
BAC2203200	右传动轴总成	Right transmission shaft assy.		PCS	340.56
L3921013B1	车尾车名标识牌	Rear LOGO“LIFAN”		PCS	13.80
B6202211	右后门内护板装饰条	Interior trim,rear right door		PCS	35.80
BAC3820000C1	组合仪表	Instrument cluster		PCS	407.55
BAC3820000D1	组合仪表	Instrument cluster		PCS	407.55
L1000000A1	发动机总成	Engine assy.		PCS	28452.00

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
L1701000A1	变速器总成	Transmission assy.		PCS	4553.50
04777997AA	气缸盖罩螺栓带胶圈	Cylinder head cover bolt		PCS	15.60
4777796AE	气缸盖罩总成	Cylinder Head Cover assy		PCS	1380.00
04777799AA	气缸盖罩垫片	Gasket, Cylinder Cover		PCS	435.75
6505239AA	气缸盖螺栓	Cylinder head bolt		PCS	16.00
53010533AA	气缸盖定位销	Pin		PCS	18.41
04693083AA	气缸垫	Cylinder head gasket		PCS	409.24
6101940	气缸盖连接螺栓	Bolt		PCS	5.14
04693124AA	工艺堵塞(带密封圈)	Plug		PCS	70.24
4693206AB	PCV阀软管(曲轴箱通风)	PCV valve vent hose		PCS	79.30
4777796AE	气缸盖罩总成	Cylinder Head Cover assy		PCS	1380.00
4693304AA	排气摇臂	Intake swing arm		PCS	200.02
04777783AA	进气摇臂轴隔圈	Intake swing arm spacer		PCS	15.91
4777785AA	排气摇臂轴组件(含堵头)	Intake swing arm shaft		PCS	222.61
4693122AA	凸轮轴	Camshaft		PCS	900.00
4777879AB	进气摇臂(右)	Intake swing arm (R)		PCS	200.02
4777778AB	进气摇臂(左)	Intake swing arm (L)		PCS	200.02
04777776AA	进气摇臂轴组件(含堵头)	Intake swing arm shaft		PCS	339.58
4777050AC	气门弹簧锁片	Valve Spring lock		PCS	2.00
4777774AA	气门弹簧座	Valve Spring Retainer		PCS	12.34
4777773AA	气门弹簧	Valve Spring		PCS	35.00
4777772AC	排气门	Exhaust Valve		PCS	115.97
4777770AB	进气门	Intake Valve		PCS	82.64
6505763AA	应为气缸体和基板连接螺栓 (M8X1.25X85)	Bolt, connecting signal panel and crankshaft		PCS	4.00
6100945	曲轴主轴承螺栓	Bolt, crankshaft main bearing		PCS	20.00
4694106	气缸体与基板定位销	Pin		PCS	12.00

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
04777689AA	1, 2, 4, 5#曲轴主轴瓦(上)	1,2,4,5# crankshaft main bearing(upper)		set	4.18
5015906AB	3#曲轴主轴瓦(推力轴承)	3# crankshaft main bearing	thrust bearing	set	60.00
PBS0519PC	活塞, 活塞销和连杆组件	Piston, pin and rod		set	1682.80
5019834AA	活塞环组件	Piston rings group		set	793.43
5015910AA	连杆轴瓦	Rod Bearing		set	2.00
5015902AA	1, 2, 4, 5#曲轴主轴瓦包	1,2,4,5# crankshaft main bearing packing		set	504.00
4667198	曲轴前油封	CRANKSHAFT REAR SEAL		PCS	60.62
4693110AB	张紧器塞(带铜垫片)	Tensioner plug		PCS	125.40
4693261AB	张紧器	Tensioner		PCS	386.00
6505690AA	前盖螺栓	Front cover bolt		PCS	15.08
04777680AA	前盖密封圈组	Front cover seals		PCS	74.94
4777710AB	正时链导板(压紧张紧轮)	Timing chain guide	compress tensioner wheel	PCS	210.00
4777699AA	正时链条	Timing chain		PCS	530.00
6506197AA	凸轮轴正时链轮连接螺栓	Bolt, timing chain wheel		PCS	15.00
4777736AA	凸轮轴正时链轮	Timing chain wheel		PCS	316.99
4777707AA	正时链导板	Timing chain guide		PCS	210.00
4777694AA	曲轴链轮	Crankshaft chain wheel		PCS	185.00
6506062AA	前盖螺栓	Front cover bolt		PCS	18.00
4693140AA	机滤盖	Oil filter cap		PCS	354.00
L1017200A1	机油滤清器滤芯	Oil filter element		PCS	9.12
4777667AB	机滤座	Oil filter base		PCS	245.00
04693104AA	机油泵密封圈(进)	Oil pump seal (in)		PCS	80.86
04693164AA	机油泵密封圈(出)	Oil pump seal (out)		PCS	77.40
4777836AC	前盖机油泵组件	Oil pump component, front cover		PCS	405.00
4693165AA	机油集滤器组件	Oil strainer		PCS	120.00
6506403AA	螺栓组件	Bolt		PCS	2.40

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
04777835AA	油底壳垫片	Oil Pan gasket		PCS	143.95
L1009104A1	放油螺塞组件(含铜垫圈)	Oil plug	with washer	PCS	3.75
6506402AA	螺栓组件	Bolt		PCS	9.00
6506401AA	螺栓组件	Bolt		PCS	14.40
04621939AB	曲轴后油封	Crankshaft rear seal		PCS	145.62
L1009221A1	机油尺套管	Oil level gauge guide		PCS	16.80
L1009211A1	机油尺	Oil level gauge		PCS	6.00
04777845AE	进气歧管	Intake manifold		PCS	360.00
04693125AA	绝对压力传感器(MAP)	MAP sensor		PCS	300.00
L1132110B1	节气门体总成	Throttle assy		PCS	216.00
L1132102A1	节气门垫片	Throttle gasket		PCS	0.30
04777852AB	排气歧管垫片	Exhaust manifold gasket		PCS	175.10
04693119AB	节温器组件	Thermostat assy.		PCS	471.20
L1025100A1	张紧轮	Tensioner assy		PCS	126.28
4777681AB	曲轴皮带轮	Crankshaft Pulley		PCS	396.00
6506442AA	曲轴皮带轮固定螺栓	Bolt, crankshaft Pulley		PCS	16.00
L1025200A1	惰轮(带固定螺栓)	Idle gear	with bolt	PCS	60.05
L3407210A1	动力转向泵皮带轮	Pulley, power steering pump		PCS	44.40
L1025400B1	传动皮带	Belt		PCS	93.60
05033216AC	1#高压线	Ignition cable 1	1,2,3,4must be ordered in suite	PCS	113.41
05033217AC	2#高压线	Ignition cable 2	1,2,3,4must be ordered in suite	PCS	112.85
05033218AC	3#高压线	Ignition cable 3	1,2,3,4must be ordered in suite	PCS	114.31
05033219AC	4#高压线	Ignition cable 4	1,2,3,4must be ordered in suite	PCS	114.98
04777800AC	火花塞套管油封	Seal, spark pulg guild pipe		PCS	41.72
5033076AB	火花塞	Spark Plug		PCS	52.82
6507047AA	点火线圈螺栓组件	Ignition Coil bolt		PCS	22.00

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
5269670AB	点火线圈	Ignition Coil		PCS	912.00
04693243AA	点火线圈隔热垫	Heat insulator, Ignition Coil		PCS	25.00
4897125AA	O型圈	O seal		PCS	231.57
4418257AB	夹箍	Clamp		PCS	3.02
4418257AB	夹箍	Clamp		PCS	3.02
4897125AA	O型圈	Pressure adjustor seal		PCS	231.57
4891338AA	油轨总成	Fuel Distributor		PCS	2200.27
04693097AA	进水管接头密封圈	Inlet tube joint seal		PCS	18.45
L3708100	起动电机总成	Startor assy.		PCS	298.80
L3701100B1	发电机总成	Generator assy.		PCS	496.20
L1002118A1	变速器挡板	Transmission fender		PCS	1.18
L1005300A1	飞轮总成	Flywheel		PCS	161.40
L1005301A1	飞轮螺栓	Flywheel bolt	M10×1×22	PCS	1.25
L1601200A1	离合器从动盘总成	Clutch Driven Plate		PCS	126.31
L1601100A1	离合器压盘	Clutch press plate		PCS	183.60
L1602202A1	分离轴承	Throwout bearing		PCS	115.00
05269870AB	水温传感器	Water Temperature Sensor		PCS	296.17
05293161AA	凸轮轴位置传感器	Camshaft Position Sensor		PCS	228.00
04606093AC	爆震传感器	Knock Sensor		PCS	581.60
L3612320B1	曲轴位置传感器	Crankshaft Position Sensor	Sun&teck	PCS	100.08
6501957	螺栓组合件	Bolt		PCS	3.00
L4001000C8	B端子线	B end harness		PCS	60.00
L1130301B1	碳罐控制阀	Canister Control Valve	Sun&teck	PCS	50.60
L3612260B1	氧传感器	Oxygen Sensor	Sun&teck	PCS	201.90
L1701109A1	定位销	Pin		PCS	0.76
L1701102A1	输入轴前轴承	Input shaft front bearing		PCS	197.52

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
L1701212A1	各档叉轴衬套	Forkshaft sleeve		PCS	6.39
L1701213A1	换、选档轴衬套	Gear shift and choose shaft sleeve		PCS	6.60
L1701106A1	输出轴前轴承(外圈)	Out ring, Input shaft front bearing		PCS	128.71
L1701107A1	输出轴前轴承(保持架组件)	Retainer, Input shaft front bearing		PCS	43.85
L1701104A1	输出轴前轴承压板	Pressure plate, nput shaft front bearing		PCS	1.46
L1701134A1	双头螺栓	Thru-stud		PCS	2.36
L1701103A1	换档钢球定位装置	Steel ball locating device		PCS	58.59
L1701138A1	磁铁	Magnet		PCS	8.34
L1701114A1	放油螺栓	Oil plug		PCS	0.83
L1701204A1	差速器前、后油封	Differential seal	front, rear	PCS	13.14
L1701101A1	离合器壳体	Clutch shell		PCS	702.37
Q5270624	螺旋弹性销	Pin		PCS	0.76
L1701218A1	换档轴衬套	Gear shift shaft sleeve		PCS	9.66
L1702310A1	换档摇臂组件	Shift swing arm element		PCS	12.16
L1702100A1	选、换档机构	Gear shift and choose system		PCS	67.28
L1702220A1	选档摇臂组件	Choose swing arm element		PCS	13.00
L1701219A1	选档轴衬套	Gear choose shaft sleeve		PCS	8.20
Q43115	选档轴卡环(轴用弹性挡圈)	Spring circlip for shaft		PCS	0.28
Q5220624	选档固定销	Pin		PCS	0.49
L1701201A1	变速器壳体	Transmission shell		PCS	658.44
L1701214A1	导油管	Oil guide tube		PCS	4.24
L2303215B1	车速传感器从动齿轮	Speedometer driven gear		PCS	8.40
L3612250	里程表传感器	Speedometer sensor		PCS	48.79
Q1410620F9	曲轴位置传感器螺栓	Bolt, crankshaft position sensor		PCS	0.30
L1701163A1	垫片--限油、放油螺塞(铜)	Washer	copper	PCS	0.76
L1701162A1	限油螺塞	Oil limited plug		PCS	1.46

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
L1701204A1	差速器前、后油封	Differential seal	front, rear	PCS	13.14
L1701202A1	输入输出轴后轴承	Input and output shaft rear bearing		PCS	99.52
L1701208A1	换、选档轴油封	Gear shift and choose shaft seal		PCS	5.98
L1701132A1	输入输出轴卡环	Circlip, Input and output shaft		PCS	0.83
Q1410820F9	热回管螺栓	Bolt		PCS	0.49
L1701110A1	后盖总成	Rear cover		PCS	19.88
L1701213A1	换、选档轴衬套	Gear shift and choose shaft sleeve		PCS	6.60
L1701212A1	各档叉轴衬套	Forkshaft sleeve		PCS	6.39
L1701120A1	倒档灯开关总成	Reverse light switch		PCS	23.00
Q9000B	通气阀总成	Vent valve		PCS	3.61
L1702300A1	换档轴总成	Gear shift shaft assy.		PCS	14.25
L1701311A1	输入轴	Input shaft		PCS	365.85
L1701313A1	导油板堵盖	Oil guide plug		PCS	0.63
L1701364A1	三、四、五档滚针轴承	Needle bearing		PCS	6.26
L1701330A1	三档主动齿轮总成	Third drive gear assy.		PCS	160.96
L1701365A1	三、四档同步环	Third、forth gear synchronize rim		PCS	44.62
L1701363A1	三、四、五档齿毂卡环	Third、forth、fifth gear hub circlip		PCS	0.97
L1701340A1	四档主动齿轮总成	Forth drive gear assy.		PCS	160.96
L1701382A1	半挡环	Semi-circlip	5	PCS	4.10
L1701381A1	挡环	Circlip		PCS	3.34
Q523048	止动销	Pin		PCS	0.28
L1701350A1	五档主动齿轮总成	Fifth drive gear assy.		PCS	187.58
L1701367A1	五档同步环	Fifth gear synchronize rim		PCS	35.72
L1701378A1	倒档同步环	Reverse gear synchronize rim		PCS	24.88
L1701375A1	倒档同步锥总成	Reverse gear synchronize assy.		PCS	76.10
L1701446A1	同步外环-一二档同步器	First、second gear synchronize outer rim		PCS	29.26

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
L1701447A1	同步锥环-一、二档同步器	First、second gear synchronize taper rim		PCS	35.10
L1701448A1	同步内环-一、二档同步器	First、second gear synchronize inner rim		PCS	29.26
L1701420A1	一档从动齿轮总成	First driven gear assy.		PCS	197.52
L1701459A1	一、二档滚针轴承	Needle bearing		PCS	6.60
L1701411A1	输出轴	Output shaft		PCS	365.85
L1701313A1	导油板堵盖	Oil guide plug		PCS	0.63
L1701453A1	五档从齿卡环	Fifth driven gear circlip		PCS	0.97
L1701452A1	五档从动齿轮	Fifth driven gear assy.		PCS	140.46
L1701451A1	三、四档双联齿轮	Third、forth duplicate gear		PCS	299.96
L1701430A1	二档从动齿轮总成	Second driven gear assy.		PCS	182.92
L1701456A1	一、二档齿毂卡环	First、second gear hub circlip		PCS	0.97
L1702620A1	五档拨叉总成	Fifth gear fork		PCS	44.20
L1702610A1	三、四档拨叉总成	Third、forth gear fork		PCS	44.97
L1702606A1	三、四档导块	Third、forth gear guide		PCS	16.82
L1702604A1	五、倒档导块	Fifth、reverse gear guide		PCS	16.82
L1702603A1	三档限位衬套	Third stopper sleeve		PCS	1.18
Q436120	卡环—倒档拨销	Circlip		PCS	0.28
L1702602A1	五、倒档叉轴	Fifth、reverse gear forkshaft		PCS	15.50
L1702601A1	三、四档叉轴	Third、forth gear forkshaft		PCS	15.50
L1702200A1	选档机构总成	Gear selector assy.		PCS	27.80
L1702501A1	一、二档叉轴	First、second gear forkshaft		PCS	9.66
Q5270524	螺旋弹性销	Pin		PCS	0.63
L1702510A1	一、二档拨叉总成	First、second gear fork		PCS	46.29
L1701610A1	倒档惰轮总成	Reverse idle gear		PCS	140.46
L1701616A1	倒档惰轮垫圈	Reverse idle gear washer		PCS	0.63
L1701614A1	倒档惰轮轴锁紧螺钉	Reverse idle gear bolt		PCS	2.09

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
L1701613A1	倒档惰轮轴	Reverse idle gear shaft		PCS	8.34
L1702700A1	倒档摇臂机构组件	Reverse swing arm element		PCS	39.55
Q150B0616	倒档锁止装置固定螺栓	Hex bolt		PCS	0.35
L1702400A1	倒档锁止装置	Reverse stopper		PCS	23.98
L2303202A1	主减速从动齿轮	Deceleration driven gear		PCS	198.98
L2303203A1	差速器前、后锥轴承	Differential tapered bearing		PCS	58.59
L2303201A1	差速器壳	Differential shell		PCS	143.45
L2303213A1	主减速从动齿轮连接螺栓	Bolt		PCS	2.22
Q5240535	行星轴定位销	Pin		PCS	0.49
L2303222A1	里程表主动齿轮	Speedometer drive gear		PCS	8.06
L2303209A1	行星齿轮垫片	washer,planet gear		PCS	1.32
L2303208A1	行星齿轮	planet gear		PCS	24.60
L2303211A1	行星齿轮轴	planet gear shaft		PCS	8.34
L2303206A1	半轴齿轮	Differential axle gear		PCS	51.22
L2303207A1	半轴齿轮垫片	Differential axle gear washer		PCS	0.97
L2303216A1	差速器轴承调整垫片	Differential bearing shim		PCS	0.83
L1602206A1	分离拨叉-防尘罩			PCS	3.84
LF479Q1-1003200A1	气缸盖罩总成	Cylinder head cover assy		PCS	142.80
LF479Q1-1003212A	挡油板（I）	Oil baffle I		PCS	7.20
LF479Q1-1003213A	挡油板（II）	Oil baffle II		PCS	6.00
LF479Q1-1003201A	加油口盖	Cap,oil filler		PCS	5.16
LF479Q1-3707100A	高压阻尼线（I）	Ignition cable 1		PCS	15.78
LF479Q1-3707200A	高压阻尼线（II）	Ignition cable 2		PCS	15.78
LF479Q1-3707300A	高压阻尼线（III）	Ignition cable 3		PCS	15.78
LF479Q1-3707400A	高压阻尼线（IV）	Ignition cable 4		PCS	15.78
LF479Q1-1014011A	PCV阀通气软管	PCV vent hose		PCS	1.08

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
LBA1109012	长通气软管	Longe hose		PCS	1. 07
LF479Q1-1014100A	PCV阀总成	PCV assy.		PCS	7. 32
LF479Q1-1003015A	气缸盖罩密封垫	Gasket, cylinder head cover		PCS	10. 22
LF479Q1-1003018A	气缸盖罩螺母	Cylinder head cover nut	M6	PCS	0. 83
LF479Q1-1003017A	气缸盖罩螺栓密封垫	Cylinder head cover bolt gasket		PCS	0. 49
LF479Q1-1014014A	PCV阀密封圈	PCV seal		PCS	1. 20
LF479Q1-1003203A	汽缸盖罩油封	Seal,cylinder head cover		PCS	2. 09
LF479Q1-1003100A	气缸盖总成	Cylinder Head assy.		PCS	970. 29
LF479Q1-1003016A	半圆塞	Semi-Circle Plug		PCS	1. 08
LF479Q1-1300017A	出水管	Outlet tube		PCS	7. 19
Q1840820	六角法兰面螺栓	Hex flange bolt		PCS	0. 35
LF481Q1-1003300A	气缸盖密封垫总成	Gasket		PCS	38. 40
LF479Q1-1003013A	气缸盖连接组合螺栓（排气侧）	Cylinder head bolt(exhaust)	1*1.25*18	PCS	2. 99
LF479Q1-1003012A	气缸盖连接组合螺栓（进气侧）	Cylinder head bolt(intake)	1*1.25*9	PCS	2. 43
LF479Q1-3707011A	火花塞套筒	Spark pulg guild pipe		PCS	2. 34
LF479Q1-1003019A	气缸盖罩双头螺栓	Cylinder head cover thru-stud	M6*4/43	PCS	1. 95
LF479Q1-1003014A	汽缸盖螺栓垫圈	Cylinder head bolt washer		PCS	0. 36
LF479Q1-1307012A	水泵O型密封圈	Water Pump O-Ring	φ3*33.5	PCS	0. 28
LF479Q1-3612200A	爆震传感器	Knock Sensor		PCS	119. 33
LF481Q1-1002100A	曲轴箱总成	Crank case assy.		PCS	1012. 55
LF479Q1-1005019A	曲轴后油封	Crankshaft rear seal		PCS	9. 73
Q1841016	六角螺栓	Hex bolt		PCS	0. 49
LF479Q1-1701012A	变速器挡板	Transimission Plate		PCS	15. 96
Q1840616	六角法兰面螺栓	Hex flange bolt		PCS	0. 22
LF479Q1-1005018A	曲轴后端盖	Crankshaft rear cover		PCS	11. 98
Q5220614	曲轴后端盖定位销	Crankshaft rear cover pin		PCS	0. 28

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
LF479Q1-1005017A	曲轴后端盖密封垫	Crankshaft rear gasket		PCS	2.99
LF479Q1-3818100A	机油压力报警器	Oil pressure warner		PCS	9.84
LF479Q1-1017100A	机油滤清器总成	Oil Filter Assy		PCS	12.65
LF479Q1-1017011A	机油滤清器连接管	Oil Filter connecting pipe		PCS	2.57
LF481Q1-1006101A	进气凸轮轴	Intake Camshaft		PCS	116.41
LF479Q1-1007018A	进气门油封	Intake valve seal		PCS	2.15
LF479Q1-1007021A-1	填隙片	Shim	$235 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-2	填隙片	Shim	$240 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-3	填隙片	Shim	$245 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-4	填隙片	Shim	$250 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-5	填隙片	Shim	$255 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-6	填隙片	Shim	$260 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-7	填隙片	Shim	$265 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-8	填隙片	Shim	$270 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-9	填隙片	Shim	$275 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-10	填隙片	Shim	$280 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-11	填隙片	Shim	$285 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-12	填隙片	Shim	$290 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-13	填隙片	Shim	$295 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-14	填隙片	Shim	$300 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-15	填隙片	Shim	$305 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-16	填隙片	Shim	$310 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-17	填隙片	Shim	$315 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-18	填隙片	Shim	$320 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-19	填隙片	Shim	$325 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-20	填隙片	Shim	$330 \times (10^{-2})$ mm	PCS	2.57

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
LF479Q1-1007021A-21	填隙片	Shim	$335 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-22	填隙片	Shim	$340 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-23	填隙片	Shim	$345 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007021A-24	填隙片	Shim	$350 \times (10^{-2})$ mm	PCS	2.57
LF479Q1-1007019A	挺柱	Tappet		PCS	8.34
LF479Q1-1007016A	气门锁片	Valve Lock		PCS	0.42
LF479Q1-1007015A	气门弹簧座	Valve Spring Retainer		PCS	1.15
LF479Q1-1007013A	气门弹簧	Valve Spring		PCS	2.15
LF479Q1-1007017A	排气门油封	Exhaust Valve Seal		PCS	2.15
LF479Q1-1007014A	气门弹簧底座	Valve Spring Seat		PCS	0.25
LF481Q1-1007011A	排气门	Exhaust Valve		PCS	10.20
LF481Q1-1007012A	进气门	Intake Valve		PCS	9.00
LF479Q1-1006202A	排气正时齿轮	Exhaust timing gear		PCS	26.97
LF481Q1-1006201A	排气凸轮轴	Exhaust Camshaft		PCS	134.76
LF479Q1-1006203A	排气齿轮卡环	Exhaust gear snap ring		PCS	0.63
LF479Q1-1006011A	凸轮轴油封	Camshaft shaft seal		PCS	2.15
LF479Q1-1006203A	排气齿轮卡环	Exhaust gear snap ring		PCS	0.63
LF479Q1-1006104A	波形垫	Wave Washer		PCS	0.58
LF479Q1-1006106A	进气正时齿轮副齿	Intake timing sub gear		PCS	17.31
LF479Q1-1006103A	消隙弹簧	Backlash spring		PCS	3.75
LF479Q1-1006105A	进气正时齿轮	Intake timing gear		PCS	26.97
LF479Q1-1006107A	进气齿轮卡环	Exhaust gear snap ring		PCS	1.32
LF481Q1-1005015A	曲轴上轴瓦	Crankshaft upper bearing	ordered in suite	PCS	1.74
LF481Q1-1005024A	曲轴下轴瓦	Crankshaft lower bearing	ordered in suite	PCS	1.74
LF479Q1-1005013A	曲轴上止推片	Crankshaft upper thrust washer	ordered in suite	PCS	0.94
LF479Q1-1005014A	曲轴下止推片	Crankshaft lower thrust washer	ordered in suite	PCS	0.94

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
LF479Q1-1005022A	曲轴前油封	Crankshaft front seal		PCS	4.31
LF479Q1-1005012A	半圆键	Crankshaft woodruff key		PCS	0.83
LF481Q1-1005011A	曲轴	Crankshaft		PCS	348.00
LF479Q1-1004013A	活塞销	Piston Pin		PCS	5.04
LF481Q1-1004201A	活塞环I	Piston ring I	ordered in suite	PCS	5.52
LF481Q1-1004202A	活塞环II	Piston ring II	ordered in suite	PCS	3.94
LF481Q1-1004211A	片环	Piece ring	ordered in suite	PCS	3.75
LF481Q1-1004212A	衬环	Sleeve ring	ordered in suite	PCS	3.75
LF481Q1-1004012A	活塞	Piston	ordered in suite	PCS	17.97
LF481Q1-1004011A	连杆轴瓦	Rod Bearing	ordered in suite	PCS	1.67
LF479Q1-1004100A	连杆	Rod		PCS	37.25
Q1840620	六角法兰面螺栓	Hex flange bolt		PCS	0.20
LF479Q1-1025021A	前罩壳上体	Front cover upper		PCS	2.88
LF479Q1-1025022A	前罩壳中体	Front cover middle		PCS	2.88
Q1840625	六角法兰面螺栓	Bolt		PCS	0.28
LF479Q1-1025023A	前罩壳下体	Front cover lower		PCS	3.12
LF479Q1-1025014A	凸轮轴正时皮带轮	Camshaft timing pulley		PCS	13.54
Q1841025	六角法兰面螺栓	Hex flange bolt		PCS	0.44
LF479Q1-1025100A	张紧轮总成	Tenioner		PCS	19.81
Q1841040	六角螺栓	Bolt		PCS	0.72
LF479Q1-1025025A	张紧轮扭簧	Tenioner spring		PCS	0.76
LF479Q1-1025018A	曲轴正时皮带轮前挡片	Front plate,crankshaft timing pulley		PCS	2.16
LF479Q1-1025012A	曲轴正时皮带轮	Crank shaft timing pulley		PCS	5.98
LF479Q1-1025019A	曲轴正时皮带轮后挡片	End plate ,crankshaft timing pulley		PCS	0.96
LF479Q1-1025016A	正时皮带	Timing belt		PCS	43.14
LF479Q1-1010011A	机油集滤器密封垫	Gasket, oil strainer		PCS	0.56

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
LF479Q1-1009012A	机油盘双头螺柱	Thru-stud	6*1/11	PCS	0.42
Q32006	六角法兰面螺母	Hex flange bolt		PCS	0.24
LF479Q1-1010100A	机油集滤器总成	Oil strainer sub-assy		PCS	12.66
Q1840612	六角法兰面螺栓	Hex flange bolt		PCS	0.18
LF479Q1-1009100A	机油盘总成	Oil Pan		PCS	45.00
LF479Q1-1009012A	机油盘双头螺柱	Thru-stud	6*1/11	PCS	0.42
Q32006	六角法兰面螺母	Hex flange bolt		PCS	0.24
LF479Q1-1009013A	放油螺塞	Oil plug	12*1.25*16	PCS	1.18
Q40112T4F	放油螺塞垫圈	Oil plug washer		PCS	3.75
LF479Q1-1009015A	油位计导管	Oil level gauge guide		PCS	5.34
LF479Q1-1009300A	油位计总成	Oil level gauge assy		PCS	3.06
LF479Q1-1009011A	O型密封圈	O seal		PCS	0.12
Q1840825	六角法兰面螺栓	Bolt		PCS	0.37
Q32008	六角法兰面螺母	Hex flange nut		PCS	0.28
LF481Q1-1008201A	进气歧管上体	upper intake manifold		PCS	54.00
LF479Q1-1104014A	碳罐控制阀托架	Canister Control Valve bracket		PCS	0.96
LF479Q1-1108011A	油门拉索支架	Throttle cable bracket		PCS	1.60
LF479Q1-3765011A	节气门体总成密封垫	Throttle gasket		PCS	1.60
LBA1132100	节气门体总成	Throttle assy	Delphi	PCS	322.92
LBA1132100B1	节气门体总成	Throttle assy	Sun&teck	PCS	249.60
LBA1132100C1	节气门体总成	Throttle Assy	Sun&teck, plastic manifold	PCS	249.60
Q1840650	节气门螺栓	Throttle bolt		PCS	0.42
LF479Q1-1008203A	进气歧管上下体密封垫	Gasket upper&lower intake manifold		PCS	5.21
LF479Q1-1008202A	进气歧管下体	Lower intake manifold		PCS	247.98
LF479Q1-1008018A	双头螺栓	Thru-stud	M8*12/26	PCS	0.56
LF479Q1-3614011A	进气温度压力传感器支架	Bracket,temperature&pressure sensor	delphi	PCS	0.66

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
LF479Q1-1008018A	双头螺栓	Thru-stud	M8*12/26	PCS	0.56
Q32008	六角法兰面螺母	Hex flange nut		PCS	0.28
LF479Q1-1008014A	进气歧管密封垫	Intake manifold gasket		PCS	4.80
Q1840830	六角法兰面螺栓	Bolt,Intake manifold		PCS	0.42
LF479Q1-1008200A	进气歧管总成	Intake manifold		PCS	186.00
LF479Q1-1008200A1	进气歧管总成	Intake manifold	Plastic	PCS	186.00
LF479Q1-1008013B	排气歧管密封垫	Exhaust manifold gasket	1.2±.1	PCS	3.60
LF481Q1-1008100A	排气歧管总成	Exhaust Manifold		PCS	114.00
LF479Q1-1008011A	排气歧管上罩	Heat Insulator upper		PCS	26.97
Q1840610	螺栓	Bolt		PCS	0.18
LF479Q1-1008012A	排气歧管下罩	Heat insulator lower		PCS	5.21
Q32010	六角法兰面螺母	Nut		PCS	0.38
LF479Q1-1008017A	排气歧管双头螺柱	Thru-stud	1*1.25*2/2	PCS	0.58
Q1840816	六角法兰面螺栓	Bolt		PCS	0.33
LF479Q1-1008016A	排气歧管支架	Exhaust manifold bracket		PCS	5.21
Q1841016	六角螺栓	Hex bolt		PCS	0.49
LF479Q1-1306201A	节温器座	Thermostat seat		PCS	28.08
Q1840840	六角螺栓	Bolt		PCS	0.42
LF479Q1-1306100A	节温器总成	Thermostat assy		PCS	13.61
LF479Q1-1300015A	进水管总成	Inlet tube		PCS	7.79
Q1840620	六角法兰面螺栓	Hex flange bolt		PCS	0.20
Q32008	六角法兰面螺母	Hex flange nut		PCS	0.28
LF479Q1-1306012A	节温器座双头螺栓	Thru-stud,thermostat seat	8*15/36	PCS	0.83
Q1840612	六角法兰面螺栓	Hex flange bolt		PCS	0.18
LF479Q1-1025011A	水泵皮带轮	Water pump pulley		PCS	34.47
LF479Q1-1025013A	曲轴皮带轮	Crankshaft Pulley		PCS	57.60

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
LF479Q1-1025015A	皮带	Water pump and generator belt	water pump	PCS	19.39
Q40212	平垫圈	Washer		PCS	0.47
LF479Q1-1025024A	曲轴皮带轮螺栓	Crankshaft pulley bolt	12*1.25*36	PCS	1.60
Q1840825	六角法兰面螺栓	Bolt		PCS	0.37
LBA1121100	燃油分配管总成	Fuel Distributor	delphi	PCS	463.32
LBA1121100B1	燃油分配管总成	Fuel Distributor	sun&teck with OBD	PCS	496.09
LBA1124100B1	燃油喷射器	Fuel injector	sun&teck with OBD	PCS	114.00
LBA3705100B1	点火线圈总成	Ignition Coil	su&teck with OBD	PCS	123.50
LBA1132100	节气门体总成	Throttle assy	delphi	PCS	322.92
LBA1132100B1	节气门体总成	Throttle assy	sun&teck with OBD	PCS	249.60
LBA1132100C1	节气门体总成	Throttle Assy		PCS	249.60
LBA3614300	进气温度压力传感器	Temperature And Pressure Sensor	delphi	PCS	168.33
LBA3614300B1	进气温度压力传感器	Temperature And Pressure Sensor	sun&teck with OBD	PCS	153.38
LBA1130310	碳罐控制阀	Canister Control Valve	delphi	PCS	56.43
LBA1130310B1	碳罐控制阀	Canister Control Valve	sun&teck with OBD	PCS	32.94
LF479Q1-3707800A	火花塞总成	Spark Pluge		PCS	10.19
LBA3612400	爆震传感器	Knock Sensor		PCS	119.33
LBA3612400B1	爆震传感器	Knock Sensor	with OBD	PCS	41.14
LBA3612600	曲轴位置传感器	Crankshaft Position Sensor		PCS	92.92
LBA3612600B1	曲轴位置传感器	Crankshaft Position Sensor	sun&teck with OBD	PCS	31.90
LBA3616100	水温传感器	Water Temperature Sensor	delphi	PCS	33.15
LBA3616100B1	水温传感器	Water Temperature Sensor	sun&teck with OBD	PCS	25.72
LF479Q1-3818100A	机油压力报警器	Oil pressure warner		PCS	9.84
LBA3612300	氧传感器	Oxygen Sensor	delphi	PCS	161.46
LBA3612300B1	氧传感器	Oxygen Sensor	sun&teck with OBD	PCS	192.00
LBF3612300	前氧传感器	Front oxygen Sensor		PCS	168.00

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
LBF3612300B1	后氧传感器	Rear oxygen Sensor		PCS	168.00
LBA1121100	燃油分配管总成	Fuel Distributor	delphi	PCS	463.32
LBA1121100B1	燃油分配管总成	Fuel Distributor	sun&teck with OBD	PCS	496.09
LBA1124100B1	燃油喷射器	Fuel injector	sun&teck with OBD	PCS	114.00
LF481Q1-3611011A	曲轴位置传感器垫片	Crankshaft Position Sensor gasket		PCS	3.24
Q1840630	曲轴位置传感器螺栓	Crankshaft Position Sensor bolt		PCS	0.28
LBA1132160	节气门位置传感器	Throttle position sensor	delphi	PCS	67.90
LBA1132160B1	节气门位置传感器	Throttle position sensor	sun&teck with OBD	PCS	67.90
LBA1132150	怠速步进电机	Idle motor	delphi	PCS	87.05
LBA1132150B1	怠速步进电机	Idle motor	sun&teck with OBD	PCS	86.46
LF479Q1-1008018A	双头螺栓	Thru-stud	M8*12/26	PCS	0.56
Q676B45	水泵进出水软管管夹	Clip		PCS	3.00
LF479Q1-1307015A	水泵进水胶管	Inlet Water Hose		PCS	1.08
LF479Q1-1307013A	水泵进水管	Inlet Water Hose		PCS	23.97
Q1840610	螺栓	Bolt		PCS	0.18
Q32008	六角法兰面螺母	Hex flange nut		PCS	0.28
Q150B0835	六角头螺栓	Bolt		PCS	0.27
LF479Q3-1307100A-1	水泵总成	Water Pump		PCS	115.20
LF479Q1-3701011A	发电机调节支架	Generator adjusting bracket		PCS	10.77
LF479Q1-1024012A	缸盖右吊钩	Cylinder head right hook		PCS	3.75
LF479Q1-1001400A	发动机右安装支架	Engine right bracket		PCS	25.85
LF479Q1-1024011A	缸盖左吊钩	Cylinder head left hook		PCS	3.89
LF479Q1-3701200A	发电机托架总成	Generator bracket assy.		PCS	23.70
LF479Q1-3705011A	点火线圈支架	Ignition coil bracket		PCS	6.36
LF479Q1-1008015A	进气歧管支撑架	Intake manifold bracket		PCS	10.80
Q5220820	离合器压盘定位销	Pin		PCS	0.28

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
LF481Q1-1005100A	飞轮齿圈总成	Flywheel rim		PCS	177. 60
LF479Q1-1005023A	飞轮螺栓	Flywheel bolt	M1*1.25*25	PCS	0. 96
LF481Q1-1601200A	离合器从动盘总成	Clutch Driven Plate		PCS	110. 51
LF481Q1-1601100A	离合器压盘总成	Clutch press plate		PCS	124. 80
LF479Q1-1601012A	离合器组合螺栓	Clutch cover bolt	8*16	PCS	0. 42
LF481Q1-1011100A	机油泵总成	Oil Pump Assy		PCS	91. 20
LF479Q1-1011011A	机油泵密封垫	Gasket, oil pump		PCS	4. 31
LF479Q1-1011012A	机油泵定位销	Oil pump pin	φ11*8	PCS	0. 49
Q1840825	六角法兰面螺栓	Bolt		PCS	0. 37
LF479Q1-3701013A	发电机紧固螺母	Generator nut	M1*1.25	PCS	1. 32
LF481Q1-3701100A	发电机总成	Generator assy.		PCS	433. 78
Q18410105	发电机托架螺栓	Generator bracket bolt		PCS	2. 29
LF481Q1-3708100A	起动电机总成	Startor assy.		PCS	292. 56
Q1841040	六角螺栓	Bolt		PCS	0. 72
LF479Q3-3701110A	皮带轮	Pulley	Generator spare part	PCS	9. 60
LF479Q3-3701120A	前端盖	Front cap	Generator spare part	PCS	27. 60
LF479Q3-3701130A	前滚动轴承	Bearing	Generator spare part	PCS	13. 20
LF479Q3-3701140A	定子	Stator	Generator spare part	PCS	90. 00
LF479Q3-3701150A	转子	Rotor	Generator spare part	PCS	103. 20
LF479Q3-3701160A	后滚动轴承	Bearing	Generator spare part	PCS	8. 40
LF479Q3-3701170A	后盖组成	End cap	Generator spare part	PCS	24. 00
LF479Q3-3701180A	电压调节器	Voltage regulator	Generator spare part	PCS	67. 20
LF479Q3-3701190A	电刷总成	Brush	Generator spare part	PCS	9. 60
LF479Q3-3701111A	整流器	Rectifier	Generator spare part	PCS	48. 00
LF479Q3-3701112A	绝缘套	Insulant	Generator spare part	PCS	1. 20
LF479Q3-3701113A	罩盖	Cover	Generator spare part	PCS	8. 40

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
LF479Q3-3708110A	前盖总成	Front cap assy.	Startor spare part	PCS	27.00
LF479Q3-3708120A	单向器	unidirectional	Startor spare part	PCS	27.00
LF479Q3-3708130A	电磁开关	Solenoid Switch	Startor spare part	PCS	45.60
LF479Q3-3708140A	星轮轮轴总成	Star gear	Startor spare part	PCS	19.80
LF479Q3-3708150A	减速齿轮总成	Reducing gear	Startor spare part	PCS	6.84
LF479Q3-3708160A	星形齿轮总成	Spider gear	Startor spare part	PCS	1.80
LF479Q3-3708170A	电枢总成	Armature	Startor spare part	PCS	78.00
LF479Q3-3708180A	机壳总成	Shuck	Startor spare part	PCS	32.40
LF479Q3-3708190A	刷架总成	Brush bracket	Startor spare part	PCS	26.40
LF479Q3-3708111A	电刷端盖总成	Front cap with brush assy.	Startor spare part	PCS	6.72
LF479Q3-3708112A	拨叉	Fork	Startor spare part	PCS	1.20
LF481Q1-1700000A	变速器总成	Transmission assy.		PCS	3960.00
LF481Q1-1701011A	离合器壳体	Clutch shell	old status	PCS	407.48
LF481Q1-2303321A	T型差速器油封	Differential T seal	clutch side old status	PCS	10.71
LF481Q1-1701023A	连接螺栓	Connecting bolt	M8X35	PCS	0.71
LF481Q1-1702110A	换档导轴组件	Shift shaft component		PCS	38.50
LF481Q1-1701330A	分离拨叉	Throwout fork		PCS	11.54
LF481Q1-1701331A	分离拨叉护套	Throwout fork sleeve		PCS	6.53
LF481Q1-1702160A	离合器分泵	Clutch slave cylinder		PCS	59.63
LF481Q1-1702047A	拉线支架螺栓	Cable bracket bolt	M8X18	PCS	0.64
LF481Q1-1701024A	油管支架	Tube bracket		PCS	0.36
LF481Q1-1701026A	六角头螺塞	Hex bolt plug		PCS	1.26
LF481Q1-1701033A	换档定位总成	Shift position device		PCS	36.56
LF481Q1-1701154A	端盖	End cover		PCS	4.80
LF481Q1-1701155A	端盖螺栓	End cover bolt	M6X18.5	PCS	0.63
LF481Q1-1701334A	分离轴承	Throwout bearing		PCS	41.70

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
LF481Q1-1701333A	分离拨叉支撑柱	Throwout fork support		PCS	5.35
LF481Q1-2303314A	T型差速器油封	Differential T seal	transimission side old status	PCS	13.69
LF481Q1-1701030A	输入轴S型油封	Input shaft S seal	23*37*7	PCS	6.95
LF481Q1-1702159A	离合器分泵螺栓	Bolt		PCS	0.56
LF481Q1-1702157A	换档盖紧固螺栓	Bolt		PCS	0.62
LF481Q1-1702158A	换档盖定位螺栓	Bolt		PCS	0.59
LF481Q1-1701034A	导油槽	Oil passage		PCS	2.62
LF481Q1-1702170A	液压油管	Hydraulic tube		PCS	15.92
LF481Q1-1701086A	铝垫	Aluminium washer		PCS	0.22
LF481Q1-1701069A	五档同步环	Fifth synchronize rim		PCS	15.50
LF481Q1-1701044A	输入四档止推垫定位球	Input forth thrust washer ball		PCS	0.05
LF481Q1-1701065A	四档同步环	Forth synchronize rim		PCS	15.50
LF481Q1-1701042A	同步器档圈	Synchronize circlip		PCS	0.71
LF481Q1-1701059A	三档同步环	Third synchronize rim		PCS	15.50
LF481Q1-1701141A	输出轴前轴承	Output shaft front bearing	3X55X17	PCS	59.21
LF481Q1-1701113A	一档同步环	First synchronize rim		PCS	15.71
LF481Q1-1701124A	二档同步环	Second gear synchronize rim		PCS	15.36
LF481Q1-1701127A	二档滚针轴承	Second gear needle bearing	K34X39X23TN	PCS	7.23
LF481Q1-1701138A	四档从动齿轮	Forth driven gear		PCS	32.18
LF481Q1-1701150A	输出轴后轴承	Output shaft rear bearing	2X47X15	PCS	33.22
LF481Q1-1701120A	一二档同步器总成	First second synchronize assy.		PCS	85.49
LF481Q1-1701103A	一档滚针轴承	First needle bearing	K34X39X28DTN	PCS	8.13
LF481Q1-1701106A	输出轴	Output shaft		PCS	238.18
LF481Q1-1701101A	输出五档档圈	Output fifth circlip		PCS	0.56
LF481Q1-1701137A	输出轴三档定位套	Output third position sleeve		PCS	1.67
LF481Q1-1702081A	互锁销B	Interlock pin		PCS	1.40

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
LF481Q1-1702082A	互锁销B	Interlock pin		PCS	1.40
LF481Q1-1702072A	五倒档换档导块	Fifth reverse shift block		PCS	13.21
LF481Q1-1702054A	换档叉止动螺栓	Shift fork stop bolt	M6X.75X19	PCS	0.49
LF481Q1-1702056A	弹性圆柱销	Spring pin	5.5X22	PCS	4.80
LF481Q1-1702057A	叉轴档圈	Fork shaft circlip	1.5x11.6x16.6	PCS	0.14
LF481Q1-1702074A	拨叉回位弹簧	Fork spring		PCS	0.93
LF481Q1-2303304A	半轴齿轮垫片	Differential axle gear washer		PCS	1.34
LF481Q1-2303301A	差速器壳	Differential shell	old and new status	PCS	106.47
LF481Q1-2303306A	行星齿轮轴	Planet gear shaft		PCS	9.04
LF481Q1-2303302A	半轴齿轮	Differential axle gear		PCS	25.51
LF481Q1-2303312A	差速器后轴承6308	Differential rear bearing	old status	PCS	27.87
LF481Q1-2303311A	差速器螺栓	Differential bolt	M12X1X19.5	PCS	1.95
LF481Q1-2303308A	差速器齿圈	Differential roller bearing		PCS	144.12
LF481Q1-2303307A	圆柱销	Pin		PCS	0.25
LF481Q1-2303303A	行星齿轮	Planet gear		PCS	23.35
LF481Q1-2303300A	差速器总成	Differential assy.		PCS	456.60
LF479Q1-3802100A	里程表传感器	Speedometer sensor		PCS	30.00
LF481Q1-1702141A	通气塞垫片	Vent valve gasket	1X14X1.5	PCS	0.17
LF481Q1-1702151A	换档盖	Shift cap		PCS	17.51
LF481Q1-1702138A	换挡导轴挡圈	Shift shaft circlip	A15X21X1.5	PCS	2.02
LF481Q1-1702128A	回位弹簧座	Return spring seat		PCS	1.46
LF481Q1-1702156A	回位弹簧	Return spring	A1.5x26.6x63x7.5	PCS	1.25
LF481Q1-1702035A	换位摇臂油封	Transposition swing arm seal	16x26x7	PCS	2.92
LF481Q1-1702115A	换位摆杆螺栓	Transposition swing lever bolt	M8X21	PCS	0.70
LF481Q1-1702030A	换位摇臂组件	Transposition swing arm		PCS	8.41
LF481Q1-1702142A	换档摆杆	Shift swinglever		PCS	6.53

Parts code	配件名称	Parts name	Description	Unit	FOB price (¥)
LF481Q1-1702116A	换档摆杆弹性圆柱销	Pin	5.5X26	PCS	0.44
LF481Q1-1702155A	回位弹簧	Return spring	B1.2x13.2x63x9	PCS	0.90
LF481Q1-1702154A	换档导轴尼龙垫圈	Shift shaft washer		PCS	0.14
LF481Q1-1702137A	换挡导轴挡圈	Shift shaft circlip	A1.5/3x21	PCS	0.14
LF481Q1-1702108A	换档摆杆互锁架	Shift swinglever interlock bracket		PCS	15.92
LF481Q1-1702120A	五倒档互锁凸轮	Fifth reverse cam		PCS	10.70
LF481Q1-1702122A	五倒档互锁凸轮弹簧	Fifth reverse cam spring		PCS	3.41
LF481Q1-1702016A	换挡盖定位环	Shift cap position ring	11X8.5X12	PCS	1.67
LF481Q1-1702121A	五倒档互锁凸轮密封球	Fifth reverse cam seal ball	6.2	PCS	0.05
LF481Q1-1702152A	换挡盖衬套	Shift cap bush	18X21X1	PCS	2.64
LF481Q1-1702036A	换挡导轴油封	Shift shaft seal	18x28x8	PCS	3.75
LF481Q1-1702105A	换挡导轴护套	Shift shaft sleeve		PCS	2.92
LF481Q1-1702110A	换挡导轴组件	Shift shaft component		PCS	38.50
LF481Q1-1702114A	换位摆杆	Transposition swing lever		PCS	5.07
LF481Q1-1702123A	五倒档互锁凸轮销	Fifth reverse cam pin		PCS	1.04
LF481Q1-1701090A	倒档摆臂支架总成	Reverse swing arm bracket		PCS	16.33
LF481Q1-1701085A	倒档摆臂支架垫	Washer		PCS	0.98
LF481Q1-1701095A	倒档摆臂支架螺栓	Bolt		PCS	0.49
LF481Q1-1701081A	倒档中间齿轮轴	Reverse middle gear shaft		PCS	5.98
LF481Q1-1701080A	倒档中间齿轮总成	Reverse middle gear assy.		PCS	30.09
LF481Q1-1701083A	倒档中间齿轮螺栓	Bolt		PCS	0.59
LF481Q1-1701211A	里程表传动被动齿轮	Speedometer driven gear		PCS	9.38
LF481Q1-1701215A	里程表定位卡簧	Speedometer circlip		PCS	0.63
LF481Q1-1701214A	O型橡胶密封圈	O seal		PCS	0.38
LF481Q1-1701213A	里程表油封	Speedometer seal		PCS	3.75
LF481Q1-1701217A	里程表护套	Speedometer sleeve		PCS	0.42



Chongqing Lifan Industry(group)Imp.&Exp.co.,Ltd

Add:NO.60 Zhangjiawan,Shangqiao,Shapingba
District,Chongqing,China.

Website:www.lifanauto.com

E-mail:iecauto@lifan.com